

# OPERATOR'S MANUAL

Original instructions

## TCR50-2

Serial No. 305400002~

Book No. AAA0E001

OETCR50-2\_4-XB

**CRAWLER DUMPER**

**TAKEUCHI**



**WARNING** Read and understand these instructions.  
Failure to do so can cause injury or death.

## SAFETY ALERT SYMBOL




This symbol represents the safety alert. The message that follows the symbol contains important information about safety. Read and understand the message to avoid personal injury or death.

It is the owner or employer's responsibility to fully instruct each operator in the proper and safe operation of all equipment. All persons using this machine should thoroughly familiarize themselves with the contents of this manual.

All operators must be instructed on the proper functions of this machine before running the machine.

Learn and practice correct use of the machine controls in a safe, clear area before operating this machine on a job site.



Improper operation, inspection and maintenance of this machine can cause injury or death.

**Read and understand this manual before performing any operation, inspection or maintenance on this machine.**

Always store this manual near at hand preferably on the machine itself. If it should be lost or damaged, immediately order a new one from your Takeuchi dealer.

When transferring ownership of this machine, be sure to hand this manual to the next owner.

Takeuchi supplies machines complying with the local regulations and standards of the country of export. If your machine has been purchased in another country or from a person or company of another country, it may not have the safety devices or safety standards required for use in your country. Should you have any question about whether your machine complies with the regulations and standards of your country, contact a Takeuchi dealer.

## SIGNAL WORDS

Safety messages appearing in this manual and on machine decals are identified by the words “DANGER”, “WARNING” and “CAUTION”. These signal words mean the following:



### **DANGER**

**DANGER** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.



### **WARNING**

**WARNING** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.



### **CAUTION**

**CAUTION** indicates a hazard with a low level of risk which, if not avoided, could result in minor moderate injury.

**IMPORTANT:** The word **IMPORTANT** is used to alert operators and maintenance personnel about situations which could result in damage to the machine and its components.

It is impossible to foresee every possible circumstance that might involve a potential hazard. The warnings in this manual or on the machine can not cover all possible contingencies. You must exercise all due care and follow normal safety procedures when operating the machine so as to ensure that no damage occurs to the machine, its operators or other persons.

# INTRODUCTION

---

## FOREWORD


This manual describes operation, inspection and maintenance of the machine, as well as safety instructions to be heeded during these operations.

If you have any questions about the machine, please contact a Takeuchi sales or service outlet.

- Some details in this manual may differ from those provided in the machine you are using.
- Please note that the information and specifications in this manual are subject to change without prior notice.

## MANUAL STORAGE COMPARTMENT


A compartment for storing this manual is provided at the position shown on the diagram below.




## SERIAL NUMBERS

**IMPORTANT: Do not remove the machine name plate with the serial number. Check the serial numbers of the machine and engine and write them down in the spaces below.**

**Machine number:**




**Engine number:**





# MACHINE DESCRIPTION

## FRONT, REAR, LEFT AND RIGHT



This manual refers the front, rear, left and right of the machine as seen when sitting in the operator's seat.

## DESIGNATED OPERATIONS

Use this machine primarily for the following operations:

- Hauling over rough terrain

## FEATURES

- Hydrostatic drive system
- Safety structure cab with ROPS/FOPS
- Engine emergency stop system
- Dump body with 90-degree right/left swing
- Low engine noise and exhaust emissions

## BREAK-IN PERIOD

When the machine is new, operate the machine for the first 100 hours (as indicated on the hour meter) by following the instructions below.

Using a new machine without a break-in period will lead to quicker deterioration of machine performance and may shorten the machine's service life.

- Sufficiently warm up the engine and hydraulic oil.
- Avoid heavy loads and rapid operations. Operate with a load of about 80% the maximum load.
- Do not abruptly start up, accelerate, change directions, or stop unless necessary.


## NOTES ON READING THIS MANUAL

Please note that the descriptions and diagrams included in this manual may not be applicable to your machine.

The numbers used in the illustration are with circles around them. The same numbers appear between the parentheses in the text. (Example: ① → (1))

Symbols used in this manual

The symbols used in this manual have the following meanings.

 ,  ..... Prohibition

 ..... Lock

 ..... Unlock

## ABBREVIATION USED IN THIS MANUAL

The abbreviations used in this manual are described below.

DPF ..... Diesel Particulate Filter

PM ..... Particulate Matter

SCR ..... Selective Catalytic Reduction

DEF ..... Diesel Exhaust Fluid

AdBlue® . Registered trademark of the  
Verband der Automobilindustrie  
e.V. in Germany.

ECU ..... Engine Control Unit

DQC ..... DEUTZ Quality Class

# CONTENTS

## Introduction .....0-2

## Machine description .....0-3

## Safety .....1-1

General precautions .....	1-2
Precautions when preparing .....	1-11
Precautions when starting .....	1-14
Precautions when operating .....	1-16
Precautions when stopping .....	1-24
Precautions when transporting .....	1-25
Precautions on maintenance .....	1-26
Safety signs (decals) .....	1-37

## Controls .....2-1

Names of components .....	2-2
Covers.....	2-4
Ignition key .....	2-4
Fuel filler port .....	2-4
DEF/AdBlue® refill port .....	2-5
Engine hood .....	2-6
Side cover (tool box) .....	2-7
Battery cover .....	2-7
Dump body prop .....	2-8
Cab .....	2-9
Cab door .....	2-9
Emergency exit .....	2-9
Front window.....	2-10
Lower front window .....	2-11
Side window .....	2-12
Emergency hammer (optional) .....	2-12
Seat and seat belt .....	2-13
Seat .....	2-13
Seat belt.....	2-15
Multi-information display .....	2-16
Home screen.....	2-16
Warning lamps.....	2-17
Indicators.....	2-20
Screen control key.....	2-24
Screen navigation .....	2-26
Switching images .....	2-30
Switches .....	2-31
Ignition switch.....	2-31
Engine shutdown switch.....	2-31
Throttle controller.....	2-31
Horn button.....	2-32
Deceleration button .....	2-32
Turn signal buttons .....	2-32
Travel speed button .....	2-33

Automatic deceleration switch .....	2-33
DPF manual regeneration/inhibit select switch.....	2-34
Parking brake switch .....	2-36
Working light switch.....	2-36
Front wiper switch .....	2-37
Washer switch .....	2-37
Beacon lamp switch (If equipped) .....	2-37
Rear wiper/Washer switch .....	2-38
Levers and Pedals .....	2-39
Safety lock lever .....	2-39
Control levers .....	2-39
Throttle pedal .....	2-40
Accessories.....	2-41
Air conditioner (If equipped) .....	2-41
Heater (If equipped) .....	2-47
Cup holder .....	2-48
Power supply socket .....	2-48
External power socket .....	2-49
Interior light.....	2-49
Radio (If equipped).....	2-50
Fuel Supply Pump (If equipped) .....	2-62
Rear light (if equipped) .....	2-62
Mirrors .....	2-63
Camera .....	2-64
Auto camera mode.....	2-65

## Operation .....3-1

Before starting operation .....	3-2
Getting on or off the machine.....	3-2
Walk-around inspection .....	3-2
Daily inspection.....	3-2
Starting and stopping the engine .....	3-3
Before starting the engine .....	3-3
Starting the Engine .....	3-4
Warming up the engine.....	3-5
Stopping the engine .....	3-5
Operating the machine .....	3-6
Lever pattern .....	3-6
Warming up the machine (hydraulic oil) ..	3-8
Inspection after warm-up.....	3-9
Traveling the machine .....	3-10
Stopping travel .....	3-12
Operating the dump body.....	3-13
Operating procedures.....	3-14
Cautions on operating .....	3-14
Precautions on using the machine in water .....	3-15
Precautions when traveling on slopes ...	3-16
Operations possible with this machine ..	3-17

Parking the machine.....	3-18	Lubricating the dump body and track rollers.....	5-23
Parking.....	3-18	Checking the DEF/AdBlue® level and refilling .....	5-24
Inspection and checks after stopping the engine.....	3-19	After the initial 50 hours (only for new machines).....	5-27
Handling in cold climates.....	3-20	Replacing the hydraulic oil return filter ..	5-27
Preparing for cold climates .....	3-20	Replacing the pilot line filter.....	5-28
Cautions after operations.....	3-20	Inspecting and adjusting the fan belt..	5-29
After the cold climate.....	3-20	Inspecting and adjusting the compressor belt (Air conditioner).....	5-31
Handling rubber tracks .....	3-21	Every 50 hours .....	5-33
Prohibitions.....	3-21	Inspecting the track tension .....	5-33
Cautions.....	3-22	Inspecting the battery fluid level and replenishing .....	5-34
Preventing the rubber tracks from coming off .....	3-22	After the initial 250 hours (only for new machines).....	5-36
Handling the engine.....	3-24	Replacing the travel motor gear oil.....	5-36
Prohibitions.....	3-24	Every 250 hours .....	5-37
Cautions.....	3-24	Inspecting and adjusting the fan belt..	5-37
Diesel fuel.....	3-24	Inspecting and adjusting the compressor belt (Air conditioner) .....	5-37
<b>Transport .....</b>	<b>4-1</b>	Draining the water from the fuel tank..	5-38
Loading and unloading .....	4-2	Cleaning the air cleaner .....	5-39
Hoisting the machine .....	4-3	Cleaning the radiator fins and the oil cooler fins.....	5-41
Securing the machine.....	4-4	Cleaning the condenser (Air conditioner).....	5-41
<b>Maintenance .....</b>	<b>5-1</b>	Cleaning the air filters (Air conditioner/Heater) .....	5-42
General.....	5-2	Inspecting the refrigerant (gas) level (Air conditioner).....	5-43
Maintenance overview .....	5-2	Lubricating the swing bearing .....	5-45
Cautions on maintenance .....	5-2	Every 500 hours .....	5-46
Service data .....	5-4	Replacing the pilot line filter.....	5-46
Fuel and lubricant table.....	5-4	Replacing the engine oil and the oil filter ..	5-46
Handling of DEF/AdBlue® .....	5-7	Replacing the fuel filter.....	5-48
List of consumables.....	5-8	Replacing the water separator filter....	5-49
List of tools (If equipped).....	5-9	Inspecting the slew pinion gear.....	5-49
List of tightening torques .....	5-10	Replacing the air cleaner element .....	5-50
Safety-critical parts.....	5-12	Every 1000 hours .....	5-51
Maintenance list.....	5-14	Replacing the hydraulic oil return filter..	5-51
Walk-around inspection .....	5-16	Replacing the travel motor gear oil.....	5-51
Inspecting by opening the engine hood and covers.....	5-16	Replacing the hydraulic oil and cleaning the suction strainer .....	5-52
Inspecting by walking around the machine.....	5-17	Inspecting and adjusting the engine valve clearance.....	5-54
Inspecting while sitting in the operator's seat .....	5-17	Inspecting the radiator cap .....	5-54
Daily inspection (every 10 hours).....	5-18	Every 1500 hours .....	5-55
Inspecting and replenishing the coolant ..	5-18		
Inspecting and replenishing the engine oil..	5-19		
Inspecting the water separator .....	5-20		
Inspecting the fuel level.....	5-20		
Inspecting the hydraulic oil tank level and replenishing .....	5-21		

Inspecting the crankcase breather system .....	5-55
Every 2000 hours .....	5-56
Cleaning the engine cooling system... ..	5-56
Every 3000 hours .....	5-58
Inspecting the ECU and related sensors and actuators .....	5-58
Inspecting the turbocharger (blow wash as necessary) .....	5-58
Inspecting the DPF and DOC.....	5-58
Inspecting the operation of the air intake throttle valve.....	5-58
Inspecting the SCR catalyst and related sensors and actuators.....	5-58
Inspecting and replacing the supply module main filter .....	5-58
Inspecting and cleaning the fuel injector..	5-58
When required.....	5-59
Inspecting and replenishing the windshield washer fluid .....	5-59
Lubricating the levers.....	5-59
Draining the water from the water separator .....	5-60
Inspecting and cleaning the DPF soot filter .....	5-60
Inspecting the rubber tracks .....	5-61
Replacing the rubber tracks .....	5-62
Every 2 years .....	5-64
Replacing the receiver dryer.....	5-64
Maintenance during extended storage period.....	5-65

## **Troubleshooting .....6-1**

Symptoms that are not malfunctions .....	6-2
If the engine overheats.....	6-3
If the battery goes dead.....	6-4
If a fuse blows .....	6-6
Inspecting and replacing the fuse.....	6-6
Restarting after adding fuel .....	6-10
Bleeding air from the fuel system .....	6-10
Restarting when the DEF/AdBlue® level is low or the tank is empty .....	6-11
If a warning lamp flashes .....	6-12
Vehicle error code list.....	6-14
Engine error code list.....	6-16
Other symptoms.....	6-28
Towing.....	6-31
Lowering the dump body.....	6-32
If the cab is damaged .....	6-33
Exhaust gas control system error.....	6-34

Error code list .....	6-34
NOx control diagnostic system (NCD)..	6-35
Particulate control diagnostic system (PCD) .....	6-35
Limiting the engine output.....	6-36
Output limitation performed by inducement due to an abnormality detected in the SCR system .....	6-39
Output limitation performed by inducement due to decreased DEF/AdBlue® tank level .....	6-42

## **Specifications .....7-1**

Basic Specifications.....	7-2
Machine dimensions.....	7-4
Operating ranges.....	7-6

## **Options .....8-1**

General precautions .....	8-2
Safety precautions .....	8-2
Cautions when installing attachments ..	8-2
Precautions when operating attachments..	8-3
Optional equipment mass .....	8-4
Takeuchi Security System .....	8-5
Ignition key .....	8-5
Starting the engine.....	8-5
Registering and deleting the ignition key..	8-6
If the master key is lost .....	8-12
Countries where the system can be used ..	8-12
Takeuchi Fleet Management .....	8-13







## GENERAL PRECAUTIONS

**It is your responsibility to observe all pertinent laws and regulations and to follow the manufacturer's instructions on machine operation, inspection and maintenance.**

Virtually all accidents occur as the result of a failure to observe basic safety rules and precautions.

Most accidents can be prevented by identifying the potentially hazardous situations beforehand.

Read and understand all safety messages which describe how to prevent accidents.

Do not operate the machine until you are sure that you have gained a proper understanding of its operation, inspection and maintenance.

### Observe all safety rules

- Operation, inspection and maintenance of this machine must be performed only by a trained and qualified person.
- All rules, regulations, precautions and safety procedures must be understood and followed when performing operation, inspection and maintenance of this machine.
- Do not perform any operation, inspection and maintenance of this machine when under the adverse influence of alcohol, drugs, medication, fatigue or insufficient sleep.

### When a problem is found on the machine

If any problem (noise, vibration, smell, disorder of instrument, smoke, oil leak or wrong indication of alarm and panel, etc.) is detected during the operation or inspection and maintenance of the machine, please inform the administrator and take proper actions. Do not operate the machine until the trouble is cleared.

### Operating temperature range

To maintain the performance of machine and to prevent it from early wear, observe the following operating conditions.


- Do not operate the machine if the ambient temperature is higher than +45°C (+113°F) or lower than -15°C (+5°F).
  - If operated at an ambient temperature of higher than +45°C (+113°F), the engine may overheat and cause the engine oil to degrade. Also, the hydraulic oil may become very hot, causing damage to the hydraulic equipment.
  - If operated at an ambient temperature of lower than -15°C (+5°F), the parts made of rubber such as gaskets may get hardened to cause an early wear or damage to the machine.
  - If the machine is to be used outside the ambient temperature range described above, consult your sales or a service dealer.






## SAFETY GENERAL PRECAUTIONS

### Wear appropriate clothing and protective equipment



- Do not wear loose clothing or any accessory that can catch on controls or in moving parts.
- Do not wear oily or fuel stained clothing that can easily catch fire.
- Wear a hard hat, safety shoes, safety glasses, filter mask, heavy gloves, ear protection and other protective equipment as required by job conditions. Wear required appropriate equipment such as safety glasses and filter mask when using grinders, hammers or compressed air, as metal fragments or other objects can fly and cause serious injury.
- Use hearing protection when operating the machine. Loud prolonged noise can cause hearing impairments, even the total loss of hearing.

### Install a fire extinguisher and first aid kit



#### Be prepared for fire and accidents

- Install an extinguisher and a first aid kit, and learn how to use them.
- Learn how to fight a fire and how to deal with accidents.
- Know how to contact emergency assistance and make a list of emergency contacts.

### Never remove safety equipment


- Make sure all protective guards, covers, cab and doors are in place and secured. Repair or replace damaged parts before operating the machine.



- Know how to use the safety lock lever, seat belt, dump body prop and other safety equipment and use them properly.
- Never remove any safety equipment except for servicing. Keep all safety equipment in good operating condition.




### Use a signal person and a flag person



Learn how to use the hand signals required for particular jobs and make sure who has the responsibility for signaling.

- All personnel must fully understand all the signals.
- The operator must respond to signals only from the appointed signal person, but must obey a stop signal at any time from anyone.
- The signal person must stand in a clearly visible location when giving signals.

### Cautions when standing up from or leaving the operator's seat



- Before standing up from the operator's seat to open/close the window, remove/install the lower window or adjust the operator's seat, lower the dump body all the way, raise the safety lock lever to engage the lock and stop the engine. If any control is accidentally touched when the safety lock lever is lowered (unlocked), the machine will suddenly move and cause serious injury or death. If it is absolutely necessary to leave the raised dump body unattended, be sure to engage the dump body prop to prevent the dump body from dropping.
- Be careful not to touch the operating levers when raising or lowering the safety lock lever.
- Before leaving the operator's seat, fully lower the dump body, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take the key with you and store it in a specified place.

**Avoid fire and explosion hazards**

Keep flames away from fuel, oil, grease and antifreeze. Fuel is particularly flammable and dangerous.

- When handling these combustible materials, keep lit cigarettes, matches, lighters and other flames or sources of flames away.
- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Do not leave the location while refilling with fuel or oil.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Also, do not spill the fuel on the hot surface of the machine or the component of the electric system.
- Clean up spilled fuel or oil immediately.
- Check for fuel, oil leak. Stop all leaks and clean the machine before operating.
- When operating with grinder or welding, move inflammables to a safe place.
- Do not cut or weld on pipes or tubes that contain flammable fluids. Clean thoroughly with nonflammable solvent before cutting or welding.
- Remove all trash or debris from the machine. Make sure that oily rags or other flammable material are not stored on the machine.
- Handle all solvents and dry chemicals (foam type fire extinguisher) according to procedures identified on manufacturer's containers. Work in a well-ventilated area.
- Never use fuel for cleaning purposes. Always use a nonflammable solvent.
- When handling the fuel, washing oil or paint, open the door and windows to ventilate thoroughly.
- Store all flammable fluids and materials in a safe and well-ventilated place.
- The short circuit of the electric system may cause the fire. Check for any loosened connections or damage to the wires every day. Retighten the loosened connector and wire clamp. Fix or change the damaged wire.
- Fire from the pipes:  
Make sure that the clamps, guards and cushions of the hoses and tubes are securely fixed. If not, hoses or tubes may be damaged due to vibration or contact with other parts during operation. This can cause the high-pressure oil to spurt out, resulting in the fire or injury.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.  
DPF: Diesel Particulate Filter



## Fire prevention



When working in a certain environment, it is impossible to prevent combustible debris from collecting in the machine. This debris, in itself, may cause a fire; however, when mixed with fuel, oil or grease in a hot or confined place, the danger of fire is greatly increased. The following fire prevention guidelines should be used to supplement the operator's fire prevention efforts. In no case should the guidelines be used, or assumed, as replacements for diligent operator efforts at preventing fires (that include regular schedule of cleaning and inspecting the machine as conditions require).

The following guidelines will help to keep your equipment up and running efficiently and keep the risk of fire to a minimum.

1. Maintain a CHARGED fire extinguisher on or near the machine at all times and KNOW HOW TO USE IT.
2. Remove debris and blow out dust regularly from side air intake areas, engine radiator, hydraulic oil cooler, air conditioning condenser core to prevent overheating of the engine and hydraulics and to maintain efficient operation of the machine.
3. Blow off all accumulated debris near hot engine exhaust components (turbocharger and exhaust manifold as well as exhaust pipes and muffler) at the completion of each work shift or more frequently when working in severe conditions where large amounts of combustible debris are present. Engine exhaust systems provide numerous small pockets where flammable debris can gather. Even small accumulations close to hot exhaust components can ignite and smolder.
4. Clean out all accumulated debris (twigs, pine needles, branches, bark, leaves, saw dust, small wood chips) and any other combustible materials from the under covers inside the machine or the lower machine structure, as well as from areas in proximity to the engine, fuel and hydraulic oil systems, after the completion of each work shift or more frequently.
5. Inspect the machine regularly for any signs of diesel fuel or hydraulic system leakage. Check for worn or damaged fuel or hydraulic lines before starting up any equipment.
6. Clean up any grease, diesel fuel, hydraulic and lubricating oil accumulation and spillage immediately.
7. Steam clean the areas of engine and the under covers at least once a month or more frequently when working in severe conditions where large amounts of combustible debris are present.
8. Use only nonflammable solutions for cleaning the machine and components.
9. Inspect the exhaust system daily for any signs of leakage. Check for worn, cracked, broken or damaged pipes or muffler. Also check for missing or damaged bolts or clamps. Should any exhaust leaks or defective parts be found, repairs must be made immediately. Engine exhaust leaks can cause fires. Do not operate the machine until the exhaust leak is repaired.



10. During daily operation of the machine, the occurrence of exhaust leaks are usually accompanied by a change or increase in engine exhaust noise levels. These audible warnings cannot be ignored. Should any exhaust leaks occur during operation, the machine must be shut down immediately and not put back to work until the necessary repairs have been completed.
11. Before starting repair work, such as welding, the surrounding area should be cleaned and a fire extinguisher should be close by.
12. Do not use the machine on top of or to push piles of burning timber. A machine fire will likely result.

What to do to prepare for a machine fire

- Prevent the fire from happening in the first place by ensuring that all machine systems are frequently inspected and always well maintained.
- Ensure that any hand held fire extinguishers are charged and in working order. Fire extinguishers require routine care. Follow the manufacturer's instructions for inspection and maintenance shown on the label of the fire extinguisher and in the extinguisher manufacturer's manual.
- Ensure that you follow all national, state / provincial and local regulations dealing with fire fighting in effect in your specific geographic region.
- Ensure that all information necessary for you to immediately contact all sources of help (local fire department, etc) in the event of a fire emergency is recorded and readily available at all times.

What to do if a machine fire occurs

If operating the machine when a fire occurs:

1. Fully lower the dump body.
2. Shut the engine off.
3. Exit the machine. Call for help. Be certain to report a fire immediately.
4. At all times ensure your own personal safety and the safety of anyone that may be in the area. Approach any fire with extreme caution. All fires can be very dangerous and life threatening.

Before deciding to fight the fire, be certain that:

1. The fire is small and not rapidly spreading.
  2. There is always a clear, safe escape route.
  3. You have received training in the use of the available fire extinguishing devices and are confident that you can operate them effectively.
- Be aware that engine coolant, diesel fuel or hydraulic hoses could fail during a fire. If this happens, hot coolant, fuel or oil could possibly be ignited by the fire.
  - If in any doubt about whether or not to fight the fire ? DON'T. Instead stand well clear of the fire and wait for help to arrive.




- Use the **PASS** method. This is the most effective use of a fire extinguisher.
  - **P**ull the pin at the top of the extinguisher that keeps the handle from being pressed. Break the plastic seal as the pin is pulled.
  - **A**im the nozzle at the base of the fire. Do not aim the nozzle at the flames. In order to put out the fire, you must extinguish the fuel, not the flames. Hose nozzles are often clipped to the extinguisher body. Release the hose before taking aim.
  - **S**queeze the handle to release the pressurized extinguishing agent. The handle can be released at any time to stop the discharge.
  - **S**weep from side to side at the base of the fire until the fire is completely out or the fire extinguisher is empty
- Only if you can safely do so, open the access panels to the machine in the area of the fire.
- Failing all attempts to access the machine compartment, discharge the extinguisher through the mesh or any available openings on the machine.
- Ensure that the machine and all components have cooled down sufficiently after a fire so that re-ignition does not occur.
- Remain in the area until help arrives.

What to do after a machine fire has occurred

- Before returning the machine to work.
  1. Ensure that the cause of the fire is determined and all appropriate repairs are completed.
  2. Ensure that all extinguishers used in fighting the fire are replaced or recharged.
- Notify your equipment dealer and/or Takeuchi Manufacturing.



### Exhaust fumes from the engine are poisonous



- Do not operate the engine in an enclosed area without adequate ventilation.
- If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.
- Ammonia not held by the SCR catalyst could be discharged into the exhaust gas. Be careful of the potential ammonia odor when the system is excessively operated.

### Handling asbestos dust

Inhaling asbestos dust can cause lung cancer. When handling the materials which may contain asbestos, take the following precautions:

- Never use compressed air for cleaning.
- Avoid brushing or grinding parts containing asbestos.
- For clean up, use a vacuum equipped with a high efficiency particulate air filter (HEPA).
- Wear the stipulated respirator if there is no other way to control the dust. When working indoors, install a ventilation system with a macromolecular filter.
- Do not allow unauthorized personnel in the work area while working.
- Follow the rules and environmental standard applicable to the work area.

**Be careful not to get crushed or cut**

Never put your hands, feet or other parts of your body between the dump body and the machine body or between the cylinder and the dump body. The sizes of these gaps change when the dump body moves, and a person could suffer severe injury or death.

**Using optional products**

- Consult with Takeuchi before installing optional attachments. Depending on the type of attachments or the combination of them, the attachment may come into contact with the operator's compartment or the other parts of the machine. Make sure that the optional attachment installed is not contacted with other parts before use.
- Do not use attachments that have not been approved by Takeuchi. Doing so may compromise safety or adversely affect the machine's operation or service life.
- Takeuchi will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.

**Never modify the machine**

Unauthorized modifications to this machine can cause injury or death. Never make unauthorized modifications to any part of this machine.

If you modify or alter the configuration of the machine in a way which results in a restriction of the operator's field of vision, a new risk assessment will need to be performed. If this becomes necessary, contact your Takeuchi service or sales dealer.





## PRECAUTIONS WHEN PREPARING


### Know the work area

Before starting operation, know the working area condition to ensure safe operation.

- Inspect the topography and ground condition of the working area, or the structure of the building when working indoors, and take the safety precautions as necessary.




- Be sure to avoid all hazards and obstructions such as ditches, trees, cliffs, overhead electrical wires, or places where there is a danger of falling rocks or landslides.
- When working on roads, be sure to consider the safety of pedestrians and vehicles.
  - Use a flag person and/or a signal.
  - Fence off the working area and keep off unauthorized persons.
- When working in water or crossing shallow streams or creeks, check the depth of the water, the solidity of the ground and the water flow speed beforehand. Refer to “Cautions on operating” for further instructions.



- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF. DPF: Diesel Particulate Filter
- The DPF may automatically perform the regeneration while the engine is left running. Make sure that there are no flammable items around the DPF and the exhaust line, and also that the engine hood is closed to prevent fire. Be careful not to burn yourself on the high-temperature exhaust gas.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.

### Check the strength of the bridge

When traveling over a bridge or a structure, check the permissible load. If the strength is insufficient, reinforce the bridge or the structure.






**Always keep the machine clean**



- Clean windows, mirrors and lights to ensure good visibility.  
Adjust the mirror to the best position for the operator to see the rear view (blind spot) from the operator's seat.
- Wipe off any oil, grease, mud, snow or ice, to prevent accidents due to slipping.
- Remove all loose objects and unnecessary devices from the machine.
- Remove any dirt, oil or grease from the engine area to prevent fires.
- Clean around the operator's seat and remove any unnecessary object from the machine.

**Perform inspection and maintenance every day**



Failure to identify or repair the irregularities or damage on machine can lead to accidents.

- Before operating, perform the specified inspection and make prompt repairs where necessary.
- If a failure occurs and the operation becomes impossible or the engine fails, immediately stop the machine by following the shutdown procedure, and keep machine securely parked until the malfunction is corrected.




### Cautions in the operator's compartment

- Remove mud and grease from shoe soles before entering the operator's compartment. Pedaling the machine with the shoes with mud and grease will cause a slip accident.
- Do not leave the parts or tools around the operator's seat.
- Do not leave any plastic bottles in the operator's compartment or attach any suction cups on the window glass. The plastic bottle or suction cup act as a lens and can cause fire.
- Do not use the mobile phone during traveling or working.
- Do not bring combustibles or explosives into the operator's compartment.
- After smoking, be sure to tightly close the lid of the ashtray to put out the match or cigarette.
- Do not leave the cigarette lighter in the operator's compartment. When the room temperature rises, the lighter may explode.


### Emergency exit

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.

### Emergency hammer (optional)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the window pane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.



## PRECAUTIONS WHEN STARTING

Support your weight in a three point secure stance when getting on/off the machine

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move.



- Climb up/down the steps facing the machine and holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

### Before starting the machine, ask any unauthorized personnel to leave the area

Do not start the engine until you are sure it is safe to start the machine by checking the following items.

- Walk around the machine and warn the person who is servicing the machine or is walking near the machine. Do not start the machine until you are certain that no one is around the machine.



- Check if there is a “DO NOT OPERATE” alert sign or similar sign is on the cab door, controls or ignition switch. If there is one, do not start the engine or touch any levers.
- Sound the horn to warn people around the machine.

### Sit in the operator's seat and start the engine


- Adjust the seat to securely latch it.



- Fasten the seat belt.
- Check if the parking brake is on and the control levers are in the neutral position.
- Check if the safety lock lever is in the lock position.
- Make sure that no one is near the machine.
- Start and operate the machine only from the operator's seat.
- Never attempt to start the engine by shorting across the starter terminals.



### Starting with jumper cables



Use jumper cables only in the recommended manner. Improper use of jumper cables can result in battery explosion or unexpected machine motion.

Refer to “If the battery goes dead” for further instructions.

### After starting the engine

After starting the engine, perform the operations and checks described below in a safe place with no persons or obstacles in the area. If any malfunction is found, follow the shutdown procedure and report the malfunction.

- Warm up the engine and hydraulic oil.
- Check if all gauges and warning devices are properly working.
- Check for any noises.
- Test the engine speed control.
- Operate each control to ensure they are properly working.

### In cold climates



- Be careful of slippery conditions on freezing ground, steps and hand holds.
- In severe cold climates, do not touch any metal parts of the machine with bare hands. The skin will freeze to the metal, resulting in severe injury.
- Do not use ether or starting fluid on this engine. The starting fluids can cause explosion and serious injury or death.
- Warm up the engine and hydraulic oil. If the levers are operated without warming, the machine will not react or move promptly or properly, resulting in accident.



## PRECAUTIONS WHEN OPERATING

### Ensure good visibility

Check the field of view before operating the machine.

- When working in dark places, turn on the machine's working lights and headlights and additional lighting equipment installed, as necessary.
- When visibility is poor due to bad weather (fog, snow, rain or a cloud of dust), stop operating the machine and wait until visibility improves.
- Clean the windows, mirrors, lights and camera to ensure good visibility. Adjust the mirror and camera to the best positions so that the operator can see the rear view (blind spots) from the operator's seat.
- Unauthorized machine modifications or installation of unapproved attachments could impair the visibility. The operator's field of view must conform to ISO 5006.

### Do not permit riders on the machine




Do not allow anyone to ride on any part of the machine at any time while traveling or operating.


### Operate the machine only from the operator's seat

When operating any lever or switch, always do it while sitting in the operator's seat. Failure to do so may be very dangerous.


### Check if the work area is safe and secure before operation



- Confirm the performance limits of the machine.
- Use a signal person at road shoulders, narrow places or where your vision is obstructed.
- Never allow anyone to enter the machine's swing radius and path.
- Signal your intention to move by sounding the horn.
- There is a blind spot in the rear of the machine. Before traveling in reverse, check that the area is safe and clear.

**Precautions on traveling and turning**

- Do not travel while the dump body is being swung or raised. Doing so is dangerous because it causes the machine to become unstable. Fully lower the dump body and make it parallel to the main frame.
- Avoid sudden starting, stopping and turning. Otherwise, the loaded material could be shifted to cause the machine to lose its balance, or the structures in the surrounding area could be damaged by the material fallen from the dump body.
- Do not raise the safety lock lever while traveling. Doing so is dangerous; the parking brake will be activated and the machine will stop abruptly.
- Do not switch off the ignition switch while traveling. Doing so is dangerous; the machine will stop abruptly.
- Before traveling in reverse, visually check if the rear view is clear. Failure to do so could result in contact with a worker or obstacle.
- When hauling materials or when traveling over rough terrain or slippery road surface, slow down the travel speed and drive carefully.





- Avoid crossing over obstacles whenever possible. If you must do so, try to go over the obstacle at a right angle to it at a low speed. Never cross obstacles which will tilt the machine to an angle of 10° or greater.




### Precautions when traveling on slopes

When traveling on slopes, do it carefully so that the machine does not tip (roll) over or slide.



When traveling on slopes of 15 degrees or more, position the heavier end of the machine (front or back, whichever is heavier) pointing up the slope.

- Never travel on slopes that are too steep for the machine to maintain its stability. Note that in reality, the machine's performance decreases on slopes due to its poor working condition.
- When traveling on slopes or grades, drive slowly in 1st (low) speed. Especially on down slopes, slow down the engine speed and limit the stroke length of the left control lever to less than half. Going down a slope at high speed may lead to loss of control.
- Braking abruptly on slopes could result in the machine losing its balance and tipping over.




- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.
- The machine may slip sideways even on a slight slope if the ground is covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Make sure the machine is never positioned sideways on slopes.
- If the machine is stalled on the slope, return each control lever to the neutral position before restarting the engine.




**Operate the machine on snow or ice with extra care**

- When traveling on snow or on frozen surfaces, drive at a low speed and avoid starting, stopping or changing directions abruptly.
- In the snowy area, the road shoulder and objects placed beside the road are buried in the snow and cannot be seen. There is a hazard of the machine tipping over or hitting covered objects, so always carry out operations carefully.
- If the machine enters deep snow, there is a hazard that it may tip over or become buried in the snow.  
Be careful not to drive beyond the road shoulder or to get trapped in a snow drift.
- With frozen ground surfaces, the ground becomes soft when the temperature rises, and this may cause the machine to tip over, resulting in an operator trapped inside the machine.

**Take care when handling unstable loads**

ASSA010


Unstable load such as round items, cylindrical items and stacked plates may fall from the dump body. When handling unstable load, be sure to secure it for hauling.

**Precautions when dumping**

ASSA012

Do not perform the following dumping operations. The machine may tip over due to the shift of the center of gravity.

- Dumping on slopes or bumpy terrain
- Dumping while swinging the dump body
- Dumping while traveling


**Precautions when loading material**

ASSA011

When loading earth or sand, make sure that the machine operator is safe. Do not load material on slopes. Do it only on a firm ground.


Improper loading is dangerous, as it could cause the machine to tip over or result in the load shifting.

- Do not exceed the maximum loading capacity (3700 kg, 8155 lb).
- Load the material so that it is evenly distributed in the dump body.
- Be sure to properly secure the unstable load onto the dump body.


**Keep a safe distance from the overhead high-voltage cables**

Never bring any part of the machine or loaded material to near to the high voltage cables unless all safety precautions required by the local and national authorities have been installed. If a person comes near to the machine that is discharging sparks or located near to or in contact with the power source, there is a hazard of electric shock and death.


- Always maintain a safe distance between the machine and the high-voltage electric cable.
- Check with the local power company about safe operating procedure before starting operations.
- Consider all cables to be high-voltage cables and treat all cables as energized even though it is known or believed that the power is shut off and the cables are visibly grounded.
- Use a signal person to give warning if the machine approaches too close to the high-voltage electric cables.
- Caution all personnel in the work area not to come close to the machine or the loaded material.

**Watch out for hazardous working conditions**


- Never operate the machine under the cliff. Doing so is dangerous as it could cause landslides.
- Do not operate in places where there is a danger of falling rocks.
- Do not come close to unstable grounds (cliffs, road shoulders, deep ditches). If the ground should collapse under the weight or vibration of the machine, there is a hazard that the machine may fall or tip over.
  - Remember that the soil after heavy rain or blasting is weak.
  - The ground of top of the embankment and of the circumferences of the excavated ditches are also weak.

**Travel in narrow or crowded places**

When traveling in narrow sites, crowded places or indoors, operate the machine while carefully looking around the area and maintaining the safe speed to avoid contact accidents.


**Precautions when passing through tunnels or going under bridges**

Check the height limit and width limit of tunnels and bridges beforehand to avoid the machine from contact with the ceiling or walls. If contacted, it could result in a serious accident.

**Do not enter areas where there is soft ground.**

Driving on the soft ground could cause the machine to tilt under its own weight, resulting in a machine tipping over or sinking into the ground.

Do not drive on soft surface such as a back-filled ground.

**Do not come close to unstable grounds**

Working on unstable grounds is dangerous because the machine is likely to tip over.


- Avoid coming close to cliffs, road shoulders and ditches because they are surrounded by soft ground.
- Take care when working over the embankment/mound; the weight or the vibration of the machine could cause the embankment/mound to collapse or the machine to suddenly tilt over.
- Remember that the soil after heavy rain or blasting is weak.



### Be careful with flying objects

This machine is not equipped with protective equipment to protect the operator from flying objects. Do not use this machine in places where there are risks of the operator being hit by flying objects.

### Cautions when towing



When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.


- Do not tow using only a towing hook or hole on one side.
- It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
- Do not use a wire rope that is kinked, twisted or otherwise damaged.
- Do not apply heavy loads abruptly to the wire rope.
- Wear safety gloves when handling the wire rope.
- Make sure there is an operator on the machine being towed as well as on the machine that is towing.
- Never tow on slopes.
- Do not let anyone come near to the wire rope while towing.

Refer to "Towing" for further instructions.




## PRECAUTIONS WHEN STOPPING

### Park safely




- Park the machine on a flat, rigid and safe ground. Set the parking brake.




If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.
- Before leaving the operator's seat, raise the safety lock lever to engage the lock and stop the engine.



- Do not leave the machine while the dump body is being raised. If it is absolutely necessary to leave the raised dump body unattended, be sure to engage the dump body prop to prevent the dump body from dropping.




- Before leaving the machine, do the followings:
  1. Fully lower the dump body and make it parallel to the main frame.
  2. Raise the safety lock lever to the lock position.
  3. Stop the engine and remove the ignition key.
  4. Lock the cab and covers and take the key with you.



## PRECAUTIONS WHEN TRANSPORTING

### Load/unload the machine safely



The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the tracks.
- Chock the transporter wheels to prevent movement.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramp. If it is necessary, move down from the ramps, change the course and then get on the ramps again.
- Do not swing or raise the dump body on the ramps. The machine may tip over.
- When raising the dump body on the truck bed, do it slowly as the footing should be unstable.
- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.

### Hoist the machine safely

- Know and use correct crane signals.
- Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
- When hoisting, use a wire rope capable of lifting the machine mass.
- Hoist the machine in such a manner described in the procedure below. Do not do it in any other manner, as it may result in the machine losing its balance. Refer to “Hoisting the machine” for further instructions.
- Do not hoist the machine with an operator on it.
- When hoisting, hoist slowly so that the machine does not tip.
- Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.

### Transport the machine safely

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.



## PRECAUTIONS ON MAINTENANCE

### Display a “DO NOT OPERATE” alert sign


Severe injury could result if an unauthorized person should start the engine or touch controls during inspection or maintenance.

- Before performing maintenance, stop the engine and remove the ignition key which will be kept by the maintenance personnel.



- Display a “DO NOT OPERATE” alert sign on easy-to-see locations such as the ignition switch or control levers.

### Use the correct tools



Do not use damaged or weakened tools or tools designed for other purposes. Use tools appropriate for the work involved.

### Replace safety-critical parts periodically


- Replace fuel hoses periodically. Fuel hoses wear out over time, even if they do not show any symptom of wear.
- Regardless of the replacement schedule, replace immediately if a symptom of wear is found. Refer to “List of safety-critical parts” for further details.

### Explosionproof lighting



To prevent an ignition or explosion, use explosion-proof lights when inspecting fuel, oil, coolant or battery fluid. Otherwise, explosion could result causing serious injury or death.



**Prohibit access by unauthorized persons**

Do not allow unauthorized personnel in the work area while working. Be careful when grinding, welding or using a hammer. You could be injured by flying debris from the machine.


**Prepare work area**

- Select a firm, level work area. Make sure there is adequate light and, if indoors, ventilation.
- Clear obstacles and dangerous objects. Eliminate slippery areas.

**Cautions on working on top of the machine**

- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.

- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.
- Do not stand on the track and perform maintenance work. Doing so is dangerous because of the unsteady foothold. Use the work bench.

**Always keep the machine clean**


- Clean the machine before performing maintenance.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.



### Stop the engine before performing maintenance

- Avoid lubrication or mechanical adjustments while the machine is moving or while the engine is running when the machine is not moving.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
  - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
  - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.

### Stay clear of the moving parts




- Stay clear of all rotating and moving parts. If a hand or tool becomes trapped in the rotating or moving part, serious injury or death could result.
- If a tool or other objects is dropped or inserted in the fan or fan belt, it will be flown or cut in pieces. Do not drop or insert anything in the fan or fan belt.

### Firmly secure the machine or any component that may fall



- Before performing maintenance or repairs under the machine, lower the dump body completely.
- Chock the tracks.
- If you must work under the raised machine or its components, always use the dump body prop, wood blocks, jack-stands or other rigid and stable supports to keep the machine or its components raised. Never get under the machine or its components if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.
- The support device provided on the machine is designed assuming that there is no load. Remove the load before using the support device.

**Precautions when raising the dump body**

AS5A022

- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.
- Disconnecting or loosening any faulty hydraulic line, hose, fitting or component could cause the dump body to fall.
- Repair or replace the dump body prop if it is damaged or any part is missing. Failure to do so may cause the dump body to fall, resulting in a serious injury or death.

**Secure the engine hood or covers when opened.**

Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or cover open on a windy day or if the machine is parked on a slope.

**Place heavy objects in a stable position**

AG7A078

When it is necessary to temporarily place a heavy machine part or an attachment on the ground during removal or installation, be sure to place it in a stable position. Keep unauthorized persons from the storage place for such object.



### Cautions when refueling



- Do not smoke or permit open flames while fueling or near fueling operations.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap. If the fuel cap is lost, replace it only with the genuine cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning.
- Use the correct grade of fuel for the operating season.

### Handling of hoses

Oil leak or fuel leak can cause a fire.

- Do not twist, bend or hit the hoses.
- Never use twisted, bent or cracked pipes, tubes or hoses; otherwise, they may burst.
- Retighten loose connection.

### Be careful with hot and pressurized components



Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The engine coolant, hydraulic oil and other oils are also hot and under high pressure. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.


**Be careful with hot cooling systems**

Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap to release the internal pressure and remove it.

**Be careful with oil internal pressure**

Pressure is maintained in the hydraulic circuit long after the engine has been shut down.

- Completely relieve the internal pressure before performing maintenance work.



- The hydraulic oil is high enough pressure to penetrate the skin or eyes and cause serious injury, blindness or death.

Remember that the hydraulic oil escaping from a small hole is almost invisible. When checking for leaks, wear protective goggles and thick gloves, and use a paperboard or plywood to keep your skin from oil spurting.

If oil penetrates the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

**Release pressure before working on the hydraulic system**

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- Oil or plug may spurt out according to the pressure in the travel motor case. Loosen the plug slowly and release the internal pressure.

**Be careful with debris when the hammer is being used**

When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.

- If hard metal parts such as pins and bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
- When hitting pins, always check that there is no one in the surrounding area.

**Cautions when servicing the air conditioner**

If the refrigerant comes in contact with eyes, it damages your eyesight. If the refrigerant comes in contact with skin, it may cause frostbite. Never touch the refrigerant.

**Disconnect the battery wiring**

- Disconnect the battery wiring before working on the electrical system or doing electric welding. Disconnect the negative (-) battery cable first. When reconnecting, connect the negative (-) battery cable last.
- The SCR system operates for up to 10 minutes after the ignition switch is turned to the OFF position.  
When removing the batteries or electrical connectors for inspection or maintenance, wait for at least 10 minutes after the ignition switch is turned to the OFF position. Otherwise, the system could fail.

**Use caution when handling batteries**

- Batteries contain sulfuric acid which will damage the eyes or skin in case of contact.
  - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
  - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
  - If acid contacts skin or clothing, wash off immediately with a lot of water.
- Wear protective goggles and gloves when working with batteries.
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- When checking the level of the battery fluid, use a flashlight.
- Be sure to stop the engine by turning off the ignition switch before inspecting or handling the battery.
- Be careful not to let metal tools or any metal objects come into contact with the battery terminals and cause a short circuit.
- Loose battery terminals may result in sparks. Be sure to fasten terminals tightly.
- Make sure the battery caps are tightened securely.
- Do not charge a battery or jump-start the engine if the battery is frozen; otherwise it may explode. Warm the frozen battery to 15°C (60°F) before use.
- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Use a dampened cloth to clean around the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it could cause static electricity to build up, resulting in ignition or explosion.

**Precautions for handling DEF/AdBlue®**

DEF/AdBlue® is a colorless, transparent, odorless and non-hazardous aqueous solution (32.5% urea, 67.5% water, freezes at  $-11^{\circ}\text{C}$ ), and is harmless to the human body. In very rare cases, however, inflammation could occur in some people, and proper actions should be taken as follows.

- If skin contact occurs, flush with water. If there are changes in the skin condition or if there is pain, immediately seek medical attention.
- If accidentally swallowed, drink one or two glasses of water or milk and immediately seek medical attention.
- If eye contact occurs, immediately flush with a large amount of clean water and seek medical attention.
- Although DEF/AdBlue® itself is a nonflammable liquid, a pungent odor may be produced if heated in a fire. In case of fire, immediately evacuate the area and go to a safe place.
- Do not use expired DEF/AdBlue® solution (including solution left in the tank) stored for a long period. Doing so could cause ammonia slip, degraded NOx conversion efficiency or device damage.
- When handling DEF/AdBlue®, do not use anything such as cotton work gloves whose fibers could get into the solution. Doing so could cause clogging of the DEF/AdBlue® filter or urea deposit at the DM injection port.

**Periodically replace the safety-critical parts**

- To use the machine safely for a longer period, periodically add oil and perform inspection and maintenance. To improve the safety, replace the safety-critical parts like hoses and seat belts periodically. Refer to “Safety-critical parts to be replaced periodically” for further details.
- The “Safety-critical parts to be replaced periodically” are the parts which deteriorate, wear and fatigue after repeated use and whose properties change over time. While these characters of these parts could cause serious physical or personal damage, judging the remaining life of these part are difficult from external inspection or the feeling when operating.
- Replace the “Safety-critical parts to be replaced periodically” if any defect is found from external inspection, even when they have not reached the time specified interval.





### **Jump starting with booster cables**

- When starting the engine using the booster cables, be sure to connect the cables in the proper order described below. Wrongly connected cables can result in sparking and battery explosion.
  - Do not allow the “machine in trouble” and “rescue machine” to touch each other.
  - Do not allow the positive (+) and negative (-) clips of the booster cables to touch each other or to come in contact with the machine.
  - When connecting, attach the positive booster cable to the positive (+) terminals first. When disconnecting, remove the negative cable from the negative (-) terminal (ground) first.
  - Be sure to connect the clips securely.
  - Connect the last clip of the booster cable to a point as far away from the battery as possible.
- Always wear the protective goggle and gloves when starting the engine by using the booster cables.
- Use the booster cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded booster cables and clips.
- Be sure that the battery of the “rescue machine” has the same capacity as the battery of the “machine in trouble”.



### Have a Takeuchi service agent repair welding

If welding must be performed, make sure that it is done by a qualified person in a properly equipped workplace. To prevent any part from breaking down or being damaged due to overcurrent or sparks, observe the following.

- Disconnect the wiring from the battery before doing electric welding.
- Do not continuously apply 200 V or more.
- The earth ground must be connected within one meter from the welding section. Do not connect the earth ground near to an electronically controlled device/instrument or connectors.
- Make sure that there are no seals or bearings between the welding section and the earth ground.
- Do not connect the earth ground around the pins in the dump body or hydraulic cylinders.
- When welding is to be done on the machine body, disconnect the connectors for the electronically controlled devices before working.

### Vibrations operators are subject to

According to the results of the tests conducted to determine the vibrations transmitted to the operator by the machine, the upper limbs are subjected to vibrations lower than  $2.5 \text{ m/s}^2$  ( $8.2 \text{ ft/s}^2$ ) while the seated part of the body is subjected to vibrations lower than  $0.5 \text{ m/s}^2$  ( $1.64 \text{ ft/s}^2$ ).

### Checks after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from the serviced parts.
- Operate each control lever and check that the machine is operating properly.

### Disposing of wastes



- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, coolant, solvent, DEF/AdBlue®, filters and batteries.

### Handling of poisonous chemicals

Poisonous chemicals will cause serious injury if directly contacted.

Poisonous chemistry used in this machine includes grease, battery solution, coolant, DEF/AdBlue®, paint and adhesive agent. Handle the poisonous chemicals properly with care.




## **SAFETY SIGNS (DECALS)**

For the safety of the operator and the personnel working around the site, safety signs (decals) are placed at certain locations on the machine as shown below. Walk around the machine with this manual, and check the content and location of these safety signs. Review these signs and the operating instructions in this manual with your machine operators.

- Keep the signs clean and legible. If any of the safety labels is peeling or damaged and becomes difficult to read, replace it with a new one. Please include your product serial number when ordering a new sign from the Takeuchi service agent.
- When a part/unit to which a safety sign is attached is replenished, a new sign must be attached to the new part/unit.



**SAFETY**  
**SAFETY SIGNS (DECALS)**




AAA0A002



1. No.05793-00011

Safety Distance

Do not get near or stand within the machine working area.



2. No.03793-66006

Hazard of rotating parts.

Turn off before inspection and maintenance.




4. No.08710-80515




5. No.08710-83006




7. No.08740-30104



3. No.08740-30107



6. No.08740-30101



8. No.03993-00400

Position of Fire extinguisher





**SAFETY**  
**SAFETY SIGNS (DECALS)**

9. No.03593-06600

Diesel Fuel



10. No.03593-06700

Hydraulic oil



11. No.03993-00500

Position of Hoisting



12. No.08810-31549

Tie down point



13. No.05793-00035


Noise Outside the Cab (If equipped)

This value indicates the noise level outside the machine and refers to the noise perceived by the persons who are in the vicinity of the work area.



14. No.08710-86051

Position of Emergency Exit




15. No.08820-31135



Sign indicates a burn hazard from spurting hot water or oil if radiator or hydraulic tank is uncapped while hot. Allow radiator or hydraulic tank to cool before removing cap.

16. No.05693-00090



17. No.07193-00023



Sign indicates a burn hazard from touching heated parts, such as engine, pump, or muffler during or right after operation. Never touch when hot.


AAA0A004E

# CONTROLS





## NAMES OF COMPONENTS




- |                        |                    |
|------------------------|--------------------|
| 1. Cab                 | 11. Dump body      |
| 2. Seat                | 12. Dump cylinder  |
| 3. Engine hood         | 13. Swing motor    |
| 4. Bumper              | 14. Rubber track   |
| 5. Front light         | 15. Idler          |
| 6. Turn signal light   | 16. Track roller   |
| 7. Rear light*         | 17. Carrier roller |
| 8. Rear view mirror    | 18. Travel motor   |
| 9. Fuel tank           |                    |
| 10. Hydraulic oil tank |                    |

\*: Subject to the specifications or optional products selected





## CONTROLS NAMES OF COMPONENTS



AAA0B002


- |                              |  |
|------------------------------|--|
| 1. Multi-information display | 12. Air conditioner control panel*/Heater control panel* |
| 2. Ignition switch           | 13. DPF manual regeneration/inhibit select switch        |
| 3. Horn button               | 14. Parking brake switch                                 |
| 4. Travel speed button       | 15. Working light switch                                 |
| 5. Safety lock lever         | 16. Front wiper switch                                   |
| 6. Turn signal buttons       | 17. Washer switch  |
| 7. Throttle controller       | 18. Beacon lamp switch*                                  |
| 8. Left control lever        | 19. Rear wiper/Washer switch                             |
| 9. Right control lever       | 20. Throttle pedal                                       |
| 10. Deceleration button      |  |
| 11. Engine shutdown switch   |  |

\*: Subject to the specifications or optional products selected



## COVERS

### IGNITION KEY



The ignition key is used to start and stop the engine, as well as to lock and unlock the following components:

- Fuel filler cap
- Cab door
- Engine hood
- Covers


### FUEL FILLER PORT



#### WARNING

- Do not smoke and keep away from heat or flame while filling the fuel tank.
- Fill the fuel tank in a well ventilated place, with the engine turned off.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.

#### Opening



1. Open the cover, insert the key and turn it counterclockwise to unlock the cap.
2. Turn the fuel filler cap counterclockwise and remove it.

#### Closing

1. Install the fuel filler cap to the fuel filler port, and then turn the cap clockwise to close it.
2. Lock the fuel filler cap.



## DEF/ADBLUE® REFILL PORT

### WARNING

- When removing the cap from the DEF/ AdBlue® tank, take care not to inhale steam.
- Do not put anything else other than DEF/AdBlue® solution in the DEF/ AdBlue® tank. Putting liquids, particularly light oil or gasoline, in the tank could cause a fire or damage the SCR system. If this is accidentally done, contact a Takeuchi service dealer.


### CAUTION

- DEF/AdBlue® is a colorless, transparent, odorless and non-hazardous aqueous solution (32.5% urea, 67.5% water, freezes at  $-11^{\circ}\text{C}$ ), and is harmless to the human body. In very rare cases, however, inflammation could occur in some people, and thus proper actions should be taken as follows.
- If skin contact occurs, flush with water. If there are changes in the skin condition or if there is pain, immediately seek medical attention.
- If accidentally swallowed, drink one or two glasses of water or milk and immediately seek medical attention.
- If eye contact occurs, immediately flush with a large amount of clean water and seek medical attention.

### IMPORTANT

- Do not use expired DEF/AdBlue® solution (including solution left in the tank) stored for a long period. Doing so could cause ammonia slip, degraded NOx conversion efficiency or device damage.
- When handling DEF/AdBlue®, do not use anything such as cotton work gloves whose fibers could get into the solution. Doing so could cause clogging of the DEF/AdBlue® filter or urea deposit at the DM injection port.

## Opening



1. Insert the ignition key and turn it counterclockwise to unlock the DEF/ AdBlue® tank cover (1).
2. Open the DEF/AdBlue® tank cover (1) until it stops.
3. Lower the stay (3) while supporting the DEF/AdBlue® tank cover, and then insert the stay (3) into the stay holder to secure the DEF/AdBlue® tank cover.
4. Turn the DEF/AdBlue® tank cap (2) counterclockwise and remove it.

## Closing

1. Install the DEF/AdBlue® tank cap (2) on the refill port, and then turn the cap clockwise to close.
2. Support the DEF/AdBlue® tank cover (1) by hand, and then release the stay (3) to return it to the original position.
3. Close the DEF/AdBlue® tank cover (1) and press it down until a click is heard.
4. Insert the ignition key and turn it clockwise to lock the DEF/AdBlue® tank cover (1).




## ENGINE HOOD


### WARNING

- Before opening the engine hood, be sure to stop the engine. If a hand or tool becomes trapped in the rotating or moving part, serious injury could result.
- Be sure to secure the engine hood before working under the engine hood. Do not leave the engine hood or cover open on a windy day or if the machine is parked on a slope.
- When opening or closing the engine hood, be careful not to get your hands or other parts of your body caught by it.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.

## Opening



1. Insert the ignition key and turn it counterclockwise to unlock the engine hood (1).
2. Open the engine hood (1) until it stops.



3. Raise the stay (2) and insert it into the stay holder to support the engine hood (1).

## Closing

1. Support the engine hood (1) by hand, and then release the stay (2) to return it to the original position.
2. Close the engine hood (1) and press down the edge of it until a click is heard.
3. Insert the ignition key and turn it clockwise to lock the engine hood (1).




## SIDE COVER (TOOL BOX)

### CAUTION

- When opening the side cover, open it all the way to the position where it is securely stopped.
- When opening or closing the side cover, be careful not to get your hands or other parts of your body caught by the cover.

The grease gun and the tools are stored under the cover.

### Opening



1. Insert the ignition key and turn it counterclockwise to unlock the side cover (1).
2. Open the side cover (1) until it stops.
3. Lower the stay (2) and insert it into the stay holder to support the side cover.

### Closing

1. Support the side cover (1) by hand, and then release the stay (2) to return it to the original position.
2. Close the side cover (1).
3. Insert the ignition key and turn it clockwise to lock the side cover (1).


## BATTERY COVER

### CAUTION

- When opening the battery cover, open it all the way to the position where it is securely stopped.
- When opening or closing the battery cover, be careful not to get your hands or other parts of your body caught by the cover.

Perform the maintenance of the battery and the fusible links.

### Opening



1. Insert the ignition key and turn it counterclockwise to unlock the battery cover (1).
2. Open the battery cover (1) until it stops.

### Closing


1. Support the battery cover (1) by hand, and then release the stay (2).
2. Close the battery cover (1).
3. Insert the ignition key and turn it clockwise to lock the battery cover (1).



## DUMP BODY PROP

### **WARNING**

If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.



### Engaging the dump body prop

1. Fully raise the dump body.
2. Raise the safety lock lever to the lock position and stop the engine.
3. Pull up the ring and disengage the lock pin (1), and then remove the pin (2).
4. Pull the disconnected end of the prop (3) toward the lock hole, and then insert the pin (2) into the lock hole.
5. Attach the lock pin (1) and push down the ring.

### Disengaging the dump body prop

1. Move the right control lever to raise the dump body.
2. Disengage the dump body prop (3) and put it back in place.



## CAB

### CAB DOOR


#### WARNING

When getting on or off the cab, first open the door all the way until it is secured in the catch and check that it does not move.

Open the door fully and press it against the catch at the back of the door to secure it in place.

The door must be locked when getting on or off the machine and while in operation.


#### Locking and unlocking



Insert the ignition key and turn it.

#### Opening


1. Pull the knob (1) towards you and open the door.



To open the door from inside the cab, pull the lever (2) toward you.

2. Open the door fully and press it against the cab to secure it in place.


#### Closing



1. Push the release lever (3) downward.
2. Close the released door.

#### EMERGENCY EXIT

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.




## FRONT WINDOW


### WARNING

- Grasp the handles firmly with both hands when opening and closing the front window. Your head or hands may get caught if it slips from your hands.
- When the front window is opened or closed, it will come close to the head. Be careful that the window does not strike the head.
- When you open the front window, be sure to lock it in place with the lock pins on the left and right sides. The window may fall if it is not locked in place.

### Opening



1. Park on a level surface and stop the engine.
2. Set the safety lock lever to the locked position.
3. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
4. Pull the front window (3) toward you and lift while doing so.




5. Release your thumb from the knobs (2) and then lift the front window (3) fully and lock the front window with lock pin (4).

### Closing


### WARNING

When closing the front window slowly so as not to hit your head. Lowering the window abruptly may result injury or damage the front window.



1. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
2. Pull down the front window (3) and while doing so, slide it to the front and slowly lower it.







3. Release your thumb from the knobs (2) and then press the front window toward front and lock the front window with lock pin (4).

## LOWER FRONT WINDOW

### Removing




1. Open the front window and stow it in the ceiling.
2. Slowly lift the lower front window (4).



3. Hold the window in a vertical position (the bottom of the window should be in front of you), place it through the guide (5) on the left side of the cab, and then secure it with the support (6).




## SIDE WINDOW



1. Grasp the catch (7), unlock it and open the side window.
2. To close the side window, close it until a click is heard.

## EMERGENCY HAMMER (OPTIONAL)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the window pane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.




## SEAT AND SEAT BELT

### SEAT

#### **WARNING**

- Adjust and secure the seat.
- Do not make any adjustments while operating the machine.
- Do not set the backrest to its maximum reclining position and slide the seat backwards at the same time. Doing so may damage the rear window or cause injury.
- Remember that the backrest returns to the forward position abruptly due to the spring force.




#### **(A) Adjusting the backrest angle**

1. Sit up and sit back in the seat.
2. Pull up the lever (1), recline the backrest by using the spring force. Release the lever (1) at the desired angle to secure the backrest.

#### **(B) Fore-and-aft adjustment**

1. Pull up the lever (2) and slide the seat backward or forward to the desired position for operation of machine.
2. Release the lever (2) at the desired position to secure the seat.  
Adjustment range: 15 positions, in 150 mm (5.9 in.)



#### **(C) Adjusting according to operator's weight**

1. Turn the handle (3) until the scale (4) indicates the weight of operator.  
Adjustment range: 50 to 130 kg (110 to 287 lbs)

#### **(D) Adjusting the height of the seat**

##### Upward

1. Lift the seat to first or second position click-stop.  
Adjustment ranges: 2 positions, in 60 mm (2.36 in.)

##### Downward

1. First lift the seat to highest position, then the seat can be lowered to lowest position.




### (E) Adjusting the headrest (Option)

The headrest (E) can be moved upward or downward.


1. Grab the headrest (E) with both hands, and move upward or downward to the desired position.

### (F) Adjusting the operating lever stand



1. Pull up the lever (5) and slide the lever stand (seat).
2. Release the lever (5) at the desired angle to secure the lever stand (seat).  
Adjustment range: 9 positions, in 90 mm (3.5 in.)


### (G) Adjusting the seat pan angle



The angle of the seat pan can be individually adjusted.

To adjust, lift the left side handle (6). Use the pressure applied to the seat to set the seat pan to the desired angle.

### (H) Adjusting the seat depth



The depth of the seat pan can be individually adjusted.

To adjust, lift the right side handle (7). Move the seat cushion forward or backward until the desired seat depth is obtained.




## SEAT BELT

### **WARNING**

Be sure to fasten the seat belt securely before starting the engine.


#### Fastening the seat belt

1. Adjust the seat to the desired position for operation, sit upright and sit back in the seat.
2. Pull the seat belt to the desired length.



3. Make sure that the belt is not twisted and then insert the tongue plate (A) into the buckle (B) of the seat belt until you hear a clicking sound as it locks in place.
4. Check if the belt is securely locked by pulling it, and arrange the belt around your waist.

#### Releasing the seat belt




1. Grasp the tongue plate (A) and press the button (C) on the buckle (B).  
The seat belt retracts back into its original position.



# MULTI-INFORMATION DISPLAY

## HOME SCREEN



AAA0B012

For explanation purposes, all lamps on the screen image above are in the lit condition. This screen image is different from that of the real operation. If a warning is displayed, the corresponding symbol appears at the center of the display for approx. three seconds. If a function is selected, the corresponding symbol appears at the center of the display for approx. one second.

When the ignition switch is set to ON, the battery charge warning lamp and the engine oil pressure warning lamp first appear enlarged, and then turn on with an alarm at their original locations. The machine system is normal if the lamps turn off after the engine is started.



## WARNING LAMPS

**IMPORTANT: If a warning lamp flashes and an alarm is sounded, immediately stop all operations and check the corresponding component. Refer to “If a warning lamp flashes” on pages 6-12 and 6-13.**

### 1. ECU error warning lamp

This warning lamp flashes if the Electronic Control Unit (ECU) detects an engine problem while the ignition switch is in the ON position. The problem detected is recorded as an ECU error.

Refer to “Engine error code list” on pages 6-16 to 6-27.

### 1-1. Vehicle and engine emergency lamp

If there is a problem with the machine, this lamp is displayed enlarged for three seconds, and then flashes with an alarm sounding. Go to “Error code display” from the Menu screen, get the vehicle or engine error code number, and consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list” in this manual.


Refer to “Menu screen” on page 2-26.

Refer to “Error code display” on page 2-29.

Refer to “Vehicle error code list” on pages 6-14 and 6-15.

Refer to “Engine error code list” on pages 6-16 to 6-27.

### 1-2. Overrun warning indicator



If the engine revolution becomes too high to cause the engine to overrun, the overrun warning indicator and the vehicle and engine emergency lamp are in turn displayed enlarged and the buzzer sounds. After the vehicle and engine emergency lamp is displayed enlarged, the cluster screen is as shown in the figure. If the engine revolution is further increased, the buzzer sound changes from intermittent to continuous. The main cause of overrun could be that the machine is descending slopes at high speed or that the overloaded machine is descending the slopes. If the indicator appears on the LCD, stop the machine and observe the following procedures.

- Move to a more gentle slope to descend.
- Keep the low speed by minimizing the travel lever inclination angle.
- Travel with the accelerator dial set to the half throttle or less.
- The machine may be overloaded. Reduce the load and travel.

### 2. Engine stop request warning lamp

While the ignition switch is ON, if a serious engine problem occurs and thus immediate engine stop is required, this warning lamp starts flashing. Immediately stop the engine and inspect the problem.

### 3. Battery charge warning lamp

This lamp flashes and an alarm is sounded if a problem rises in the charging system while the engine is running.

### 4. Engine oil pressure warning lamp

This lamp flashes and an alarm is sounded if the lubricant oil pressure abnormally low while the engine is running.

### 5. Water separator warning lamp

This lamp flashes and an alarm is sounded if the water is detected within the water separator while the ignition switch is in the ON position.



### 6. Coolant temperature warning lamp

This lamp flashes and an alarm is sounded if the engine coolant temperature becomes abnormally high while the engine is running.

### 7. Air cleaner warning lamp

This lamp flashes and an alarm is sounded if the air cleaner filter is clogged while the engine is running.

### 8. Fuel level warning lamp

This lamp flashes when the fuel level is low while the ignition switch is in the ON position.

### 9. SCR system/NCD warning lamp

- SCR system warning lamp

If an abnormality, such as failure to inject DEF/AdBlue® solution or degradation of the solution, is detected in the SCR system while the engine is running, this lamp either lights up or flashes and the buzzer sounds.

#### Lamp light-up conditions

The lamp lights up if the above-mentioned abnormality occurs, and remains lit until the engine running time reaches 3 hours and 40 minutes unless the abnormality is corrected. If another abnormality occurs within 40 hours of engine running time after the last abnormality is corrected, the lamp lights up again and remains lit for less than 10 minutes. Note that this new abnormality may be different from the previous one. The engine RPM and fuel injection amount are not limited, but depending on the abnormality, they may be limited to protect the engine system. If this happens, immediately correct the abnormality

### Lamp flashing conditions

If the abnormality is not corrected within the engine running time of 3 hours and 40 minutes, the lamp starts flashing and keeps flashing until the end of the engine running time of 4 hours unless the abnormality is corrected. If another abnormality occurs between the time that the abnormality (flashing) is corrected (light off) and the time that the engine running time reaches 40 hours, the lamp starts flashing again and keeps flashing for 10 to 30 minutes. At this time, the engine RPM is limited to the maximum torque rotation speed + 200 min<sup>-1</sup> and the fuel injection amount is limited to 50%. If the engine running time exceeds 4 hours from the time the abnormality occurred, or if the engine running time exceeds 30 minutes from the time the reoccurred abnormality was corrected, the engine RPM is limited to low idle and the fuel injection amount is limited to 50%. If this happens, immediately correct the abnormality.

- NCD warning lamp

RED: This lamp flashes and an alarm is sounded if the NOx control detects any error.

NCD: NOx Control Diagnostic system





### 10. Pilot line filter warning lamp

This lamp flashes and an alarm is sounded if the pilot line filter for the hydraulic oil is clogged while the engine is running. This lamp may flash immediately after the engine is started in cold weather. This is not a malfunction. The lamp will turn off as the engine warms up.

### 11. DEF/AdBlue® level warning lamp

If the level of DEF/AdBlue® substantially decreases while the engine is running, this lamp either lights up or flashes and the buzzer sounds.

#### Lamp light-up conditions


The lamp lights up if the level of the DEF/AdBlue® level meter decreases to 10% or less. The engine RPM and fuel injection amount are not limited, but DEF/AdBlue® must be added immediately.

#### Lamp flashing conditions

If the DEF/AdBlue® level is decreased to 0%, the warning lamp flashes and the fuel injection amount is limited to 75%. If the DEF/AdBlue® level in the fuel tank is zero (unable to draw up DEF/AdBlue®), the engine RPM is limited to low idle and the fuel injection amount is limited to 50%. If this happens, immediately add DEF/AdBlue®.

**Note:** The Selective Catalytic Reduction (SCR) system is a system to reduce NOx emissions into the atmosphere, by spraying the DEF/AdBlue® solution (reduction agent) into the exhaust gas.

### 12. Safety start warning lamp




This lamp appears enlarged on the display and the buzzer sounds if the engine is started when the safety lock lever is in the unlock position. The engine cannot be started. First, set the safety lock lever to the lock position, and then start the engine.



## INDICATORS

### 13. Deceleration indicator lamp



#### **Automatic deceleration mode**

When the ignition switch is turned to ON, this lamp turns on to indicate that the engine is in the automatic deceleration mode.

The engine speed automatically drops to low idle (deceleration mode) four seconds after the control levers are set to neutral, to reduce fuel consumption. Moving the control levers will cause the speed to return to the original engine speed.

#### **Deceleration mode**

This lamp turns on when the deceleration button is pressed. The lamp lights up to indicate that the engine is in the deceleration mode at low idling speed (1200 rpm).

Refer to “Deceleration button” on page 2-32.


### 14. Exhaust temperature warning indicator lamp

This indicator lights up to warn if the exhaust temperature is abnormally increased. Check for any flammable items around the exhaust piping.

### 15. Glow indicator lamp

This indicator lamp turns off when the engine preheating is completed.

### 16. DPF auto regeneration/inhibit indicator lamp



#### **DPF auto regeneration under way**

The DPF regeneration is automatically performed by the engine, when certain criteria are met. The operator only has to check the display.

#### **DPF auto regeneration inhibit**

The DPF manual regeneration inhibit symbol appears on the display when the DPF manual regeneration under way or the DPF auto regeneration under way is cancelled.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-34.




**17. DPF manual regeneration under way/  
regeneration promoting/DPF manual  
regeneration error indicator lamp**

The indicator starts flashing and an alarm starts sounding, if the accumulated PM exceeds the limited amount on the DPF. Immediately perform the manual DPF regeneration.

Refer to “DPF manual regeneration/inhibit select switch” on page 2-34.

**Note:** When the DPF manual regeneration is started, there may be a case that the symbol corresponding to the error source is repeatedly displayed, resulting in DPF manual regeneration error. This problem will disappear after a while. If it continues for more than 15 minutes, contact your sales or service dealer for repair.

**18. Travel speed indicator lamp**



..... High-speed travel

..... Low-speed travel

This lamp turns on when the travel speed button is set to the 2nd (high) speed.

**19. Parking brake indicator lamp**

This lamp turns on when the parking brake switch is pressed.



..... Exhaust temperature is too low.


..... Orange: Water temperature is too high.

..... Blue: Water temperature is too low.

..... Fuel temperature is too high.




## 20. Dump body raising indicator lamp



This lamp lights up when the dump body is raised and moves out of the sensor's range. It goes out when the dump body is lowered all the way down.

## 21. Dump body alignment indicator lamp



This lamp lights up when the orientation of the dump body is parallel to the main frame. The lamp goes out when the dump body swings to the left or right.

## 22. Water temperature gauge

Indicates the temperature of the engine coolant water. The indicator level must be within the green range during machine operation. The red range indicates overheating.

## 23. Fuel gauge

Indicates the amount of fuel in the tank. Be sure to fill up the tank before running out of fuel.

## 24. Hydraulic oil thermometer


This instrument indicates the temperature of the hydraulic oil. The level must be within the green range during machine operation. The red range indicates overheating. This symbol flashes if the hydraulic oil temperature becomes abnormally high while the engine is running.

## 25. DEF/AdBlue® level indicator

This meter Indicates the amount of the DEF/AdBlue® solution remaining. Be sure to refill the tank in good time before running out of DEF/AdBlue®.



## 26. Engine load factor indicator



This gauge displays the load condition of the work. When the gauge is in the green range, the work load is light to medium. When the gauge is in the red range (75% or more), the work load is high. When the button (C) (Bar meter key) is pressed in a normal screen, the display changes in the following order: the engine load factor, throttle opening position and PM accumulation amount indicator.

**Note:** The machine is not faulty if the gauge is in the red range. Operating the machine with the gauge being in the green range is energy-saving and will help conserve the global environment.

- The throttle opening position is displayed if there is a change in the throttle opening position.

## 27. Air conditioner indicator lamp (If equipped)


Lights up while the air conditioner is operating.

## 28. Working lights indicator lamp

Lights up when the working light is turned on.




### 29. Date and time indicator



Displays the date and time set. Refer to “Date and time setting” on page 2-28.

### 30. Hour meter/Trip meter

#### • Hour meter



Displays the total engine running time in hours. The rightmost digit indicates tenths of

hours (6 minutes).


Set the inspection and maintenance intervals according to the time displayed on the hour meter.

#### • Trip meter

Three patterns of desired operating hours can be displayed.

Refer to “Trip meter setting” on page 2-27.

### SCREEN CONTROL KEY



**Note:** Do not press the symbol keys on the display. The LCD could be damaged if the symbol keys are pressed hard. For actual operation, press the push button keys located at the bottom of the screen.


#### A. Menu key

Use this key to switch between the Home screen and the Menu screen. This key is also used to cancel changes made in each setting. The screen returns to the Home screen if this key is pressed in the information screen.

#### B. Hour meter key

This hour meter symbol is displayed in the initial screen. Pressing this key changes the meter display in the following order: the trip meter 1, trip meter 2, trip meter 3 and hour meter.

#### Down (↓) key

Use this key to move the cursor  downward and to decrease the value in each setting. Press and hold this key for one second to rapidly decrease the value.



### C. Bar meter key

This bar meter symbol is displayed in the initial screen. Pressing the key changes the meter display in the following order: the engine load factor, throttle opening position and PM accumulation amount.

#### Up (↑) key

Use this key to move the cursor ► upward and to increase the value in each setting. Press and hold this key for one second to rapidly increase the value.

### D. Enter key

Use this key to confirm or execute the setting made by each key.

To clear the trip meter being displayed, press and hold this key for three seconds.

### E. Camera image key




#### WARNING

**Do not look at the images produced by the camera when traveling in reverse. Move in reverse while visually looking at the direction of travel.**

Since the camera is installed at the back of the dump body, the screen can be used to check the position or condition of dumping, as well as to display the rear view image.

**Note:** When the screen is used as a rear view monitor while traveling, make sure that the dump body is parallel to the main frame and the dump body alignment indicator lamp is on. It is dangerous to use the monitor when the dump body is swung.




1. Press the Camera key in the Main screen to display the images taken by the rear camera.
2. Press the Camera key again or other key to return to the Main screen.



## SCREEN NAVIGATION

- Menu screen



AAA0B016

Press the Menu key to go the Menu screen while in the Home screen.

- (1) Trip meter setting
- (2) ON/OFF setting
- (3) Date and time setting
- (4) Data display
- (5) Error code display
- (6) LCD setting


Move the cursor ► with the Up (↑) or Down (↓) key to go to the desired item to be set, and then press the Enter key to confirm. To return to the Menu screen, press the Menu key.

The wrench symbol indicates the “setting is possible state” and the (i) mark indicates information only.





## (1) TRIP METER SETTING



Six patterns of desired operating hours can be set.

To start setting, press the Enter key. The value flashes while being set.

Up (↑) key: Increases the value or moves the cursor ► upward. Rapidly increases the value when pressed and held for one second.


Down (↓) key: Decreases the value or moves the cursor ► downward. Rapidly decreases the value when pressed and held for one second.

Enter key: Confirms setting

Menu key: Cancels setting or returns to the Menu screen.

Pressing and holding the Enter key for three seconds clears the trip meter pointed by the cursor.

## (2) ON/OFF SETTING



The auto camera mode and the travel alarm can be set to ON or OFF.

To return to the machine setting screen, press the Menu key.


Use the Up (↑) or Down (↓) key to move the cursor ►, and then press the Enter key to turn on or off the blue circle.

Blue circle is lit: ON

Blue circle is off: OFF



### (3) DATE AND TIME SETTING



The year, month, date, hour and minute can be set. (Effective year range: 2010 to 2099)


- Move the cursor ► to the clock symbol, and then press the Enter key. The cursor ▼ will be shifted to the place for setting the year.

Press the Enter key again, and then enter the year. (The year display keeps flashing during editing.)

Press the Enter key to confirm. The month, date, hour and minute can be set using the same procedure for the year.

- Move the cursor ► to the calendar symbol, and then press the Enter key to change the format of “Year-Month-Date” to “Date-Month-Year” or “Month-Date-Year”. Refer to the trip meter setting for the key operation.

### (4) DATA DISPLAY



Displays various data. The setting cannot be changed.


Display items

- Engine RPM
- Coolant temperature
- Hydraulic oil temperature
- Battery voltage
- PM accumulation amount
- Ash accumulation amount

**Note:** For the data item not applicable to this machine, N/A is displayed.



## (5) ERROR CODE DISPLAY



### !.....Vehicle error code

Displays four error codes, with the latest code in the upper left.  
Refer to “Vehicle error code list” on pages 6-14 to 6-15.


### !.....ECU error code

Engine Control Unit (ECU) error code  
Displays three error codes, with the latest code at the top.  
Refer to “Engine error code list” on pages 6-16 to 6-27.

**IMPORTANT:** If an error code appears, immediately stop the operation and contact a Takeuchi sales or service outlet for help.


## (6) LCD SETTING

### • Background color setting



Move the cursor ► to the background color symbol, and then press the Enter key. The blue flashing light moves from blue gray to gray, blue and black, in this order. Move the blue flashing light to the desired color position, and then press the Enter key to confirm.

The background color can be changed in this screen, regardless of mode (day or night).



### • The brightness of the LCD is set to between 0 and 100%.

The brightness changes each time the adjustment is made.

While in the day (night) mode, adjustment is possible only for the brightness set to the night (day) mode.

Refer to the trip meter setting for the key operation.




- **Unit setting**


Switch between SI unit and US units.  
Move the blue flashing light to the desired unit position, and then press the Enter key to confirm.

Menu key: returns to the Menu screen.  
Pressing the Menu key again returns to the Home screen.

## SWITCHING IMAGES



- **Changing the background color (day/night)**




Turn on the light switch on any screen to decrease the display brightness and to enter the “evening mode”.



## SWITCHES

### IGNITION SWITCH




**IMPORTANT: Do not repeatedly switch the key from OFF to ON and ON to OFF over a short period. Doing so will cause engine breakdown.**

OFF ..... Position for stopping the engine and inserting or removing the key.

ON ..... Position in which the engine is running. At this position, all the electrical equipment is functional. When the coolant temperature is too low, the engine is automatically preheated.

START ..... Position for starting the engine. When the key is released, the switch automatically returns to the ON position.


### ENGINE SHUTDOWN SWITCH



This switch is used to shutdown the engine if it fails to stop, due to machine failure or breakage, when the ignition switch is set to the OFF position.

1. Press the switch (1).
2. After use, reset the switch (1).

### THROTTLE CONTROLLER




This dial controls the engine speed.

- (A).....Low idling
- (B) .....Medium speed
- (C) .....Maximum speed



## HORN BUTTON




Press the button situated on the right operating lever to blow the horn.

## DECELERATION BUTTON

### WARNING


Before operating the deceleration button, set the operating lever to the neutral position and take your foot off the pedals. If the deceleration button is pressed while driving, the machine's operating speed will abruptly change to result in a dangerous situation.



Press this button on the right operating lever to lower the engine speed to low idling. Press the button again to return to the engine speed set with the throttle controller. For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started. Cancel the deceleration mode by pressing the deceleration button as necessary.

**Note:** This deceleration button is capable of decreasing the engine speed and reducing the fuel consumption, with a simple operation, in a situation such as when little engine output is required and thus the operating or the travel levers are in neutral.


## TURN SIGNAL BUTTONS



The turn signal starts flashing and an alarm is sounded once any of the buttons is pressed.  
(A).....Left turn lights  
(B) .....Right turn lights




## TRAVEL SPEED BUTTON



Press this button to set the travel speed to 2nd (high) speed. Press it again to return to 1st (low) speed.


## AUTOMATIC DECELERATION SWITCH




When the safety lock lever is lowered to the unlock position, the deceleration lamp in the multi-information display flashes. This flashing stops when the deceleration function starts working, and the lamp remains lit while in the deceleration mode. The engine speed automatically drops to low idle (deceleration mode) four seconds after the control levers are set to neutral, to reduce fuel consumption. Moving the control levers will cause the speed to return to the original engine speed.



## DPF MANUAL REGENERATION/INHIBIT SELECT SWITCH



- The DPF and the exhaust gas emitted from the exhaust line can be very hot while the engine is running or the regeneration is under way, as well as immediately after the engine is stopped. Be careful not to accidentally touch them; doing so could cause burns.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.
- Do not perform regeneration when the engine hood is open. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.




**IMPORTANT:** Press the manual regeneration side on the DPF manual regeneration/inhibit select switch to burn the particulate matter (PM), when the DPF manual regeneration lamp flashes and an alarm sounds. If the machine continues to be operated without performing the manual regeneration, the engine power will decrease and eventually the engine will stop running. The ECM warning display will also flash if the DPF needs to be repaired. A number appears on the engine error code screen. Refer to the “Engine error code list” and contact a Takeuchi sales or service dealer for repair.

- **DPF manual regeneration**

When the DPF manual regeneration symbol on the display starts flashing and an alarm starts sounding, perform the DPF manual regeneration by following the procedure below.

  1. Park the machine in a safe place where there is no fire hazard.
  2. Raise the safety lock lever to the lock position.
    - Do not lower the safety lock lever and move the control levers during regeneration. Doing so interrupts the regeneration.
  3. Decrease the engine speed to low idling.
  4. Press and hold the manual regeneration side on the DPF manual regeneration/inhibit select switch.





5. The manual regeneration symbol stops flashing and remains lit to indicate that the engine RPM is automatically increased and the DPF (1) regeneration (PM burning) has started.
6. Release the switch. Do not leave the machine during regeneration. It takes approximately 25 to 30 minutes, depending on the ambient temperature, to complete the regeneration operation.
7. The manual regeneration symbol goes off to indicate the end of manual regeneration.

**Note:**

- Since the exhaust gas is cleaned through the catalyst fitted inside the DPF, it has a smell different from that of the conventional diesel engine.
- In some cases smoke may be emitted from the tail pipe while the DPF regeneration is being performed. This is not a failure; it is due to burning of the particulate matter (PM).
- It is normal that a sound is produced when the DPF regeneration is started or completed; This is to adjust the air-intake throttle and EGR opening position.
- In some cases the noise associated with the DPF regeneration operation or cancel operation may change; this is not a failure.
- The DPF manual regeneration can be completed faster while the machine engine is warm rather than cold. Note that the manual regeneration does not start unless the coolant temperature is higher than a set value. The coolant temperature may increase while manual regeneration is being performed.

- Since the DPF regeneration is designed to work only when the accumulated particulate matter (PM) in the filter exceeds a certain amount, it will not start otherwise, even if you attempt to perform manual regeneration.

• **DPF regeneration inhibit (cancel)**

To cancel the DPF regeneration currently being processed (manual or auto), press the regeneration inhibit symbol side. The DPF regeneration inhibit symbol appears on the display, and the regeneration operation must be performed again. Start the manual regeneration procedure from Step (1) above, as soon as possible. Do not press the DPF regeneration inhibit switch unless there is a risk of fire.

To cancel, press the switch again. Turning the ignition switch to OFF will also cancel the operation.


Refer to “DPF auto regeneration/inhibit indicator lamp” and “DPF manual regeneration under way/regeneration promoting/DPF manual regeneration error indicator lamp” on page 2-21.



## PARKING BRAKE SWITCH


**⚠ WARNING**

It is dangerous to press this button while traveling, as it causes the machine to stop abruptly. It may also damage the travel motors. Do not press this button while traveling except in emergency.



Pressing this button will light up the indicator and activate the parking brake.  
ON .....Forced activation of the parking brake  
OFF .....Automatic activation of the parking brake.  
Even when this button is OFF, the parking brake is automatically activated when the machine stops traveling.

## WORKING LIGHT SWITCH



When this switch is turned while the ignition switch is at ON, the lights turn on as follows:

- OFF ....Off
- ON .....Switch lamps, front light will be lit.




## FRONT WIPER SWITCH

**IMPORTANT:** If no washer fluid is discharged, do not operate the washer. Doing so may damage the pump.


**IMPORTANT:** Operating the wiper with no moisture on the windshield will scratch the glass. Use water or washer fluid when operating the wiper.

**IMPORTANT:** In cold climates, the wiper blade may freeze to the glass. Operating the wiper forcibly may damage the wiper motor.




OFF ....Off  
 INT .....Intermittence operation  
 ON .....Continuous operation

## WASHER SWITCH



ON .....Pressing the ON side of the switch causes the washer to spray washer fluid. To stop spraying, release the switch.

## BEACON LAMP SWITCH (IF EQUIPPED)



When this switch is turned on while the ignition switch is at ON, the lamp turns on as follows:  
 OFF ....Off  
 ON .....Beacon lamp is lit




## REAR WIPER/WASHER SWITCH

**IMPORTANT:** If no washer fluid is discharged, do not operate the washer. Doing so may damage the pump.

**IMPORTANT:** Operating the wiper with no moisture on the windshield will scratch the glass. Use water or washer fluid when operating the wiper.

**IMPORTANT:** In cold climates, the wiper blade may freeze to the glass. Operating the wiper forcibly may damage the wiper motor.



OFF ..... Off

ON ..... Wiper operates

PUSH.... Sprays washer fluid when pressed.  
Stops when released.




## LEVERS AND PEDALS

### SAFETY LOCK LEVER

#### WARNING

- Before standing up from the operator's seat to open/close the window, remove/install the lower window or adjust the operator's seat, lower the dump body all the way, raise the safety lock lever to engage the lock and stop the engine. If any control is accidentally touched when the safety lock lever is lowered (unlocked), the machine will suddenly move and cause serious injury or death.
- Be careful not to touch the operating levers when raising or lowering the safety lock lever.
- Before leaving the operator's seat, fully lower the dump body, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the cab, fuel filler cap and covers, take the key with you and store it in a specified place.



This device is for locking the dump body and travel operation.

When the lever is raised, the lever stand springs up to lock the lever.


#### Safety start function

When the lever is in the unlock position, the engine cannot be started.

### CONTROL LEVERS

#### WARNING

Before starting operation, carefully check which lever pattern you are going to use.



#### Right control lever


Use this lever to operate the dump body. Refer to "Lever pattern" on page 3-6. Refer to "Operating the dump body" on page 3-13.

#### Left control lever

Use this lever to move forward and in reverse and to change directions. Refer to "Lever pattern" on page 3-6. Refer to "Traveling the machine" on page 3-10.



## THROTTLE PEDAL



Releasing the pedal will return to the engine speed set with the throttle controller.

- (A).....Low idling
- (B) .....Maximum speed



## ACCESSORIES

### AIR CONDITIONER (IF EQUIPPED)

#### CAUTIONS ON USE

##### Ventilate periodically

- When using the air conditioner over an extended period of time, open the windows about once each hour to let in fresh air.
- Your eyes may become irritated if you smoke while using the air conditioner. If this happens, open the windows to let in fresh air. Smoking particularly irritates the eyes when the air conditioner is being used. Since the humidity in the cab drops, the cornea becomes dry.
- If the outside air is dirty, set the air conditioner to the circulation mode.

##### Always maintain good visibility

Working with dirty windows or fogged windows restricts visibility and is dangerous. Always clean dirt and moisture off the windows before working.

- The windows tend to get foggy when the humidity is high. If this happens, turn on the air conditioner to use outside air and the defroster to get rid of the fog.
- If the air conditioner is set to high when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn the air conditioner off or turn the temperature control dial clockwise to increase the internal temperature.
- Mist may blow out of the air outlets. This is not a malfunction. When moist air passes through the evaporator on the air conditioner unit, water particles in the air freeze and are emitted as mist.

##### Do not overcool

For health reasons, the air inside the cab should be kept at a temperature at which you feel a little cool when entering the cab from outside (a difference of 5 to 6°C (9 to 11°F)). Remember to adjust the temperature properly.

##### Do not turn on the air conditioner until the engine is started

To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.

##### Let hot air out first

If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.

##### Caution on refrigerant (gas)


If the refrigerant comes in contact with skin or eyes, it may cause frostbite or eye damage. Never touch the refrigerant or loosen the parts on the cooling circuit. If the refrigerant gas leaks, keep flames away.

##### Off-season inspection

Even off season, run the air conditioner for 3 to 5 minutes at least once a week to maintain oil in the various parts of the compressor.




## NAMES OF COMPONENTS



AAA0C001

1. Defroster
2. Condenser
3. Receiver dryer
4. Outlets
5. Compressor
6. Air conditioner unit
7. Circulation filter
8. Ventilation filter
9. Ventilation/Circulation select lever



AAA0C013

### Control panel


10. Air conditioner switch
11. Temperature control dial
12. Fan dial





### Air conditioner switch

**IMPORTANT:** To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.



Use this switch to turn on or off the cooling/dehumidifying function. When this switch is pressed while the engine is running with the fan dial set to ON, the lamp lights up and the cooling/dehumidifying function is turned on. Press this switch again or turn the fan dial to OFF to turn off the cooling/dehumidifying function.


Lamp is off ..... OFF

Lamp is on ..... ON

**Note:** To prevent leakage of refrigerant gas from the compressor's seal, operate the air conditioner at least once a week, regardless of the season.

**Note:** The air conditioner will not function if the temperature in the cab is low (3°C (38°F) or lower).

### Fan dial



Use this dial to select the fan speed from the three levels. Turning this dial to the OFF position turns off the air conditioner.


OFF ....Turning off the fan and the air conditioner.

○ .....Low

○ .....Medium

○ .....High

### Temperature control dial



Use this dial to adjust the air temperature.


COOL..... Decreases the temperature

HOT ..... Increases the temperature

**Note:** No warm air is emitted if the temperature of the engine coolant is low.




### Outlets



Move the louvers up or down or left or right to adjust the air flow direction and volume.

### Ventilation/Circulation select lever




Use this lever to select between Ventilation and Circulation.


- ..... Circulation
  - Cool or heat the cab quickly
  - When external air is dirty
- ..... Ventilation
  - Lets in fresh air
  - Removes frosting from the windows
  - Ventilates while cooling or heating

### Operation

Dehumidifying and Heating (in cold climates or when the humidity is high)



Arrange the foot outlets and the defroster so that they are directed to the front window. Let the dehumidified warm air blow on the front window, to prevent frosting.



1. Set the desired temperature by turning the temperature control dial to between the center and the right end (HOT).
2. Set the fan dial to the desired position.




## Cooling

### CAUTION


- When the air conditioner is set to the circulation mode, the air in the cab gradually becomes dirty. Switch to the “ventilation” to ventilate once a comfortable temperature is obtained.
- Excessive cooling can be harmful to your health. It is best to keep the air inside the cab only about 5 to 6°C (9 to 11°F) cooler than the outside air.

**Note:** If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.




1. Set the fan outlet to the desired position.
2. Set the desired temperature by turning the temperature control dial to between the center and the left end (COOL).
3. Set the fan dial to the desired position.

## Quick cooling



1. Set the fan outlet to the desired position.
2. Set the desired temperature by turning the temperature control dial to between the center and the left end (COOL).
3. Turn the fan dial to “High”.
4. Move the Ventilation/Circulation select lever to the right to select “Circulation”.

## Heating




1. Arrange the outlet louvers so that air can be directed to the feet.
2. Set the fan dial to the desired position.
3. Set the desired temperature by turning the temperature control dial to between the center and the right end (HOT).  
For the highest temperature, turn the dial all the way to the right.
4. Turn the fan dial to the OFF position to turn off heating.



### Defrosting or defogging the windows

**Note:** If the air conditioner fan is set to High when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn off the air conditioner or turn the temperature control dial clockwise to increase the internal temperature.



1. Set the desired temperature by turning the temperature control dial to between the center and the right end (HOT).
2. Set the fan dial to the desired position.
3. Move the Ventilation/Circulation select lever to the left to select "Ventilation".
4. Arrange the foot and defroster outlets so that they are directed to the front window.




## HEATER (IF EQUIPPED)

### WARNING


- Always be sure to allow sufficient ventilation.
- Do not place combustible or explosive objects near the air outlets.

### Control panel



1. Fan dial
2. Temperature control dial


### Fan dial



Use this dial to select the fan speed from the three levels.

- OFF ...Off
- .....Low
- .....Medium
- .....High

### Temperature control dial



Use this dial to adjust the air temperature. Counterclockwise

.....Decreases the temperature

Clockwise.....Increases the temperature

**Note:** No warm air is emitted if the temperature of the engine coolant is low.

### Ventilation/Circulation select lever

Refer to "Ventilation/Circulation select lever" on page 2-44.

### Outlets

Refer to "Outlets" on page 2-44.

### Filters

Clean the filters immediately after operating in dusty places.

If the filters are clogged, the air flow is reduced and a booming sound is heard from the heater unit.


Refer to "Cleaning the air filters (Air conditioner/ Heater)" on page 5-42.



## CUP HOLDER

### CAUTION

- Drinks may be spilled due to vibration when the machine is operating or traveling. Be particularly careful not to burn yourself with hot drinks.
- Note that the cigarette lighter or other electric parts may be damaged if drinks are spilled on them.




Pull out the cup holder towards you to use it. Push in the holder for storage after use.

## POWER SUPPLY SOCKET

### WARNING

Use only those electric products which comply with the specifications of this socket.




This socket is used to supply power to the devices inside the machine. When using, be careful not to exceed 12 V/ 5A. To use, open the cap (1).



## EXTERNAL POWER SOCKET

### WARNING

Use only those electric products which comply with the specifications of this socket.




AS7B032

This socket is used to supply power to the devices outside the machine. When using, be careful not to exceed 12 V/ 5A.  
After use, pull out the plug and close the cap (1).

## INTERIOR LIGHT

**IMPORTANT:** The battery capacity decreases if the interior light is left on for a long time when the engine is stopped.



AW4C007

O.....Remains off all the time.  
I.....Lights up all the time.




## RADIO (IF EQUIPPED)

### CAUTIONS ON USE

- To ensure safe operation of the machine, always be sure to keep the volume of the radio down to a level where you can easily hear sounds from outside the machine.
- Do not use the radio for a long time when the engine is stopped. Doing so will drain the battery and make it difficult or impossible to restart the engine.
- Be careful not to allow water or other liquids to come into contact with the radio. Otherwise, it may result in malfunction.

### NAMES OF COMPONENTS



AP1C004






**(1) POWER button**

Use this button to turn on or off the radio.


**(2) LCD**

<Home screen>



- (1) Operation mode  
USB: USB audio mode  
BT: Bluetooth mode  
AUX: Auxiliary in mode
- (2) Volume level
- (3) Audio control (For USB audio or Bluetooth mode only)

<Radio mode screen>



- (1) Radio band display  
FM1, FM2 FM3: FM band (Six stations can be preset to each band.)  
MW: AM band
- (2) Stereo display  
Turns on when receiving stereo.
- (3) Preset station
- (4) Display of frequency/clock

Displays the time/the receiving frequency and the operation mode.





**(3) Clock button (CLOCK)**

Pressing this button changes the display to the clock. Pressing the button again displays the frequency. If the button is not pressed for three seconds, the display returns to the frequency. Pressing and holding the button enters the clock setting mode.

**(4) Auto store/Auto seek station (SCAN)**

Press this button to automatically assign receivable radio stations to preset buttons (1 to 6).

**(5) Tuning button (TUNE  **

Press and hold this button (TUNE  or TUNE ) for two seconds or more to start seeking the receivable stations. The seeking stops when a station is found. To cancel tuning halfway, press the button again. Pressing the TUNE  button starts seeking stations with higher frequency. Pressing the TUNE  button starts seeking stations with lower frequency.

**(6) Preset buttons (1 to 6) (PRESET STATION)**

Each button can store three FM stations (FM1, FM2, FM3) and one MW (AM) station.

**(7) Band button (BAND)**

Pressing this button changes the band from FM1 to FM2, FM3 and MW (AM), in this order.



**(8) Volume control button (VOL  $\oplus$   $\ominus$ )**

Press the VOL  $\oplus$  button to increase the volume and the VOL  $\ominus$  button to decrease the volume.

**(9) Bluetooth button (B)**

Press this button to connect to the already paired and most recently connected Bluetooth-enabled device.

**(10) Bluetooth LED**

Lights up when a Bluetooth-enabled device is connected. Flashes while in the pairing standby mode.

**(11) Operation mode select button (MODE)**

Pressing this button changes the operation mode from FM or MW (AM) to Bluetooth, USB and AUX, in this order.


**(12) Auxiliary input jack (AUX)**

Open the rubber cap and connect to an earphone jack of a smartphone or portable audio player with a commercially available stereo mini-plug (3.5 mm) cable. Be sure that jack is closed with the rubber cap when not in use.

**(13) USB jack**

Open the rubber cap and connect to a USB flash drive with a commercially available USB extension cable. Be sure that jack is closed with the rubber cap when not in use.

**Setting the clock**



1. Press and hold the CLOCK button for at least two seconds to enter the clock setting mode. (The time display starts flashing.)
2. Use the tune  $\uparrow$  button to set the minute. Use the tune  $\downarrow$  button to set the hour.
3. Press the CLOCK button again to return to the clock display.



### Playing the radio

1. Select the band, FM or MW (AM) by pressing the BAND button.
2. Select the station with the preset button or the tuning button.
3. Adjust the volume with the VOL (⇐ or ⇒) button.

### Seeking stations (auto)

Press and hold the TUNE (⬆) button for two seconds or one to start seeking stations in the higher frequencies direction. Press and hold the TUNE (⬇) button for two seconds or more to start seeking stations in the lower frequencies direction. The radio will stop seeking when it finds a receivable station and start playing.

### Manual tuning

Press the TUNE (⬆) button to increase the frequency by one step. Press the TUNE (⬇) button to decrease the frequency by one step.

### Presetting stations

1. Press the BAND button to select a band (MW (AM) or FM), and then select the desired station.
2. To assign the selected station to a preset button, press and hold the button to be assigned for three seconds or more. The number of the preset button appears on the LCD to indicate that it is stored in the preset memory.
3. For more stations to preset, repeat the steps 1 and 2 above.
  - Each preset button (1 to 6) can store three FM stations (FM1, FM2, FM3) and one MW (AM) station.

### Auto storing stations (SCAN)

Press the SCAN button while playing the radio. The radio automatically starts seeking the receivable stations in the band currently selected and assign each preset button (1 to 6) a station.

**Note:** The previous stations stored will be cleared (cancelled) by the auto storing. If the station stored in the preset button is not desirable, try to preset the station manually.



### Playing back audio content stored on a USB flash drive

To enter the USB playback mode, first insert the USB flash drive while playing the radio and then press the MODE button. (The LCD changes to the time display and “USB” appears on the LCD.)

When playing back audio content stored on the USB drive, the following operations are available using the buttons (1) to (5).

#### (1) Backward (⏮) button

Moves one track backward and starts playing back from the beginning of it.

#### (2) Playback/Pause (⏸) button

Pauses playback when pressed during playback. When pressed again, starts playback from the point where the playback was paused.

#### (3) Stop (⏹) button

Stops playback when pressed during playback. When the Play/Pause button is pressed, the unit starts playing back the stopped track from the beginning.

#### (4) Forward (⏭) button

Moves one track forward and starts playing back from the beginning of it. Pressing and holding the button will fast forward the current track.

#### (5) Repeat (🔄) button

When pressed during playback, the unit repeats the current track.  
To cancel repeating, press the button again.

### Notes:

- When in the USB playback mode, do not insert or remove the USB drive.
- ESPERIA makes no warranty that the unit is compatible with every USB storage device.
- To connect the USB flash drive to the unit, use a commercially available USB extension cable.
- Do not connect any device other than a USB flash drive. The USB jack cannot be used to charge a device such as a smartphone.
- Please be advised that ESPERIA bears no responsibility for any damage to or loss of data on the USB drive arising from the use of the unit.

### Using the Bluetooth wireless technology

You can use your Bluetooth-enabled mobile phone or audio device by connecting it to the unit.

When a mobile phone is connected, incoming calls will be announced.

**Note:** Since the unit is not equipped with a microphone, the unit cannot be used for phone calls.

To use the Bluetooth device, certain profiles must be able to interpreted. The unit is compatible with the following profiles:



## Incoming mobile phone call

HFP (Hands-Free Profile)

## Bluetooth audio

A2DP (Advanced Audio Profile)

AVRCP (Audio Video Remote Control Profile)

**Note:** The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by ESPERIA is under license.

## Pairing a Bluetooth-enabled device

When pairing the unit with a Bluetooth device for the first time, you have to pair with each other.

Once pairing is done, the unit and the paired Bluetooth device can recognize each other.

**Note:** Before pairing with the unit, turn on the Bluetooth feature on the Bluetooth device. Refer to the instruction manual of the Bluetooth device for further instructions.

1. Press the MODE button to switch to the Bluetooth mode.
2. Turn on the Bluetooth feature on the Bluetooth-enabled device.
3. Press and hold the Bluetooth button until two short beeps are heard, indicating the unit has entered the pairing standby mode.
4. Select "CAR RADIO" on the Bluetooth-enabled device.

**Note:** Only one Bluetooth-enabled device can be paired and used at a time. To use a different device, follow the steps 1 to 4 for pairing again.

**Note:** At power-up, the unit automatically reconnects to the device most recently connected. When you leave the machine, cancel pairing by pressing and holding the Bluetooth button until two short beeps are heard, to avoid disconnection.

## Playing back audio content stored on a Bluetooth-enabled device

When a Bluetooth-enabled device has been paired with the unit, check if the Bluetooth LED is lit, and then press the MODE button to enter the Bluetooth mode.

While the Bluetooth device is connected, the following operations are available using the buttons (1) to (5).

### (1) Backward (⏮) button

Starts playing back from the beginning of the track currently playing. Pressing and holding the button will skip backward to the desired track.

### (2) Playback/Pause (⏸) button

Pauses playback when pressed during playback. When pressed again, starts playback from the point where the playback was paused.

### (3) Stop (⏹) button

Stops the currently playing audio.

### (4) Forward (⏭) button

Moves one track forward and starts playing back from the beginning of it.

### (5) Repeat (🔄) button

Disabled in the Bluetooth mode.

**Note:** If no sound is heard from the unit, check to see that the output destination of the music from the Bluetooth device is set to "CAR RADIO".



### **Receiving an incoming call on the Bluetooth-enabled device**

If a Bluetooth-enabled device has been connected, the unit enters the standby mode and waits for a call. When an incoming call arrives, "CALL" appears on the display, the volume of the car stereo is set to mute and the ringtone is heard from the speaker.

### **Auxiliary input (AUX)**

- Connect a portable audio player and listen to your favorite music.
- Plug a stereo mini plug (3.5 mm) into the AUX-IN jack on the radio.
- Press the MODE button and select "AUX" to switch to the AUX mode. (The "AUX" display appears on the LCD and the frequency display is changed to the time display.)
- To return to the radio, press the MODE button again.
- When connecting, adjust the sound volume level of the audio player so that it is same as that of the radio.
- The sound volume can be adjusted with the volume control buttons on the unit.
- Do not connect a device with a larger output compared with a portable audio player.

### **Resetting the radio**

If there is a problem such as display of incorrect frequency or failure in selecting, reset the unit by pressing the POWER button while pressing the Bluetooth button [B]. (In this case, the preset memory stations and clock are cleared.)

If you cannot reset the unit, please contact your sale or service dealer for help.



## SPECIFICATIONS

Power source: ..... 12/24 VDC (negative ground)

Max. power consumption:  
..... 2 A or less (at max. volume, 24 V)

Max. output power: .. 16 W + 16 W (4Ω)

Rated output power: 14 W + 14 W (10% distortion, 4Ω)

Dimensions:..... 178 (W) x 50 (H) x 91 (D) mm (without projections)

Receiving frequency: MW (AM) 530 to 1710 kHz (North, Central and South America), 522 to 1629 kHz (Japan, China), 531 to 1602 kHz (Europe)  
FM 87.9 to 108 MHz (North, Central and South America), 76 to 95 MHz (Japan), 87.5 to 95 MHz (China, Europe)

Practical sensitivity: ..MW (AM) 20 μV (S/N 20 dB)  
FM 3 μV (S/N 30 dB)

S/N ratio: .....FM 50 dB

AUX IN: ..... Stereo mini jack (3.5 mm); max. input, 1 V; rated input, 90 mV

Bluetooth standard: .. Ver. 2.1 + EDR

Output: ..... Class 2 (max. communication range 10 m)

Receiving frequency: 2.4 to 2.48 GHz

Supported profile: ..... HFP V 1.5, A2DP V 1.2, AVRCP V 1.0

USB standard: ..... USB 2.0/1.0

Supported file

- MP3: ..... MPEG 1/2/2.5  
..... Audio Layer 2/3
- WMA: ..... Windows Media™  
Audio

Supported format: .... FAT16/FAT32 file system

Max. output power: .. 0.5 A

**Note:** The appearance and specifications are subject to change for improvement without prior notice.

## TROUBLESHOOTING

For symptoms not included in the table below or if the problem persists after the proper remedies have been taken, consult your sales or service dealer.



## General

Symptoms	Major causes	Remedies
Radio does not operate or the display is inaccurate when the button is pressed.	<ul style="list-style-type: none"><li>• CPU malfunction due to noises, etc.</li></ul>	<ul style="list-style-type: none"><li>• Reset the unit by referring to "Resetting the radio". Note that once reset, all settings are cleared; set the unit again.</li></ul>
The clock is not displayed.	<ul style="list-style-type: none"><li>• Backup power supply (orange cable) is not connected.</li></ul>	<ul style="list-style-type: none"><li>• Consult your sales or service dealer for help.</li></ul>

## Radio

Symptoms	Major causes	Remedies
Sound is noisy.	<ul style="list-style-type: none"><li>• Incorrect frequency for the station</li><li>• Antenna (pillar antenna) is not extended.</li><li>• Antenna is not grounded or properly installed.</li><li>• The antenna is not connected to the power supply</li></ul>	<ul style="list-style-type: none"><li>• Tune to the correct frequency for the station.</li><li>• Be sure to extend the pillar antenna when using the radio.</li><li>• Consult your sales or service dealer for help.</li><li>• The power supply must be connected to the antenna with a built-in booster. For details on the connection, contact your sales or service dealer.</li></ul>
Unrealistic frequency is displayed.	<ul style="list-style-type: none"><li>• CPU malfunction due to noises, etc.</li></ul>	<ul style="list-style-type: none"><li>• Reset the unit by referring to "Resetting the radio". Note that once reset, all settings are cleared; set the unit again.</li></ul>





## USB

Symptoms	Major causes	Remedies
No sound is heard.	<ul style="list-style-type: none"><li>• The USB flash drive has no MP3/WMA files.</li><li>• The files on the drive are not MP3/WMA.</li></ul>	<ul style="list-style-type: none"><li>• Write the MP3/WMA files correctly on the USB flash drive.</li><li>• Use the MP3/WMA files properly encoded.</li></ul>
Sound skipping occurs. Noises are heard.	<ul style="list-style-type: none"><li>• The MP3/WMA files are not properly encoded.</li></ul>	<ul style="list-style-type: none"><li>• Use the MP3/WMA files properly encoded.</li></ul>
A USB device is not recognized.	<ul style="list-style-type: none"><li>• The USB flash drive is damaged.</li><li>• The USB connector is not properly connected.</li> <li>• The USB flash drive is not formatted to FAT32/16.</li></ul>	<ul style="list-style-type: none"><li>• Disconnect the USB flash drive from the unit, and then reconnect it. If the drive is still not recognized, replace it with a new one.</li><li>• Format the USB flash drive to FAT32/FAT16, and then rewrite the MP3/WMA file. Be sure to back up the files on the drive before formatting it.</li></ul>



## Bluetooth

Symptoms	Major causes	Remedies
A Bluetooth device cannot be connected.	<ul style="list-style-type: none"><li>• The Bluetooth device is not connected.</li><li>• Another Bluetooth device is connected.</li></ul>	<ul style="list-style-type: none"><li>• Some Bluetooth devices require longer time for connection and cannot be reconnected automatically. Check if the Bluetooth button is lit. If it does not turn on after a while, re-pair the device by referring to “Pairing a Bluetooth-enabled device”.</li><li>• If another Bluetooth device is connected, re-pair the device by referring to “Pairing a Bluetooth-enabled device”.</li></ul>
A Bluetooth device cannot be remote controlled.	<ul style="list-style-type: none"><li>• The AVRCP profile is not connected.</li><li>• The connection link between the unit and the device may be corrupted.</li><li>• AVRCP is not supported</li></ul>	<ul style="list-style-type: none"><li>• Remove all Bluetooth devices connected to the Bluetooth-enabled device, and then re-pair the device by referring to “Pairing a Bluetooth-enabled device”.</li><li>• Pair the Bluetooth device again with the unit by referring to “Pairing a Bluetooth-enabled device”.</li><li>• Check the profiles supported by the Bluetooth-enabled device.</li></ul>



**Bluetooth**

Symptoms	Major causes	Remedies
No sound is heard from the Bluetooth audio.	<ul style="list-style-type: none"> <li>• The volume on the Bluetooth-enabled device is too low.</li> <li>• Output destination of the Bluetooth device is not set to "CAR RADIO".</li> </ul>	<ul style="list-style-type: none"> <li>• The volume of the Bluetooth audio playback is dependent on the volume level set on the Bluetooth device Set the volume on the Bluetooth device to a proper level.</li> <li>• Check to see that the output destination of the music from the Bluetooth device is set to "CAR RADIO".</li> </ul>
Phone function is not available.	<ul style="list-style-type: none"> <li>• The unit does not support phone calls. Some mobile phone models may connect to the unit via the "phone call" profile.</li> </ul>	<ul style="list-style-type: none"> <li>• Change the microphone setting from the unit to the mobile phone microphone by referring to the instruction manual of the mobile phone being used.</li> </ul>
The Bluetooth audio is interrupted after receiving an incoming call.	<ul style="list-style-type: none"> <li>• Some mobile phones cannot resume the Bluetooth audio after a phone call interruption.</li> </ul>	<ul style="list-style-type: none"> <li>• After the phone call, re-pair the mobile phone with the unit by referring to "Pairing a Bluetooth-enabled device".</li> </ul>

**Regional limitation**

To use a Bluetooth-equipped radio, "radio wave authentication" must be obtained in the country where the radio is to be used.

It can be used in the countries listed below, as of August 2017. To use it in other countries, please contact your service or sales dealer for assistance.

**Countries where a Bluetooth-equipped radio can be used**

Ireland, Italy, UK, Estonia, Austria, Holland, Cyprus, Greece, Croatia, Sweden, Spain, Slovakia, Slovenia, Czech, Denmark, Germany, Hungary, Finland, France, Bulgaria, Belgium, Poland, Portugal, Malta, Latvia, Lithuania, Rumania, Luxemburg, Iceland, Norway, Liechtenstein, Switzerland, Turkey, USA, Canada, Japan



## FUEL SUPPLY PUMP (IF EQUIPPED)


### DANGER

Do not use the fuel supply pump for gasoline or hydraulic oil. Doing so could result in explosion or damage.  
Only use the fuel supply pump for diesel fuel.

### CAUTION


Do not fill the tank with additional fuel after the fuel supply pump stops.  
Doing so could cause the fuel to spurt out.

This device automatically supplies fuel to the fuel tank and stops automatically when the fuel tank is full.




1. Open the side cover.
2. Insert the pump's nozzle (1) in the fuel supply tank.
3. Press the switch (2).  
The pump stops automatically once the fuel tank is full.
4. Turn off the switch.
5. Store the nozzle.

## REAR LIGHT (IF EQUIPPED)



The working light switch is also changed.



OFF ..... Off

ON1..... The front light and the switch lamp are turned on.

ON2..... The front light, rear light (1) and the switch lamp are turned on.




## MIRRORS



### WARNING

Adjust the mirrors before operating the machine.  
If the visibility is poor, death or serious injury could result.

The mirror can be adjusted by moving it by hand. If it is too hard to move by hand or too loose, use a tool to adjust it. Set the machine to the travel posture, and then adjust the mirrors by following the instructions in this manual.



- Adjust the mirrors (1) so that you can see the view behind the machine.



A: The blind spot area, 1 meter (3.3 ft.) away from the machine.

- Adjust the mirrors (2) and (3) so that you can see the view of the portion obstructed by the dump body: the rear side portion 1 meter (3.3 ft.) away from the machine.




## CAMERA

### WARNING

Adjust the cameras before operating the machine.


If the visibility is poor, death or serious injury could result.



The images being taken by the camera (1) can be shown on the multi information display. While operating the machine, use the camera (1) to check the blind spots from the operator's seat.


Refer to "Camera image key" on pages 2-25. If the images are not correctly displayed, adjust the camera installation angle.

### Adjusting the installation angle



1. Loosen the right and left bolts (2) securing the camera (1).

2. Adjust the angle while checking the screen.
3. Tighten the right and left bolts (2) evenly.
  - Tightening torque: 0.5 N·m (0.4 ft-lb.)



4. Check if the images are shown on the multi-information display.

A: The blind spot area, 1 meter (3.3 ft.) away from the machine.

If the blind spot area A is not shown after adjustment, contact your service or sales dealer for assistance.



## **AUTO CAMERA MODE**

When the machine is driven in reverse, the display is automatically switched to the camera screen. When the machine stops driving in reverse, the display returns to the Home screen.

This function can be manually turned on or off. For setting the auto camera, refer to “ON/OFF setting” on page 2-27.





# OPERATION






## **BEFORE STARTING OPERATION**

### **GETTING ON OR OFF THE MACHINE**

#### **WARNING**

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move.



- Climb up/down the steps holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

### **WALK-AROUND INSPECTION**

Perform the walk-around inspections once a day before starting the engine for the first time that day.

Refer to "MAINTENANCE, Walk-around inspection", on pages 5-16 and 5-17.

### **DAILY INSPECTION**


Perform the daily inspections once a day before starting the engine for the first time. Refer to "MAINTENANCE, Daily inspection", on pages 5-18 to 5-26.




# STARTING AND STOPPING THE ENGINE

## BEFORE STARTING THE ENGINE


1. Adjust the seat for a comfortable operating position.
2. Fasten the seat belt.




3. Check that the safety lock lever is in the locked position.



4. Check that the control levers are in the neutral position.



5. Insert the key into the ignition switch, turn it to the ON position, then perform the following inspections:



- Check to see if only the battery charge warning lamp (1) and the engine oil pressure warning lamp (2) are flashing.
- Turn the light switch to check that the front light, rear light and meter light turn on.
- Operate the turn signal buttons and check if the turn signal lights flash and an alarm sounds.
- Press the horn button to check that the horn sounds
- Check the fuel level.
- Check the amount of DEF/AdBlue® solution remaining.


If a lamp does not light or the alarm is not sounded, the bulb may be burnt out or a wire may be damaged. Ask a Takeuchi service agent for repair.

**STARTING THE ENGINE****⚠ WARNING**

- Clear all personnel from the work area.
- Sound the horn to warn people around the machine.

**IMPORTANT:** Do not run the starter motor for more than 15 consecutive seconds. If the engine fails to start, wait for 30 seconds, and then try again to start the engine.

**IMPORTANT:** If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.


**Normal starting**

1. Turn the ignition key to the START position and start the engine.  
The engine does not start unless the safety lock lever is in the locked position at this point.  
Refer to “Safety lock lever” on page 2-39.
2. Once the engine starts, release the key.  
The key automatically returns to the ON position.
3. Check that the warning lamps are off.  
For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started.  
Cancel the deceleration mode by pressing the deceleration button as necessary.


4. Warm up the engine.  
Refer to “Warming up the engine” on page 3-5.
5. After the completion of the warming up, press the deceleration button to cancel the deceleration mode.

**Starting in cold climates****⚠ WARNING**

**Never use starting fluid on this engine, as the starting fluid could cause an explosion.**



1. Turn the throttle controller to the middle position.



2. Turn the ignition key to the ON position, and confirm that the glow lamp is on. (The glow lamp stays lit for 15 seconds when the coolant temperature is  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ .)
3. After the glow lamp goes out, press the deceleration button (to cancel the deceleration mode), and then turn the key to the START position to start the engine.  
The engine does not start unless the safety lock lever is in the locked position at this point.  
Refer to “Safety lock lever” on page 2-39.



- Once the engine starts, release the key.  
The key automatically returns to the ON position.
- Check that the warning lamps are off.
- Return the throttle controller to the original position and warm up the engine.  
Refer to “Warming up the engine”.


**Note:** If the engine is started at  $-15^{\circ}\text{C}$  ( $5^{\circ}\text{F}$ ), the revolution speed is controlled to 1500 min<sup>-1</sup> (rpm). After 10 seconds, the throttle controller operation becomes available.

**Note:** The glow lamp turns on if the coolant temperature is low after the engine is started.

### WARMING UP THE ENGINE

**IMPORTANT:** Avoid racing the engine until it has warmed up.

Do not warm up the engine for a long time (20 minutes or more). When idling is required, occasionally place a load or run the engine at medium speed.




- Return the throttle controller, and then run at a low idle with no load for 5 minutes.


### STOPPING THE ENGINE

**IMPORTANT:** Do not stop the engine suddenly when operating with heavy loads or at the maximum speed. Doing so may cause the engine to overheat or seize. Never stop running the engine suddenly except in emergency.

**IMPORTANT:** The SCR system operates for up to 10 minutes after the ignition switch is turned to the OFF position. When removing the batteries or electrical connectors for inspection or maintenance, wait for at least 10 minutes after the ignition switch is turned to the OFF position. Otherwise, the system could fail.



- Return the throttle controller.
- Idle the engine for about 5 minutes to gradually let it cool.



- Turn the ignition key to the OFF position to stop the engine.




# OPERATING THE MACHINE

## LEVER PATTERN

**! WARNING**

**Before starting operation, be sure to check which lever pattern you are going to use.**

This manual explains the operation by using the pattern described below.



AS7D003

	Travel Forward		Dump body lower
	Travel Reverse		Dump body raise
	Left Spin Turn		Dump body left swing
	Right Spin Turn		Dump body right swing
	Left Pivot Turn		
	Right Pivot Turn		
	Right Pivot Turn Reverse		
	Left Pivot Turn Reverse		

# MEMO

---




## WARMING UP THE MACHINE (HYDRAULIC OIL)

### **WARNING**


Operating the working equipment without warming up the machine (hydraulic oil) is dangerous, as the working equipment cannot respond to controls quickly or may move in unexpected ways, and the safety devices may not operate properly. Be sure to sufficiently warm up the machine.

**IMPORTANT:** Do not operate the levers too quickly when the hydraulic oil temperature is below 20°C (68°F). The proper hydraulic oil temperature during operation is 50 to 80°C (122 to 176°F). If operations must be performed at lower temperatures, heat up the hydraulic oil to at least 20°C (68°F).


### Normal warm-up




1. Turn the throttle controller to the middle position, and then run the engine at medium speed for about 5 minutes with no load.



2. Fully lower the safety lock lever to the unlock position.



3. Extend and retract the dump cylinders slowly several times with no load.




4. Slowly swing the dump body to the left and right.
5. Travel slowly forward and in reverse several times.





### Warm-up in cold climates


1. Perform the normal warm-up procedure.




2. Set the dump cylinders at the stroke end and keep it there.  
Do not keep this condition for more than 30 seconds.
3. Repeat the step 2 until the dump body operating speed becomes normal.

### INSPECTION AFTER WARM-UP

After warming up the engine and machine (hydraulic oil), perform the checks and inspections described below, and repair if necessary.



1. Check that the warning lamps and meters are as follows:
  - Are all warning lamps off?
  - Is the water temperature level within the green range?
  - Is the hydraulic oil temperature level within the green range?
2. Check that there are no irregularities in the exhaust color, sound and vibrations.




3. Raise the safety lock lever to the lock position, and then check that the control levers are locked.




## TRAVELING THE MACHINE

### **WARNING**


- Never allow anyone to enter the machine's swing radius and path.
- Signal your intention to move by sounding the horn.
- Do not travel while the dump body is being swung or raised. Doing so is dangerous because it causes the machine to become unstable. Fully lower the dump body and make it parallel to the main frame.
- Avoid sudden starting, stopping and turning. Otherwise, the loaded material could be shifted to cause the machine to lose its balance, or the structures in the surrounding area could be damaged by the material fallen from the dump body.
- Do not raise the safety lock lever while traveling. Doing so is dangerous; the parking brake will be activated and the machine will stop abruptly.
- Do not switch off the ignition switch while traveling. Doing so is dangerous; the machine will stop abruptly.
- Before traveling in reverse, visually check if the rear view is clear. Failure to do so could result in contact with a worker or obstacle.
- When hauling materials or when traveling over rough terrain or slippery road surface, slow down the travel speed and drive carefully.
- Avoid crossing over obstacles whenever possible. If you must do so, try to go over the obstacle at a right angle to it at a low speed. Never cross obstacles which will tilt the machine to an angle of 10° or greater.
- Clear all obstacles from the path of the machine.



1. Turn the throttle controller and increase the engine speed.



2. Fully lower the safety lock lever to the unlock position.




3. Fully lower the dump body and make it parallel to the main frame.




### Moving the machine forward and backward

1. Operate the left control lever as below.




- ➔ To move forward:  
Push the left control lever forward.
- ⇨ To move backward:  
Pull the left control lever backward.

### Traveling in 2nd (High) speed



Press the travel speed button on the left control lever to switch to 2nd (high) speed, and press it again to return to 1st (low) speed.


### Left turn



Turning to the left:

- ➔ To turn forward to the left:  
Tilt the left control lever forward to the left
- ⇨ To turn backward to the left:  
Tilt the left control lever backward to the right

### Right turn




Turning to the right:

- ➔ To turn forward to the right:  
Tilt the left control lever forward to the right
- ⇨ To turn backward to the right:  
Tilt the left control lever backward to the left



## Spin turn



- ➔ To spin left:  
Tilt the left control lever to the left.
- ⇨ To spin right:  
Tilt the left control lever to the right.


## STOPPING TRAVEL

### **WARNING**

- Park the machine on a flat, rigid and safe ground. Set the parking brake. If you must park on a slope, chock the tracks to block the machine.
- Before standing up from the operator's seat, raise the safety lock lever to engage the lock. If any controls are accidentally touched when the safety lock lever is not locked, the machine will suddenly move and cause serious injury or death.

### **CAUTION**

Never stop running the machine suddenly except in emergency. Stop in good time, if possible.



1. Set the left control lever slowly to the neutral position. The machine stops. Braking is automatically applied by the hydrostatic drive system when the left control lever is returned to the neutral position. Full braking is achieved when the safety lock lever is raised



## OPERATING THE DUMP BODY

### **WARNING**


- Before starting operation, be sure to check which lever pattern you are going to use.
- Before operating the dump body, check that the surrounding area of the machine is safe and clear.
- Do not travel while the dump body is being swung or raised. Doing so is dangerous because it causes the machine to become unstable. Fully lower the dump body and make it parallel to the main frame.

Use the right control lever to operate the dump body.

Return the right control lever to the neutral position to stop the dump body.


1. Lower the safety lock lever to the unlock position.

### Operating the dump body swing



- ➔ To swing left:  
Tilt the right control lever to the right
- ⇨ To swing right:  
Tilt the right control lever to the left.

### Dump body operation




- ➔ To lower the dump body:  
Push the right control lever forward.
- ⇨ To raise (dump) the dump body:  
Pull the right control lever backward.



## OPERATING PROCEDURES


### CAUTIONS ON OPERATING

#### Cautions on traveling




Traveling over obstacles (rocks, stumps, etc.) may put a great load on the machine body and may cause damage to it. Avoid crossing over obstacles whenever possible. If you must do so, travel at a low speed and go over the obstacle at the center of the track.

#### Cautions on traveling in 2nd (High) speed



On uneven ground, maintain the low speed and avoid starting, stopping or changing directions abruptly.

#### Precautions when loading material




When loading earth or sand, make sure that the machine operator is safe. Do not load material on slopes. Do it only on a firm ground.

Improper loading is dangerous, as it could cause the machine to tip over or result in the load shifting.

- Do not exceed the maximum loading capacity (3700 kg, 8155 lb).
- Load the material so that it is evenly distributed in the dump body.
- Be sure to properly secure the unstable load onto the dump body.

#### Precautions when dumping




Do not perform the following dumping operations. The machine may tip over due to the shift of the center of gravity.


- Dumping on slopes or bumpy terrain
- Dumping while swing the dump body
- Dumping while traveling



## **PRECAUTIONS ON USING THE MACHINE IN WATER**



- If the front of the machine is submerged in water as shown in the figure above, it could cause the radiator fan to turn in water, resulting in damage to the fan. The front of the machine must not be submerged.



- Allowable water depth  
Use the machine in water only when the water is up to the middle of the travel reduction gear case.
- For those parts used in water for a long time, apply enough grease until the old grease is expelled.
- Never submerge the swing bearing or main frame in water or sand. If submerged, contact a Takeuchi service agent for inspection.




## PRECAUTIONS WHEN TRAVELING ON SLOPES

### WARNING

When traveling on slopes, do it carefully so that the machine does not tip (roll) over or slide.

When traveling on slopes of 15 degrees or more, position the heavier end of the machine (front or back, whichever is heavier) pointing up the slope.



- Never travel on slopes that are too steep for the machine to maintain its stability (maximum gradeability: 30°, lateral tipping angle: 10°). Note that in reality, the machine's stability becomes lower than the above values depending on the working condition.
- When traveling on slopes or grades, drive slowly in 1st (low) speed. Especially on down slopes, slow down the engine speed and limit the stroke length of the left control lever to less than half. Going down a slope at high speed may lead to loss of control.
- Braking abruptly on slopes could result in the machine losing its balance and tipping over.




- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.
- The machine may slip sideways even on a slight slope if the ground is covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Make sure the machine is

- never positioned sideways on slopes.
- If the machine is stalled on the slope, return each control lever to the neutral position before restarting the engine.

### Traveling posture on slopes



### Braking when descending slopes




When descending slopes, the brakes are applied automatically once the left control lever is returned to the neutral position.






**If the engine stops**



If the engine stops when descending a slope, set the left control lever to the neutral position, stop the machine, then start the engine.


**Do not open the door while traveling on slopes**



Opening the door while traveling on slopes is dangerous, as the force required to open and close the door changes abruptly. Always keep the door closed when traveling on slopes.

**OPERATIONS POSSIBLE WITH THIS MACHINE**

**Backfilling**




Slowly travel in reverse until the dump body reaches the near side of the hole edge, and then raise the dump body to dump the loaded material.




## PARKING THE MACHINE

### PARKING

**! WARNING**




- Park the machine on a flat, rigid and safe ground. Set the parking brake.



If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.
- Before leaving the operator's seat, raise the safety lock lever to engage the lock and stop the engine.



- Do not leave the machine while the dump body is being raised. If it is absolutely necessary to leave the raised dump body unattended, be sure to engage the dump body prop to prevent the dump body from dropping.

**Before leaving the machine, do the followings:**

1. Fully lower the dump body and make it parallel to the main frame.
  2. Set the control levers to the neutral position.
  3. Return the throttle controller to idle the engine at low speed.
  4. Raise the safety lock lever to the lock position.
  5. Stop the engine and remove the ignition key.
- Refer to "Stopping the engine" on page 3-5.




## **INSPECTION AND CHECKS AFTER STOPPING THE ENGINE**

1. Check for oil or water leak and inspect the working equipment, covers and undercarriage. If any irregularities are found, repair.
2. Fill up the fuel tank.  
Refer to “Inspecting the fuel level” on page 5-20.
3. Remove any paper scraps or dirt from the engine room.
4. Remove any mud from the undercarriage.
5. Top off the DEF/AdBlue® tank.  
Refer to “Checking the DEF/AdBlue® level and refilling” on page 5-24.

### **Locking**

Be sure to lock the following places:



- Fuel filler cap
- Cab door
- Engine hood
- Side cover
- DEF/AdBlue® tank cover
- Battery cover



## **HANDLING IN COLD CLIMATES**

### **PREPARING FOR COLD CLIMATES**

Starting engine in cold climates is not easy, and it becomes more difficult if the coolant freezes. Prepare for cold-climate problems as follows.

#### **Replacing the fuel and lubricant**

Replace the hydraulic oil, engine oil and fuel with those intended for cold climates. Refer to “Fuel and lubricant table” on page 5-4.

#### **Engine coolant**



#### **WARNING**

**The engine coolant is combustible. Keep away from flame.**

**Use long-life coolant (antifreeze) and tap water for the engine coolant.**

**Note:** New machines are delivered with JIS Type 2 long-life coolant (antifreeze) at a concentration of 50%.

Refer to “Fuel and lubricant table” on page 5-4.

#### **Battery**

As the temperature drops, the battery performance decreases.

Inspect the battery. If it is discharging, contact a Takeuchi service agent to have the battery recharged.

Refer to “Inspecting the battery fluid level and replenishing” on page 5-34.

### **CAUTIONS AFTER OPERATIONS**

Observe the following cautions to prevent mud, water, or the undercarriage from freezing and making it impossible for the machine to move.

- Remove all mud and water from the machine body. In particular, wipe the hydraulic cylinder rod clean to prevent damage to the seal caused by mud or dirt on the rod surface getting inside the seal together with drops of water.
- Park the machine on hard and dry ground. If this is impossible, park the machine on a wooden board placed on ground.
- Drain any water in the fuel tank to prevent it from freezing.

Refer to “Draining the water from the fuel tank” on page 5-38.

- As the battery capacity drops markedly in low temperatures, cover the battery or remove it from the machine and keep it in a warm place.

If the electrolyte level is low, add distilled water in the morning before beginning work. To prevent the battery electrolyte from freezing in the night, do not add water after the day's work.

### **AFTER THE COLD CLIMATE**

When the climate becomes warmer, do as follows:

- Replace the fuel and oil for all parts with those specified in the “Fuel and lubricant table”.  
Refer to “Fuel and lubricant table” on page 5-4.
- If a coolant of “one season type” is used, drain the cooling system completely, clean out the inside of the cooling system thoroughly, and fill with tap water.  
Refer to “Cleaning the engine cooling system” on page 5-56.




## HANDLING RUBBER TRACKS


Rubber tracks have an inherent weakness, lack of strength, due to their use of rubber. Be sure to observe the prohibitions and cautions below to prevent the tracks from being damaged or coming off.

### PROHIBITIONS


Do not travel or operate the machine in the following places:




- Traveling and slewing on crushed rock, extremely rough hard rock, steel beams, scrap iron, or near the edges of steel plates will cause damage to the rubber tracks.



- Traveling on riverbeds or places where there are large numbers of boulders may cause the stones to get caught and damage the tracks or make the tracks come off.
- Do not use the machine on the seashore. The salt may corrode the steel core.



- Do not let fuel, oil, salt or chemical solvents get on the tracks. These substances may corrode the bonding of the steel cores on the tracks, resulting in rust or peeling. If any of these substances gets on the tracks, immediately clean it off with water.




- It will cause an irregular wear or damage to the lugs, if the machine travels on irregular surfaces such as recently paved with asphalt, exposed to a bonfire or of hot iron sheets under the blazing sun.
- Do not move earth in places where the rubber tracks may slip. Doing so may speed up lug wear.



## CAUTIONS

Observe the following cautions when operating the machine:

- Avoid changing course abruptly or spinning on concrete surfaces whenever possible. Doing so may wear or damage the rubber tracks.
- Avoid drops that may expose the rubber tracks to strong shocks.
- Salt, potassium chloride, ammonium sulfate, potassium sulfate, and triple superphosphate of lime can damage the tracks. If any of these substances gets on the tracks, wash it off thoroughly with water.
- Do not let the sides of the rubber tracks rub against concrete or walls.
- Be especially careful on snowy or frozen surfaces in winter, as the tracks tend to slip in such conditions.
- Use rubber tracks at temperatures between  $-25^{\circ}\text{C}$  to  $+55^{\circ}\text{C}$  ( $-14^{\circ}\text{F}$  to  $131^{\circ}\text{F}$ ).
- When storing the rubber tracks for long periods of time (three months or more), do so indoors in a place not exposed to direct sunlight or rain.




- Rubber tracks are not very stable because the entire lugs are made of rubber. Be very careful when swinging sideways.


## PREVENTING THE RUBBER TRACKS FROM COMING OFF

Observe the following cautions to prevent the track from coming off:

- Always keep the tracks at the proper tension.




- When traveling over a large step such as a cobblestone or rock (20 cm (8 in.) or deeper), climb up the step at the right angle and do not change courses on top of the step.




- When climbing in reverse, do not change directions at the point where the slope starts.




## OPERATION HANDLING RUBBER TRACKS




- Avoid traveling by setting one track on a slope or projecting portion and the other track on a flat surface (with the machine at a tilt of 10° or more). Travel with both tracks set on flat surfaces.



- The rubber track will come off if the machine travels backward in this condition.



- Do not change directions when the tracks are slack as shown in the figure.



- The rubber track will come off if the machine changes directions in this condition.



## **HANDLING THE ENGINE**

### **PROHIBITIONS**

Do not modify the exhaust gas control system. Any usages other than described in this manual are prohibited.

### **CAUTIONS**

- To maintain the engine's exhaust performance, operate or use the machine and perform inspection and maintenance by following this manual. Incorrectly operating or using the machine or performing inspection and maintenance could cause machine failure.
- If the exhaust gas control system is not properly functioning, the ECM error warning lamp turns on or flashes and an error code appears. If an error code appears, immediately repair the fault detected, or consult your sales or service dealer for help. Refer to "Exhaust gas control system error" on page 6-34.
- If the ECM error warning is ignored, the operator inducement system activates. Since the system limits the engine output, there is a possibility that machine becomes unable to move.

## **DIESEL FUEL**

The diesel fuel used must meet the requirements specified in the region where the machine is operated.

Refer to "Service data" on page 5-4.



# TRANSPORT




## LOADING AND UNLOADING

### WARNING


The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the tracks.
- Chock the transporter wheels to prevent movement.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramp. If it is necessary, move down from the ramps, change the course and then get on the ramps again.
- Do not swing or raise the dump body on the ramps. The machine may tip over.
- When raising the dump body on the truck bed, do it slowly as the footing should be unstable.
- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.

When loading or unloading the machine, be sure to use ramps or a platform and follow the procedure below.



1. Set the parking brake on the transporter and chock the wheels.
2. Fix the ramps securely to the truck bed. The slope of the ramps must not exceed 15°.
3. Align the center of the truck bed with the center of the machine, and of the ramp with the center of the track.
4. Fully lower the dump body and make it parallel to the main frame.
5. Set the travel speed to the 1st (low) and slow down the engine speed.



6. When getting on or down the ramps, the dump body (without load) must be pointing down the slope.
7. Drive the machine straight toward the ramps and slowly travel up or down the ramps, by following the signal from the signal person.
8. Load the machine at the specified position on the transporter. Refer to "Transporting posture" on page 4-4.



# HOISTING THE MACHINE

## WARNING


- Know and use the correct crane signals.
- Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
- When hoisting, use a wire rope capable of lifting the machine mass.
- Hoist the machine in only as manner described in the procedure below. Do not do it in any other manner. Doing so is dangerous as it may result in the machine losing its balance.
- Do not hoist the machine with an operator on it.
- When hoisting, hoist slowly so that the machine does not tip.
- Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.

**IMPORTANT:** This hoisting method applies to machines with standard specifications. This method is not applicable for the machines with non-standard attachments and/or optional products, because the center of gravity differs according to the attachments and optional products installed. Contact your Takeuchi service agent for details.

### Hoisting

1. Fully lower the dump body and make it parallel to the main frame.
2. Raise the safety lock lever to the lock position.
3. Stop the engine, remove the ignition key and get off the machine.
4. Install the wire ropes as shown on the figure below. Install the wire ropes and hoisting attachment without letting them touch the machine body.
5. Hoist the machine slowly until it leaves the ground.
6. Stop hoisting until the machine becomes stable, and then start hoisting the machine slowly again.

### Hoisting posture






## SECURING THE MACHINE

After loading the machine at the specified position, secure it as described below.

### Transporting posture



AS7F002

1. Raise the safety lock lever to the lock position.
2. Stop the engine, remove the ignition key and lock all locks.
3. Place the stoppers (chocks) in front and behind the tracks.
4. Install a chain or wire rope over the lower frame of the machine and fasten it securely to prevent the machine from slipping sideways.

### Precautions to be taken during transportation



#### WARNING

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.

# MAINTENANCE





## GENERAL

### MAINTENANCE OVERVIEW

To keep the machine in good condition and use it for a long period, perform the inspection and maintenance properly and safely following the procedures recommended by this manual.

The inspection and maintenance items are divided into groups according to the machine's total operating time: every 10 hours (walk-around and daily inspection), every 50 hours, every 250 hours, etc. Refer to the hour meter readings to determine when to schedule an inspection and maintenance. Items for which it is not possible to determine the inspection and maintenance interval are included under "When Required".

When operating the machine in extremely harsh environments (with high dust levels or high temperatures), inspection and maintenance should be performed earlier than the times specified on the Maintenance List.

### CAUTIONS ON MAINTENANCE

Do not perform any other inspection and maintenance works than those listed in this manual.

For works not listed in this manual, ask your sales or a service dealer for help.

#### Keep the machine clean

- Clean the machine before performing inspection and maintenance and try to keep it clean.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.

#### Fuel, lubricant, grease and DEF/AdBlue®

- Choose fuel, lubricant, grease and DEF/AdBlue® by referring to the "Fuel and lubricant table".
- Use clean fuels, lubricants, greases and DEF/AdBlue® which do not contain water, and take care not to allow any dirt to enter the tank when replacing or refilling.
- Store fuels, lubricants, greases and DEF/AdBlue® in the prescribed places and in such a way that no water or dirt can get in them.

#### Cautions on refueling

- If the port includes a strainer, do not remove the strainer when fueling.
- After fueling, be sure to securely tighten the fuel filler cap.
- Do not add more than the specified amount of fuel.

#### Do not use fuel to clean parts

Do not use fuel to clean parts. Use a non-combustible cleaning agent.

#### Keep dirt out

When mounting and removing parts, do so in a place where there is no dust, clean the working area and the part, and keep dirt out.




### Clean the installation surfaces

When installing and removing parts, be sure that the surfaces of contact of the parts are clean. If the sealing grooves of the surface of contact are damaged, consult your sales or service dealer for repair or release.

### Seals and split pins

- Be sure to replace all seals and cotter pins with new ones.
- When installing, be careful not to damage or twist the seal.

### Sealing tape



- When wrapping the plug with sealing tape, remove any old sealing tape from the threads and clean the threads.
- Wrap the thread tight with seal tape starting 1 or 2 threads away from the thread end.

### Disposing of wastes

- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, cooling water, coolant, filters, batteries and DEF/AdBlue®.

### Check after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from serviced parts.
- Operate each control lever and check that the machine is operating properly.

### Cautions on handling of battery wiring

- Disconnect the wiring from the both terminals (+ and -) on the battery before working on the electrical system or doing electric welding. Always disconnect it from the earth side (-). When connecting, connect the earth side last.
- Do not disconnect the battery wiring while the engine is moving. Otherwise, the electric circuits of the rotary converter or others may be damaged.
- The SCR system operates for up to 10 minutes after the ignition switch is turned to the OFF position. When removing the batteries or electrical connectors for inspection or maintenance, wait for at least 10 minutes after the ignition switch is turned to the OFF position. Otherwise, the system could fail.



## SERVICE DATA

### FUEL AND LUBRICANT TABLE

Select the appropriate fuel, lubricant and grease according to the temperature by referring to the table below.

- Regardless of the specified time, change the oil if it becomes too dirty or degraded.
- When refilling, never mix oils of different brands. If a brand is to be changed, replace the whole fuel/oil.

#### Fuel

##### Diesel fuel specifications

Diesel fuel should comply with the following specifications. The table lists several worldwide specifications for diesel fuels.

Diesel fuel specification	Area	Diesel fuel specification	Area
ASTM D975 No.1-D S15 No.2-D S15	USA Canada	ISO 8217DMX	International
Bio-diesel fuel Biodiesel blends up to B7 ASTM D6751			
EN590: 2009	European union	BS2869-A1 or A2	United kingdom
Bio-diesel fuel Biodiesel blends up to B7 EN14214			





<b>Fuel tank</b>	<b>Diesel fuel</b>	<p>To maintain the performance and service life of the engine, always use clean and high-quality fuel.</p> <ul style="list-style-type: none"><li>• To avoid freezing in cold climates, use a diesel fuel that still functions when the temperature is at least 12°C (21.6°F) below the lowest expected ambient temperature.</li><li>• Use a diesel fuel that has a cetane number of 45 or higher. When operating at a very low temperature or at a high altitude, a higher cetane number fuel will be required.</li><li>• Use fuel with sulfur content of less than 15 ppm by volume. Especially in the U.S.A. and Canada, ultra-low sulfur fuel should be used. A higher sulfur content fuel may cause sulfuric acid corrosion in the cylinders of the engines.</li><li>• Never mix kerosene, used engine oil, or residual fuel with the diesel fuel. Use of kerosene is prohibited.</li><li>• Poor quality fuel can reduce engine performance and / or cause engine damage.</li><li>• Fuel additives are not recommended. Some fuel additives may cause poor engine performance.</li><li>• Use zinc- and sodium-free fuel.</li><li>• Do not use the fuel that has been in storage for a long time.</li><li>• Do not use the fuel purchased from a non-authorized dealer.</li><li>• In the EU, use fuel that satisfies the following conditions<ul style="list-style-type: none"><li>· Sulfur content is 10 mg/kg (10 ppm) or less, and 15 mg/kg (15 ppm) or less at the final distribution point.</li><li>· Cetane number is 45% or more.</li><li>· Fatty acid methyl ester (FAME) content is 7% v/v or less.</li></ul></li></ul> <hr/> <p>Precautions when using bio-diesel fuel The warranty of the engine manufacturer may be voided by using a bio-diesel fuel that does not meet the standard or that is deteriorated.</p>
------------------	--------------------	---



**Lubricant**

Location	Type	Type by air temperature								When to replace
		-4	14	32	50	68	86	104°F		
		-20	-10	0	10	20	30	40°C		
Engine oil pan	Diesel engine oil API: CJ-4 class ACEA: E6 class								SAE 10W-30	Every 500 hrs. or once a year (whichever comes first)
Hydraulic oil tank	Anti-wear hydraulic oil								ISO VG46	Every 1000 hrs.
Engine cooling system	Cooling water (water + coolant)** SAE: J814C or J1034 ASTM: D6210 or D4985 (USA)								Mixture of 50% coolant	Every 2000 hrs. or every two years (whichever comes first)
									Mixture of 30% coolant	
Travel reduction gear	Gear oil API: GL-4								SAE 90	Every 1000 hrs after the initial 250 hrs*.
Swing bearing	Lithium based grease EP-2 NLGI No.2								—	Every 250 hrs.
Dump body										Daily or every 10 hrs.
Track roller										
Levers										

\* : If the ratio of traveling time to total operating time is high, replace the gear oil earlier than the specified time.

\*\* : For water, use tap water (soft). Do not use well or river water. When the ambient temperature drops below 0°C, add coolant (antifreeze). Follow the coolant manufacturer’s instructions to determine the mixture ratio.

API standard: American Petroleum Institute

ACEA standard: Association des Constructeurs Européens d’Automobiles

SAE standard: Society of Automotive Engineers

**Volume**

Engine oil pan	Engine cooling system	Hydraulic oil tank	Fuel tank	Travel reduction gear
Upper limit 10.5 L (11.1 US qt.)	18.5 L (19.5 US qt.)	System 84 L (22.2 US gal.)	Level capacity 127 L (33.6 US gal.)	2.6 L X 2 (2.7 US qt.) X 2
Lower limit 6 L (6.3 US qt.)		Tank 44 L (11.5 US gal.)	Effective capacity 121 L (32 US gal.)	

**Note:** On the DPF-equipped engines, part of the fuel may get mixed with engine oil during the regenerating process. This may dilute the oil and increase its quantity. If the oil rises above the upper limit of the oil level gauge, it means the oil has been diluted too much, resulting in a trouble. In such case, immediately replace the oil with new one.



## HANDLING OF DEF/ADBLUE®

The standard for DEF/AdBlue®

The DEF/AdBlue® used must be compliant with ISO 22241.

### Quantity of DEF/AdBlue® to add

DEF/AdBlue® tank
Tank capacity 13.8 L (3.6 US gal.)

### Storing DEF/AdBlue®

- Store the DEF/AdBlue® solution in a sealed container to prevent it from vaporizing.
- Store the solution in an indoor place, away from the direct sunlight, well vented and at the temperature lower than 25°C (77°F). Do not store it in a place where the temperature falls below -5°C (23°F).
- The life of DEF/AdBlue® is dependent on the temperature of the room it is stored.
- The quality of DEF/AdBlue® is maintained even after it is frozen and thawed. It is useable without doing anything.
- When storing or carrying the DEF/AdBlue® solution, use the container in which it was contained when purchased.  
If you must use the other container made out of polyethylene or stainless steel, choose a clean one without any water or dirt adherent to it and clean it with the DEF/AdBlue® solution before use.
- Do not store the DEF/AdBlue® solution in a place where the temperature may become extremely high.  
There is a risk that ammonia gas may be released if the DEF/AdBlue® solution heats up to high temperature.  
Seal the container before storing, and open the seal in an open outdoor area.  
If there is a pungent odor, do not get near it unless necessary.
- Do not use expired DEF/AdBlue® solution (including solution left in the tank) stored for a long period. Doing so could cause ammonia slip, degraded NOx conversion efficiency or device damage. For the life of DEF/AdBlue®, refer to the table below.

### Effective storage period in accordance with JIS K2247-2/ISO22241-1

Storage temperature	Expected DEF/AdBlue® life
$\leq 10^{\circ}\text{C}$ (40°F)	36 months
$10^{\circ}\text{C}$ (40°F) < T $\leq 25^{\circ}\text{C}$ (77°F)	18 months
$25^{\circ}\text{C}$ (77°F) < T $\leq 30^{\circ}\text{C}$ (86°F)	12 months
$30^{\circ}\text{C}$ (86°F) < T $\leq 35^{\circ}\text{C}$ (95°F)	6 months



## LIST OF CONSUMABLES

Periodically replace consumables such as filters and elements according to the table below.

System	Item	Part name	Part No.	When to replace
Hydraulic system	Hydraulic oil return filter	Cartridge	15510-00320	Every 1000 hrs after the initial 50 hrs.
	Pilot line filter	Element	15511-02802	Every 500 hrs after the initial 50 hrs.
Engine lubrication system	Engine oil filter	Cartridge	Y119005-35151	Every 500 hrs. or once a year (whichever comes first)
Fuel system	Fuel filter	Cartridge	Y129A00-55800	Every 500 hrs.
	Water separator filter	Element	Y129A00-55730	
Air cleaner system	Air cleaner	Primary (Outer) element	Y129979-12560	Every 1000 hrs. or after 6 cleanings (whichever comes first)
		Secondary (Inner) element	Y129979-12550	When the primary elements are replaced.
AC system	Receiver dryer		19115-05511	Every 2 years
	Ventilation filter	Element	08714-61536	Once a year or if clogging remains after cleaning
	Circulation filter	Element	19115-06736	



## LIST OF TOOLS (IF EQUIPPED)

Code	Part name	Part No.	Remarks
1	Spanner	19100-47081	10-12
2	Spanner	19100-47082	14-17
3	Spanner	16900-01922	19-22
4	Spanner	16900-02427	24-27
5	Spanner	16900-02730	27-30
6	Spanner	16900-03236	32-36
7	Spanner	16901-00013	13
8	Spanner	16901-00041	41
9	Spanner	16909-00019	19
10	Screwdriver	19100-06112	(+) (-) replaceable shank
11	Filter wrench	19103-47081	
12	Hammer	16903-00330	3/4
13	Monkey wrench	16904-00250	250 mm
14	Pliers	16905-00200	200 mm
15	Hex.wrench	16906-00250	2.5 mm
16	Hex.wrench	16906-00500	5 mm
17	Hex.wrench	16906-00600	6 mm
18	Hex.wrench	16906-00800	8 mm
19	Hex.wrench	16906-01000	10 mm
20	Hex.wrench	16906-01200	12 mm
21	Tool case	16914-00005	
22	Case	16919-00001	
23	Grease gun	16910-60600	600 cc
24	Drain connector	15545-12601	





## LIST OF TIGHTENING TORQUES

### Nuts and Bolts (for ISO strength category 10.9)

Tighten nuts and bolts at the torques shown on the table below, unless otherwise specified.

- The tightening torques used for the mounted plastic covers are not listed in the table below. Consult your sales or service dealer for details. They will be damaged if over tightened.
- When replacing nuts and bolts, replace them with nuts and bolts of the same size and standards.
- Tighten nuts and bolts alternately (top, bottom, left then right) or in 2 or 3 times so that they are evenly tightened.



Classification	Head width (b)	Size (a) x pitch	Tightening torque	
			General connection points	
			N·m	ft·lb.
Coarse	10	M6 x 1.0	9.8±0.8	7.2±0.6
	12, 13	M8 x 1.25	23±1.8	17±1.4
	14, 17	M10 x 1.5	47±3.8	35±2.8
	17, 19	M12 x 1.75	83±6.6	62±5
	19, 22	M14 x 2.0	134±10.7	99±7.9
	22, 24	M16 x 2.0	208±16.6	153±12.2
	27, 30	M20 x 2.5	411±32.9	303±24.2
Fine	12, 13	M8 x 1.0	25±2	18±1.4
	14, 17	M10 x 1.25	50±4	37±3
	17, 19	M12 x 1.5	87±7	64±5.1
	19, 22	M14 x 1.5	135±10.8	100±8
	22, 24	M16 x 1.5	221±17.7	163±13
	27, 30	M20 x 1.5	452±36.2	333±26.6

# MEMO

---



## SAFETY-CRITICAL PARTS

To use the machine safely, periodically perform inspection and maintenance. The safety-critical parts listed below must be periodically replaced for an increased safety. Serious injury or a fire could result if they are worn or damaged.

### List of safety-critical parts

Unit		Safety-critical parts to be replaced periodically	When to replace
Fuel system		Fuel hoses	Every 2000 hrs. or every two years (whichever comes first)
		Packing on fuel filler cap	
Cooling system		Rubber hoses	Every 2 years
Heater & AC systems		Heater hoses	
		Air conditioner hoses	
Hydraulic system	Main body	Hydraulic hoses (pump - delivery)	
		Hydraulic hoses (pump - suction)	
		Hydraulic hoses (travel motor)	
	Working equipment	Hydraulic hoses (swing motor)	
		Hydraulic hoses (dump cylinder piping)	
		Hydraulic hoses (tension cylinder piping)	
		Hydraulic hoses (pilot valve)	
		Seat belt	Every 3 years
		Non-slip sheet	





MAINTENANCE  
**SAFETY-CRITICAL PARTS**

---

The material of the safety-critical part listed above tends to change over time and cause wear or deterioration. It is difficult to determine the degree of deterioration at the periodic inspection, and thus they need to be replaced with new ones after a certain time to maintain their proper performance even if they appear in good condition. Note that regardless of the replacement schedule, replacement must be performed immediately if a symptom of wear is found. If a hose clamp is deformed or cracked, replace it together with the hose immediately. When replacing the safety-critical parts, ask your sales or service dealer.

In addition to the safety-critical parts, inspect the hydraulic hoses and retighten or replace as necessary. When replacing the hydraulic hoses, replace the O-rings and seals at the same time.

Check the fuel and hydraulic hoses according to the periodic schedule described below.

Refer to "Maintenance".

Type of inspection	Inspection item
Daily inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damage to cab - replace*
Monthly inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damaged hydraulic or fuel hoses (cracks, wear and tear)
Annual inspection	Leakage from the connecting parts of hydraulic or fuel hoses Deteriorated, twisted, damaged hydraulic or fuel hoses (cracks, wear and tear) or hoses in contact with other parts of the machine

\*: Cab parts No. 07186-00010



## MAINTENANCE LIST

Inspection and maintenance item	Page
<b>Walk-around inspection</b>	
Inspecting by opening the engine hood and covers	5-16
Inspecting by walking around the machine	5-17
Inspecting while sitting in the operator's seat	5-17
<b>Daily inspection (every 10 hours)</b>	
Inspecting and replenishing the coolant	5-18
Inspecting and replenishing the engine oil	5-19
Inspecting the water separator	5-20
Inspecting the fuel level	5-20
Inspecting the hydraulic oil tank level and replenishing	5-21
Lubricating the dump body and track rollers	5-23
Checking the DEF/AdBlue® level and refilling	5-24
<b>After the initial 50 hours (only for new machines)</b>	
Replacing the hydraulic oil return filter	5-27
Replacing the pilot line filter	5-28
Inspecting and adjusting the fan belt	5-29
Inspecting and adjusting the compressor belt (Air conditioner)	5-31
<b>Every 50 hours</b>	
Inspecting the track tension	5-33
Inspecting the battery fluid level and replenishing	5-34
<b>After the initial 250 hours (only for new machines)</b>	
Replacing the travel motor gear oil*	5-36
<b>Every 250 hours</b>	
Inspecting and adjusting the fan belt	5-37
Inspecting and adjusting the compressor belt (Air conditioner)	5-37
Draining the water from the fuel tank	5-38
Cleaning the air cleaner	5-39
Cleaning the radiator fins and the oil cooler fins	5-41
Cleaning the condenser (Air conditioner)	5-41
Cleaning the air filters (Air conditioner/Heater)	5-42
Inspecting the refrigerant (gas) level (Air conditioner)	5-43
Lubricating the swing bearing	5-45

\*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.



Inspection and maintenance item	Page
<b>Every 500 hours</b>	
Replacing the pilot line filter	5-46
Replacing the engine oil and the oil filter	5-46
Replacing the fuel filter	5-48
Replacing the water separator filter	5-49
Inspecting the slew pinion gear	5-49
Replacing the air cleaner element	5-50
<b>Every 1000 hours</b>	
Replacing the hydraulic oil return filter	5-51
Replacing the travel motor gear oil*	5-51
Replacing the hydraulic oil and cleaning the suction strainer	5-52
Inspecting and adjusting the engine valve clearance	5-54
Inspecting the radiator cap	5-54
<b>Every 1500 hours</b>	
Inspecting the crankcase breather system	5-55
<b>Every 2000 hours</b>	
Cleaning the engine cooling system	5-56
<b>Every 3000 hours</b>	
Inspecting the ECU and related sensors and actuators	5-58
Inspecting the turbocharger (blow wash as necessary)	5-58
Inspecting the DPF and DOC	5-58
Inspecting the operation of the air intake throttle valve	5-58
Inspecting the SCR catalyst and related sensors and actuators	5-58
Inspecting and replacing the supply module main filter	5-58
Inspecting and cleaning the fuel injector	5-58
<b>When required</b>	
Inspecting and replenishing the windshield washer fluid	5-59
Lubricating the levers	5-59
Draining the water from the water separator	5-60
Inspecting and cleaning the DPF soot filter	5-60
Inspecting the rubber tracks	5-61
Replacing the rubber tracks	5-62
<b>Every 2 years</b>	
Replacing the receiver dryer	5-64

\*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.




## WALK-AROUND INSPECTION

Perform the following inspections every day before starting the engine for the first time.

### **WARNING**

- Before operating, perform the walk-around inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or covers open on a windy day or if the machine is parked on a slope.

Before starting the engine, look around the machine and clean any combustibles from the surroundings of the engine. Also, inspect if oil or water is leaking and any nuts, bolts or electric wiring are loosened or damaged.



### **INSPECTING BY OPENING THE ENGINE HOOD AND COVERS**

1. Check for any twigs, leaves, oil or other combustible materials around the engine and battery.
2. Check for leakage of oil, fuel, DEF/ AdBlue® or engine coolant around the engine.



### **INSPECTING BY WALKING AROUND THE MACHINE**

3. Check for oil leakage from the hydraulic oil tank, hydraulic devices, hoses or connections.
4. Check lights for dirt, damage and burnt out bulbs.
5. Check the hoses for damage.
6. Check the dump body, cylinders and pins for wear, damage and looseness
7. Check the handrail, the steps and the slip-resistant surfaces for damage and loose bolts.
8. Check the tracks, carrier rollers, track rollers, idlers and sprockets for damage, wear and loose bolts.
9. Check for oil leakage from the travel motor, carrier rollers, track rollers and idlers.
10. Check the cab and the guard for damage and the bolts and the nuts for looseness or damage.
11. Check the rear view mirrors and room mirror for dirt, damage and angle adjustment.
12. Check the labels for dirt and damage.

### **INSPECTING WHILE SITTING IN THE OPERATOR'S SEAT**

13. Check the windshield for dirt or damage.
14. Check the seat and seat belt for dirt or damage.  
Check the operator's seat for dirt, oil or other combustible materials.
15. Check the monitor, instruments and switches for dirt or damage.



## DAILY INSPECTION (EVERY 10 HOURS)

Perform the following inspections every day before starting the engine for the first time.

### WARNING

- Before operating, perform the daily inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.


## INSPECTING AND REPLENISHING THE COOLANT

### WARNING

- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the radiator cool before slowly loosening the radiator cap and the drain plug to remove them.
- Always wear the protective goggle and gloves when handling coolant (antifreeze). If any coolant (antifreeze) comes in contact with eyes or skin, wash it off with clean water. Otherwise, it could result in injuries.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.

- Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or covers open on a windy day or if the machine is parked on a slope.

### Inspection



1. Open the engine hood and the battery cover.
2. Inspect the cooling water level in the reserve tank (1).  
The level should be between the upper limit (H) and the lower limit (L).  
If it is below the lower limit (L), replenish.

### Replenishing

1. Remove the cap (2) of the reserve tank (1).
2. Add cooling water up to the upper limit (H) of the reserve tank (1).  
If the reserve tank (1) is found empty at the inspection, check for water leakage and then the water level in the radiator (3). Add water to the radiator (3) as required, and then to the reserve tank (1).
3. Install the cap (2).

**Note:** Use only clean water (soft water) to replenish the cooling water loss due to evaporation. Use coolant (antifreeze) and clean water (soft water) of the specified mixing ratio to replenish the cooling water loss due to leaking.



## INSPECTING AND REPLENISHING THE ENGINE OIL

### **WARNING**



- Stop the engine and allow each part of the machine to cool down before performing maintenance.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.
- Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or covers open on a windy day or if the machine is parked on a slope.

1. Open the engine hood.
2. Take out the dipstick (1) and wipe the oil off with a rag.
3. Fully reinsert the dipstick (1), and then pull it back out.
4. Check the oil on the dipstick (1).  
The level should be between the upper limit (H) and the lower limit (L).  
If it is below the lower limit (L), replenish.

### Replenishing


1. Remove the oil filler cap (2).
2. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1).  
Problems could arise if the oil level is either too low or too high.
3. Tighten the oil filler cap (2).
4. Start the engine, run it at low idle for about 5 minutes, then stop it.
5. After about 15 minutes, inspect the oil level.

### Inspection



**INSPECTING THE WATER SEPARATOR****⚠ WARNING**

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.




1. Turn the ignition switch to the ON position.
2. Inspect the water separator warning lamp.
3. If the warning lamp is flashing, drain the water.

Refer to “Draining the water from the water separator” on page 5-60.

**INSPECTING THE FUEL LEVEL****⚠ WARNING**

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.



1. Check the fuel level using the fuel gauge (1).  
F: Tank is full.  
E: Tank is empty.
2. If the level is low, add fuel from the fuel filler port (3) while watching the sight gauge (2).  
Refer to “Fuel filler port” on page 2-4.





## INSPECTING THE HYDRAULIC OIL TANK LEVEL AND REPLENISHING

### **WARNING**


- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
  - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.

- When the oil temperature is about 20°C (68°F):  
The level should be between the middle (M) and the lower limit (L).  
(When the dump body is lowered, the oil level rises to the “M”.)  
If it is below the lower limit (L), replenish.
- When the oil temperature is about 50 to 80°C (122 to 176°F):  
The level should be around the middle (M).  
(When the dump body is lowered, the oil level rises to the middle point between the “M” and “H”.)

### Inspection

The oil level changes with the oil temperature. Inspect the oil by maintaining the machine at posture shown in the figure at the next.


- Machine configuration for inspecting the hydraulic oil level



1. Start the engine and run it at low speed.
2. Swing the dump body to the right by 90°.
3. Fully raise the dump body.
4. Raise the safety lock lever to the lock position and stop the engine.
5. Engage the dump body prop to the dump body.
6. Inspect the oil level using the sight gauge (1).



## Replenishing




**IMPORTANT:** Do not fill up to the level higher than the middle point between the middle (M) and the lower limit (L). Doing so will damage the hydraulic circuits or result in oil spurting. If excessively added, stop the engine, wait for the hydraulic oil to cool and let the excessive oil drain from the drain plug.

7. Loosen the bolts and remove the cover (4).
8. Remove the air breather (2).
9. Add the hydraulic oil up to the middle point between the middle (M) and the lower limit (L) of the sight gauge (1) through the hole in the air breather (2).
10. Tighten the air breather (2).
11. Install the cover (4).



## LUBRICATING THE DUMP BODY AND TRACK ROLLERS



1. Set the machine configuration for lubrication as shown in the diagram above, and then stop the engine.
2. Use the grease gun to lubricate the grease fitting.
3. Wipe off the excess grease.



## CHECKING THE DEF/ADBLUE® LEVEL AND REFILLING

### **WARNING**

- When removing the cap from the DEF/AdBlue® tank, take care not to inhale steam.
- Do not put anything else other than DEF/AdBlue® solution in the DEF/AdBlue® tank. Putting liquids, particularly light oil or gasoline, in the tank could cause a fire or damage the SCR system. If this is accidentally done, contact a Takeuchi service dealer.

### **CAUTION**


- DEF/AdBlue® is a colorless, transparent, odorless and non-hazardous aqueous solution (32.5% urea, 67.5% water, freezes at  $-11^{\circ}\text{C}$ ), and is harmless to the human body. In very rare cases, however, inflammation could occur in some people, and thus proper actions should be taken as follows.
- If skin contact occurs, flush with water. If there are changes in the skin condition or if there is pain, immediately seek medical attention.
- If accidentally swallowed, drink one or two glasses of water or milk and immediately seek medical attention.
- If eye contact occurs, immediately flush with a large amount of clean water and seek medical attention.

### IMPORTANT:

- Do not use expired DEF/AdBlue® solution (including solution left in the tank) stored for a long period. Doing so could cause ammonia slip, degraded NOx conversion efficiency or device damage.
- When handling DEF/AdBlue®, do not use anything such as cotton work-gloves whose fibers could get into the solution. Doing so could cause clogging of the DEF/AdBlue® filter or urea deposit at the DM injection port.
- When refilling, be sure to use DEF/AdBlue® conforming to ISO 22241. Do not dilute it or mix it with other chemicals.
- When removing the cap from the DEF/AdBlue® tank, take care not to allow any soil or dirt to enter the tank. Otherwise, the SCR system could fail.
- Do not overfill the tank with DEF/AdBlue® or top off the tank while the engine is running. Doing so could cause the solution to leak from the breather and to freeze. The frozen solution could damage the sensor.
- Do not stand on top of the DEF/AdBlue® tank or piping, and do not put things on them. Doing so could damage them.
- Wipe off any spill of DEF/AdBlue® and rinse it off with water.
- A dry white powder of DEF/AdBlue® may be deposited around the refill port. Wipe it off so that the powder does not enter the tank.
- If DEF/AdBlue® is added while the engine is running or the ignition switch is ON, it takes a long time for the level of the DEF/AdBlue® solution to reach the correct level.



### Checking the level



Use the DEF/AdBlue® level indicator (3) to check the amount of the DEF/AdBlue® solution remaining.

F: Tank is full.

E: Tank is empty.

### Refilling

1. Turn the ignition key to the OFF position to stop the engine.
2. Open the DEF/AdBlue® tank cover (1).
3. Turn the DEF/AdBlue® tank cap (2) counterclockwise and remove it.
4. Add DEF/AdBlue® until its level can be seen in the gauge (4).
5. Install the DEF/AdBlue® tank cap (2) on the filler port, and then turn the cap clockwise to close.
6. Close the DEF/AdBlue® tank cover (1).



**Notes:**

- If any solution other than DEF/AdBlue® is used, the warning lamp lights up and the buzzer sounds. Refer to “9.SCR system/ NCD warning lamp” on page 2-18.
- The engine speed is limited if the DEF/ AdBlue® solution is insufficient. Running the engine with insufficient DEF/AdBlue® causes the engine to idle.
- If the tank is faulty, please contact a Takeuchi service dealer for advice.

**When DEF/AdBlue® is low or the tank is empty:**

Corresponding to the DEF/AdBlue® level in the tank, the warning lamp lights up or flashes. Also, the engine output and RPM are limited.

To refill the tank under these conditions, refer to “Restarting when the DEF/AdBlue® level is low or the tank is empty” on page 6-11.




## AFTER THE INITIAL 50 HOURS (ONLY FOR NEW MACHINES)

### REPLACING THE HYDRAULIC OIL RETURN FILTER


#### WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine and the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
  - The hydraulic oil is also hot and under high pressure. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
  - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.

1. Start the engine and run it at low speed.
2. Fully raise the dump body.
3. Raise the safety lock lever to the lock position and stop the engine.
4. Engage the dump body prop to the dump body.



5. Loosen the bolts and remove the cover (4).
6. Remove the air breather (2).




7. Loosen the bolts and remove the cover (A).
8. Turn the filter (8) counterclockwise with the filter wrench and remove it.
9. Clean the surface to install the filter stand.
10. Apply a thin layer of oil on the packing of the new filter.
11. Install the new filter by hand.
12. Tighten 3/4 more turn after the filter packing comes in contact with the surface of installation.
13. Inspect the oil level with the sight gauge (1), and replenish if the level is too low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-21.
14. Install the air breather (2).



## REPLACING THE PILOT LINE FILTER

### WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine and the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
  - The hydraulic oil is also hot and under high pressure. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
  - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.



5. Loosen the bolts and remove the cover (4).
6. Turn the case (1) counterclockwise and remove it.
7. Remove the element (2) and O-ring (3).
8. Clean the inside of the case (1).
9. Coat the O-ring receiving groove on the new filter with a thin layer of oil.
10. Install the new element on the filter stand.
11. Coat the new O-ring (3) with a thin layer of oil.
12. Set the new O-ring (3), and then tighten the case (1) to the filter stand.  
Tightening torque:  $45 \pm 5 \text{ N}\cdot\text{m}$  ( $33.2 \pm 3.7 \text{ ft}\cdot\text{lb.}$ )
13. Inspect the level with the sight gauge and replenish if the level is low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-21.

1. Start the engine and run it at low speed.
2. Fully raise the dump body.
3. Raise the safety lock lever to the lock position and stop the engine.
4. Engage the dump body prop to the dump body.





## INSPECTING AND ADJUSTING THE FAN BELT


### **WARNING**

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.
- Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or covers open on a windy day or if the machine is parked on a slope.


**IMPORTANT:** The loose belts could result in bad battery charge, overheat of engine or early wear of belt. Too tight belts could damage the water pump or bearing and belt used to drive the alternator.

**IMPORTANT:** Do not let any oil or grease get on the belt.

### Inspection




1. Open the engine hood.



2. Press the fan belt (1) at the midpoint between the fan pulley (2) and alternator pulley (3) to check the tension (approx. 98 N or 22 lbf).  
The slack (A) should be 7 to 10 mm (0.27 to 0.4 in.).
3. Inspect the fan belt (1) and replace if it is as follows.
  - There are cuts or cracks.
  - The belt is worn and touches the bottom of the V groove in the pulley.
  - The belt stretched too loose to be adjusted.



## Adjustment



1. Loosen the bolts (5) and locking nuts (4).
2. Turn the adjustment bolt (6) to move the alternator (7) and to adjust the tension of the fan belt (1).
  - Tighten: Clockwise
  - Loosen: Counterclockwise
3. Tighten the bolts (5) and locking nuts (4).

**Note:** When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension.





## INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AIR CONDITIONER)

### WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.

**IMPORTANT:** Do not let any oil or grease get on the belt. It will cause the belt to slip, decrease the cooling capacity or shorten the service life of the air conditioner.

If the belt is too slack, it will slip and vibrate, resulting in decreased cooling capacity. The service life of the air conditioner also will be shortened. Adjust the belt tension to the standard value (approximately 8 mm or 0.3 in).



### Inspection

1. Loosen the bolts and remove the inspection cover (1).
2. Press on the center of the belt (2) with a finger. The belt tension is normal if the slack in the belt is 8 mm (0.31 in.) when pressed with a force of 98 N (22 lbf).



### **Adjustment**

If the belt tension is not normal, adjust it with the adjuster bolt (3).

1. Loosen the locking nut (4).
2. Turn the adjuster bolt (3) as follows.
  - Tighten: Clockwise
  - Loosen: Counterclockwise
3. Tighten the locking nut (4) after adjustment.

**Note:** When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension again.

### **Replacing**

Replace the belt in the following cases:

- There are cuts or cracks.
- The belt is worn and touches the bottom of the V groove in the pulley.
- The belt stretched too loose to be adjusted.



## EVERY 50 HOURS

### INSPECTING THE TRACK TENSION

#### **WARNING**


If maintenance must be performed with the engine running, always work as a two person team communicating each other.

- One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
- The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.

This machine uses a hydraulic cylinder to adjust the tension of the tracks. It is not necessary to regularly perform adjustments of the tension of the track.

If the tension is too loose and the track comes off after the engine start-up, the hydraulic cylinder is likely faulty. Ask your sales or service dealer for repairs.

#### Inspection



1. Move the machine to a flat, rigid and safe ground.
2. Move the machine forward and backward two or three times.
3. Travel in reverse so that the slack in the track is on the upper side.
4. Place straight bars on the track on the sprocket side and idler side with the carrier roller at the center.

- Each slack of (A) and (B) should be 5 to 15 mm (0.2 to 0.6 in.).

#### Adjustment

If the amount of slack is too large, contact a Takeuchi sales or service outlet for repairs.



## INSPECTING THE BATTERY FLUID LEVEL AND REPLENISHING



### DANGER

- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- Use a dampened cloth to clean above the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it can cause static electricity to build up, resulting in ignition or explosion.
- Do not use the cable if it's connecting terminal is loose or corroded. If used, ignition or explosion may occur.
- Do not block the exhaust hole of the battery. An explosion could result, if blocked.



### WARNING

- Wear protective goggle and clothing when working with batteries.
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Batteries contain sulfuric acid which will damage eyes or skin if contacted.
  - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
  - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
  - If acid contacts skin or clothing, wash off immediately with a lot of water.
- Before performing maintenance on top of the work bench, clean the footing and observe the following precautions to


prevent falling.

- Do not spill oil or grease.
- Do not leave tools scattered around.
- Watch your step when walking.
- Never jump down from the machine or the work bench. When getting on or off the machine or work bench, use the steps, handrails or work bench to support your body. Your weight should be evenly distributed among the three contact points (one hand and two feet or two hands and one foot).


### Inspection

**IMPORTANT:** Check the fluid level of all cells following the steps below, even when the fluid level can be checked using the indicator.

**IMPORTANT:** The SCR system operates for up to 10 minutes after the ignition switch is turned to the OFF position. When removing the batteries or electrical connectors for inspection or maintenance, wait for at least 10 minutes after the ignition switch is turned to the OFF position. Otherwise, the system could fail.



1. Open the battery cover.
2. Inspect the indicator (1).
  - Blue: Good
  - White: Charging needed
  - Red: Insufficient battery fluid



### Replenishing

When adding distilled water, do so before starting operations in order to prevent freezing.

1. Remove the sealing plugs (2), and then add distilled water up to the highest level line (H).
2. Check that the indicator (1) turns blue.
3. Securely tighten the sealing plugs (2).

**Note:** For the replacement battery, a semi-sealed type is recommended.

3. Inspect the fluid level.  
The fluid level must be between the upper level (H) line and lower level (L) line. If not, add distilled water up to the line (H).
4. Check the battery terminal for looseness, dirt and corrosion.
5. Check the exhaust holes (4) for dirt.
6. Turn the ignition switch to ON and check the battery voltage on the display. The battery is normal if the voltage is 12 V or more.  
Refer to “(4) Data display” on page 2-28.




## **AFTER THE INITIAL 250 HOURS (ONLY FOR NEW MACHINES)**

### **REPLACING THE TRAVEL MOTOR GEAR OIL**

#### **⚠ WARNING**

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The travel motor is hot immediately after the engine is stopped. Touching it will cause burns.
  - The gear oil is also hot and under high pressure immediately after the engine is stopped.  
Be careful when loosening the plugs. Working on the machine under these conditions could result in burns or injuries.
- The pressure in the reduction gear case of travel motor may cause oil or the plug to fly out. Loosen the plug slowly to release the pressure.

**IMPORTANT:** If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.



1. Set the travel motor so that plug (1) is at the very bottom.
2. Place a pan under the plug (1).
3. Remove the plugs (1), (2) and (3), and drain the oil.

4. Rewrap the plugs with new sealing tape.
5. Tighten the plug (1).
  - Tightening torque:  $157 \pm 8$  N·m (115.7  $\pm$  5.8 ft-lb.)
6. Add oil through the hole of the plug (3) until oil flows out of the hole of the plug (2).
7. Tighten the plugs (2) and (3).
  - Tightening torque:  $157 \pm 8$  N·m (115.7  $\pm$  5.8 ft-lb.)





## **EVERY 250 HOURS**

### **INSPECTING AND ADJUSTING THE FAN BELT**

Refer to “Inspecting and adjusting the fan belt” on page 5-29.

### **INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AIR CONDITIONER)**

Refer to “Inspecting and adjusting the compressor belt (Air conditioner)” on page 5-31.




## DRAINING THE WATER FROM THE FUEL TANK

### WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.

Do the draining operation before starting the machine.



1. Remove the fuel filler cap (2).
2. Connect the hose to the drain valve (3).

3. Place a pan under the end of the hose just connected.
4. Open the drain valve (3) and drain the water and sediment buildup in the bottom of the tank
5. Close the drain valve (3) and disconnect the hose.
6. Add fuel while watching the sight gauge (1).
7. Tighten the fuel filler cap (2) and lock it with the key.
8. Bleed air.

### Bleeding air from the fuel system

Refer to "Bleeding air from the fuel system" on page 6-10.

**Note:** Air in the fuel system causes the engine to fail to start or to have problems. Bleed air when the fuel tank is emptied, using the same procedure above.



## CLEANING THE AIR CLEANER


### **WARNING**

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching it will cause burns.
- Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


**IMPORTANT:** Be careful not to scratch the element. Do not use an element if it is damaged.

**IMPORTANT:** When operating the machine in very dusty places, perform inspection and maintenance operations every day.


**IMPORTANT:** Be sure to install the element and dust cap securely. If not, dust could be drawn into the cylinder, damaging the engine.



1. Open the side cover.



2. Loosen the clamps (1) and remove the dust cap (2).
3. Clean the inside of the dust cap (2).
4. Remove the primary element (3).  
To prevent dirt from getting inside the engine, do not remove or clean the secondary element (5) except for replacing.
5. Clean the inside of the body (4).



6. Clean the primary element (3) with dried compressed air (294 to 490 kPa or 43 to 71 psi).  
First blow the air from the inside of the element along the pleats. Then blow the air from the outside and finally from the inside again.
7. Light up the inside of the primary element (3) with a light bulb, inspect it, and replace it if there are small holes or thin spots.
8. Install the primary element (3).
9. Install the dust cup (2) with its “**↑ TOP ↑**” mark facing up, and then fasten it with the clamps (1).



## CLEANING THE RADIATOR FINS AND THE OIL COOLER FINS

### WARNING


Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

**IMPORTANT:** Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200 kPa (28 psi) and hold the nozzle sufficiently away from the fins.

**IMPORTANT:** When using water, cover the electrical system to prevent water from getting in.

**IMPORTANT:** When operating the machine in very dusty places, perform inspection and maintenance operations every day.



1. Blow compressed air on the fins to remove mud and dirt stuck on them.


## CLEANING THE CONDENSER (AIR CONDITIONER)

### WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

**IMPORTANT:** Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200 kPa (28 psi) and hold the nozzle sufficiently away from the fins.



1. Loosen the bolts and remove the under cover (1).
2. Clean the condenser (2).

**Note:** If the condenser is dirty, heat will not discharge properly and the air conditioner will not work efficiently.




## CLEANING THE AIR FILTERS (AIR CONDITIONER/HEATER)

### WARNING


Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

Clean the filters immediately after operating in dusty places.  
If the filters are clogged, the air flow is reduced and a booming sound is heard from the air conditioner unit.

### Removing the filters



1. Slide the seat fully forward, and then fold the backrest forward.
2. Loosen the knobs and remove the cover (1).
3. Remove the circulation filter (2).  
Circulation filter (2): Part No. 19115-06736



4. Loosen the bolts and remove the cover (3).

5. Remove the ventilation filter (4).  
Ventilation filter (4): Part No. 08714-61536

### Cleaning

1. Blow dry, compressed air (138 kPa or 20 psi or less) directly on the filters from the inside, moving up and down along the pleats.  
Be sure to keep the nozzle at an adequate distance from the filters.
2. Wash the filter with neutral detergent if it is very dirty. Dry the filter completely after washing it.




## INSPECTING THE REFRIGERANT (GAS) LEVEL (AIR CONDITIONER)

### WARNING

- Exposure of the eyes or hands to the cooler's refrigerant could result in blindness or frostbite. Never touch the refrigerant or loosen the parts of the cooling circuit.
- Keep flames away if the refrigerant gas is leaking.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.
- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.


The cooling capacity decreases if the amount of refrigerant is insufficient. Inspect the refrigerant level using the sight glass (1) on the top of the receiver drier.



1. Inspect the places for the conditions below.

Places for inspection	Conditions
Cab door	Fully open
Temperature control dial	Set fully to the COOL side
Fan speed	High
Engine speed	Maximum speed
Air conditioner switch	ON





2. Open the battery cover.
3. Inspect the refrigerant by watching the flow of air bubbles through the sight glass (1). Refer to "Check list for refrigerant volume" on page 5-44.



4. Open the inspection cover.
5. Check the temperature of the compressor's high pressure pipe (2) and low pressure pipe (3). Refer to "Check list for refrigerant volume" on page 5-44.



**Check list for refrigerant volume**

Air conditioner	Normal	Abnormal		
<b>High/low pressure pipe temperature</b>	High pressure pipe is hot (80 to 120°C or 176 to 248°F), low pressure pipe is cold (8 to 15°C or 46 to 59°F). Clear difference in temperature between the pipes.	High pressure pipe is warm, low pressure pipe is slightly cool. No significant difference in temperature between the pipes.	Little difference in temperature between the high-pressure pipe and the low-pressure pipe.	High pressure pipe is hot, low pressure pipe is slightly cool. A significant difference in temperature between the pipes.
<b>Pipe connection</b>	Normal	Some places are dirty with oil.	Some places are extremely dirty with oil.	Normal
<b>Sight glass</b>	 <p style="text-align: center;">AG7G064</p> <p>Almost transparent with some bubbles. Fully transparent when the engine speed is increased or decreased.</p>	 <p style="text-align: center;">AG7G065</p> <p>Flow of bubbles can be seen constantly. Sometimes transparent or white with bubbles.</p>	 <p style="text-align: center;">AG7G066</p> <p>Mist-like flow is faintly visible.</p>	 <p style="text-align: center;">AG7G067</p> <p>No bubbles are visible, even when the fan is set to High and the engine is idling.</p>
<b>Refrigerant level</b>	Proper level	Refrigerant may be leaking.	Refrigerant has leaked; little is left.	Refrigerant level too high

**If the air conditioner is not working**

If the air conditioner does not work well, set the fan switch to OFF and contact your sales or service dealer for inspection and/or repairs.

**IMPORTANT:** Continued use of the air conditioner when it is not working properly will damage its various parts.

**IMPORTANT:** Using the air conditioner when there is no refrigerant will damage the compressor.

**IMPORTANT:** Always consult your sales or service dealer for replacing the refrigerant. Be sure to use R134a refrigerant (1720 g or 3.8 lb)..






## LUBRICATING THE SWING BEARING


### **WARNING**

Do not swing while lubricating. Doing so is dangerous, as you may get caught in the machine.


5. Repeat the step 2 above.
6. Start the engine, swing the dump body 180° counterclockwise.
7. Stop the engine.
8. Repeat the step 2 above.
9. Wipe off the excess grease expelled from the swing bearing and grease fitting.



1. Stop the engine with the machine set as shown on the figure above.



2. Use the grease gun to lubricate the grease fitting (1).



3. Start the engine, swing the dump body 90° clockwise.
4. Stop the engine.



## **EVERY 500 HOURS**

### **REPLACING THE PILOT LINE FILTER**

Refer to “Replacing the pilot line filter” on page 5-28.

### **REPLACING THE ENGINE OIL AND THE OIL FILTER**




#### **WARNING**


- Stop the engine and allow the machine to cool down before performing maintenance.
    - The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
    - The engine oil is also hot. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries.
  - Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
    - Do not spill oil or grease.
    - Do not leave tools scattered around.
    - Watch your step when walking.
  - Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.
  - Be sure to secure the engine hood or covers when they are left open. Do not leave the engine hood or covers open on a windy day or if the machine is parked on a slope.
-



## Engine oil



1. Open the engine hood.
2. Remove the oil filler cap (2).




3. Loosen the bolts and remove the under cover (4).
4. Place a pan for catching the waste oil under the drain plug (3).
5. Remove the cap (A), install connector (B) and drain the oil. (The oil comes out when the screw is tightened.)
6. Remove the connector (B) and install the cap (A).

**IMPORTANT: Check the waste oil for metal powder. If it contains large amounts of metal powder, consult your sales or service dealer.**

7. Install the under cover (4).

## Engine oil filter



8. Loosen the bolts and remove the under cover (6).
9. Turn the filter (5) counterclockwise with the filter wrench and remove it.
10. Clean the surface of installation of the filter stand.
11. Apply a thin layer of oil on the packing of the new filter.
12. Install the new filter by hand.
13. Tighten one more turn (with the filter wrench) after the filter packing comes in contact with the surface of installation. (Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17 ft·lb.)
14. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1). Problems could arise if the oil level is either too low or too high. It takes around 10 to 20 minutes for all of the added oil to go down to the oil pan.
15. Tighten the oil filler cap (2).
16. Start the engine, run it at low idle for about 5 minutes, then stop it.
17. After about 10 minutes, inspect the oil level.


**Note:** Change the engine oil and oil filter even if the running time is less than 500 hours after a year's time of operation. Or, change the engine oil and oil filter if the running time reaches 500 hours within a year's time of operation.



## REPLACING THE FUEL FILTER

### **WARNING**

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.




1. Open the side cover.
2. Turn the filter (1) counterclockwise with the filter wrench and remove it.
3. Clean the surface of installation of the filter stand.
4. Apply a thin layer of oil on the packing of the new filter.
5. Install the new filter by hand.
6. Tighten one more turn after the filter packing comes in contact with the surface of installation. (Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17ft·lb.)
7. Bleed the air.  
Refer to “Bleeding air from the fuel system” on page 6-10.



## REPLACING THE WATER SEPARATOR FILTER

### WARNING


- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.




(S): Close

1. Open the side cover.
2. Close the valve (2) of the water separator (1).
3. Place a pan for catching fuel under the drain hose.
4. Loosen the air-bleeding plug (8) and the drain plug (7) to discharge fuel from inside.
5. Remove the sensor wiring coupler (3).
6. Remove the case (4) with the filter wrench.
7. Remove the element (5), and then clean the case. When doing the above, be careful not to damage the sensor.
8. Replace the packing with a new one and lubricate it with diesel fuel.
9. Install the new element (5) on the filter stand.
10. Tighten the case (4) by hand. Be sure to do it by hand.  
Tightening torque: 27 to 33 N·m (20 to 24.6 ft·lb)
11. Install the sensor wiring coupler (3).
12. Tighten the drain plug (7).
13. Bleed air.  
Refer to "Bleeding air from the fuel system" on page 6-10.

## INSPECTING THE SLEW PINION GEAR



1. Fully raise the dump body.



2. Remove the cap (2).
3. Make sure that the gear tooth surface of the slew bearing is well greased. If the surface is not adequately greased, add grease. If the grease has turned white due to water or mud entered it, replace the whole grease. Consult your sales or service dealer for help.  
Grease full capacity: 10 L (2.6 US gal) or 9.0 kg (20 lbs.)
4. Install the cap (2).



## REPLACING THE AIR CLEANER ELEMENT



### WARNING

Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.

**IMPORTANT:** Do not use an element if its pleats, gaskets or seals are damaged.  
**IMPORTANT:** Be sure to install the element and dust cap securely. If not, dust could be drawn into the cylinder, damaging the engine.

1. Open the side cover.



2. Loosen the clamps (1) and remove the dust cup (2).
3. Clean the inside of the dust cup (2).
4. Remove the primary element (3).
5. Clean the inside of the body (4).
6. Remove the secondary element (5).
7. Install the new elements.
8. Install the dust cup (2) with its "↑ TOP ↑" mark facing up, and then fasten it with the clamps (1).



## **EVERY 1000 HOURS**

### **REPLACING THE HYDRAULIC OIL RETURN FILTER**

Refer to “Replacing the hydraulic oil return filter” on page 5-27.

### **REPLACING THE TRAVEL MOTOR GEAR OIL**

Refer to “Replacing the travel motor gear oil” on page 5-36.




## REPLACING THE HYDRAULIC OIL AND CLEANING THE SUCTION STRAINER


### WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine and the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
  - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped.
- Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
  - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.


1. Start the engine and run it at low speed.
2. Fully raise the dump body.
3. Raise the safety lock lever to the lock position and stop the engine.
4. Engage the dump body prop to the dump body.



5. Loosen the bolts and remove the cover (4).
6. Remove the air breather (2).



7. Place a pan for catching the waste oil under the drain plug (5).
8. Loosen the drain plug (5) and drain the hydraulic oil.



9. Loosen the bolts and remove the flange (6).






10. Remove the suction strainer (7) and clean it.
11. Clean the inside of the hydraulic oil tank.
12. Install the suction strainer (7) and the flange (6).
13. Tighten the drain plug (5).
14. Replace the pilot line filter.  
Refer to “Replacing the pilot line filter” on page 5-28.
15. Replace the hydraulic oil return filter.  
Refer to “Replacing the hydraulic oil return filter” on page 5-27.
16. Add hydraulic oil from the hole of air breather (2) up to the level between the middle (M) and the lower limit (L) in the sight gauge (1).
17. Tighten the air breather (2).
18. Bleed air from the hydraulic oil circuit by following “Bleeding air” below.
19. Install the cover (4).
20. Set the machine configuration for inspecting the hydraulic oil level and inspect the oil level after the oil cools.  
Refer to “Inspecting the hydraulic oil tank level and replenishing” on page 5-21.

### **Bleeding the air**

**IMPORTANT: After replacing the hydraulic oil or hydraulic devices, or after performing maintenance of the hydraulic devices, bleed air from the hydraulic circuits and hydraulic devices. Failure to do so may damage the hydraulic devices.**

### **• Hydraulic pump**



1. Loosen the vent plugs (9) on the hydraulic pump.
2. Tighten the plugs (9) once the hydraulic oil overflows from the hole of the vent plugs (9).

### **• Cylinders**

3. Disengage the dump body prop on the dump body.  
Refer to “Dump body prop” on page 2-8.
4. Start the engine and let it run at a low-idling speed for 10 minutes.
5. Maintain the engine at low idle, and then extend and retract the dump cylinders 4 or 5 times, without letting them reach the stroke end.
6. Run the engine at high speed, and then extend and retract the dump cylinders 4 or 5 times, without let them reach the stroke end.
7. Return the engine speed to low idle, and then extend and retract the dump cylinders 4 or 5 times to the stroke end.



MAINTENANCE  
**EVERY 1000 HOURS**

---

## **INSPECTING AND ADJUSTING THE ENGINE VALVE CLEARANCE**

This operation requires experience. Ask your sales or service dealer for it.

## **INSPECTING THE RADIATOR CAP**

This operation requires experience. Ask your sales or service dealer for it.



## **EVERY 1500 HOURS**

### **INSPECTING THE CRANKCASE BREATHER SYSTEM**

This operation requires experience. Ask your sales or service dealer for it.



## EVERY 2000 HOURS

### CLEANING THE ENGINE COOLING SYSTEM


Replace the coolant after the two-year operation even if the running time is less than 2000 hours.

#### WARNING


- Stop the engine and allow the machine to cool down before performing maintenance.
  - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
  - The engine coolant is also hot and under high pressure immediately after the engine is stopped. Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot coolant spurting out.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
  - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
  - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- Standing at the back of the machine while the engine is running is extremely dangerous, as the machine could move suddenly. Never stand at the back of the machine while the engine is running.
- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap and the drain plug to remove them.

- Before performing maintenance on the top of the machine, clean the place you will work on and observe the following to prevent falling.
  - Do not spill oil or grease.
  - Do not leave tools scattered around.
  - Watch your step when walking.
- Never jump down from the machine. Use the steps and handrails when climbing up and down the machine, and always support your body at three points with your hands and feet.

When cleaning, if the temperature of the coolant is low, the thermostat will be closed and the coolant will not circulate in the radiator. Heat the coolant water to at least 90°C (194°F) before cleaning.



1. Open the engine hood and the battery cover.
2. Gradually loosen the radiator cap (3) to release the internal pressure, and then remove the cap.



3. Loosen the bolts and remove the cover.
4. Place a pan for catching the waste coolant under the drain plug (4), and then loosen the drain plug (4) to drain the coolant.
5. Tighten the drain plug (4).
6. Add tap water to the radiator through the coolant fill port up to the top of the port. Take time and slowly add water, so that no air enters the radiator.
7. Close the radiator cap (3).
8. Start the engine and run it at a speed slightly above low idling. Raise the water temperature to at least 90°C (194°F), and then run the engine for about 10 minutes with the thermostat open.
9. Stop the engine, wait until the cooling water temperature becomes lower, and then remove the drain plug (4) to drain the water.
10. After draining, clean the cooling system using a cleaning agent. When using the cleaning agent, follow the instructions included with the agent.
11. Repeat the steps 3 to 8 to rinse the cooling system.
12. Tighten the drain plug (4).
13. Tighten the bolts and install the cover.
14. Take time and slowly add the new coolant (mixture of antifreeze and tap water) to the radiator through the fill port until it is full.
15. Close the radiator cap (3).
16. Warm up the engine. Use the meters to check that there are no irregularities in the cooling system at this time.
17. Increase the water temperature to at least 90°C (194°F). Then, run the engine for about 10 minutes with the thermostat open.
18. Stop the engine, wait until the cooling water temperature becomes lower, and then check the level of coolant in the radiator.  
If necessary, add cooling water until the radiator is full.
19. Close the radiator cap (3).
20. Clean the interior of the reserve tank (1), and then add coolant to the upper limit (H).
21. When the coolant has been replaced, inspect the coolant level once again after operating the machine.  
When the machine is operated, the coolant is distributed throughout the entire system, resulting in the lower coolant level.  
Add coolant up to the full level.



## **EVERY 3000 HOURS**

### **INSPECTING THE ECU AND RELATED SENSORS AND ACTUATORS**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING THE TURBOCHARGER (BLOW WASH AS NECESSARY)**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING THE DPF AND DOC**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING THE OPERATION OF THE AIR INTAKE THROTTLE VALVE**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING THE SCR CATALYST AND RELATED SENSORS AND ACTUATORS**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING AND REPLACING THE SUPPLY MODULE MAIN FILTER**

This operation requires experience. Ask your sales or service dealer for it.

### **INSPECTING AND CLEANING THE FUEL INJECTOR**

This operation requires experience. Ask your sales or service dealer for it.




## WHEN REQUIRED

### INSPECTING AND REPLENISHING THE WINDSHIELD WASHER FLUID

#### WARNING

Choose ethyl alcohol as washer solution. Do not use methyl alcohol as washer solution. It could damage the eyes.

Use a windshield washer fluid designed specifically for motor vehicles. Follow the instructions included with the washer fluid.



#### Inspection

1. Open the cab door.
2. Inspect the washer tank (1) and add washer fluid if the level is low.

#### Replenishing

1. Mix the washer fluid to the prescribed concentration.
2. Remove the cap (2) and add washer fluid. Keep the dust away while replenishing the washer fluid.
3. Install the cap (2).


## LUBRICATING THE LEVERS

#### WARNING

Set the machine to the parking posture, stop the engine, remove the ignition key and store it. Failure to do so may result in the machine moving abruptly, leading to serious injury or death.

If the levers no longer move smoothly, grease them.

#### Control levers




1. Remove the lower mount section of the boot (1) and turn it upward.
2. Wipe off the old grease.
3. Apply grease to points (A) and (B).
4. Set the boot (1) back as it was.



## DRAINING THE WATER FROM THE WATER SEPARATOR

### **WARNING**

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.



(S): Close

1. Open the side cover.
2. Place a pan under the drain valve (7) to catch fuel.
3. Open the drain valve (7) and drain the water.  
If the water does not drain easily, loosen the plug (8).
4. Close the drain valve (7) and tighten the plug (8).  
Refer to “Bleeding air from the fuel system” on page 6-10.

## INSPECTING AND CLEANING THE DPF SOOT FILTER

For the inspection and maintenance of the DPF soot filter or oxidation catalyst, follow the procedure below.

This operation requires experience. Ask your sales or service dealer for it.

- Do not modify the DPF without permission. If modified, it may be damaged or malfunction may occur. As a result, an expensive repair work may be required.
- Do not reuse the DPF that has been dropped to the ground. There is catalyst fitted inside the DPF. It can be damaged if strong shocks are applied to it.

### • Soot filter

Cleaning:

The soot filter must be cleaned if any of the error codes listed below appears. When cleaning becomes necessary, the ECM error warning lamp or the vehicle and engine emergency lamp starts flashing and an alarm is sounded.

Display the engine error code screen to check the SPN and FMI numbers.

Error code		Classi- fication	Description
SPN	FMI		
3719	7	Warning	DPF recovery regeneration inhibit
3719	9	Warning	DPF recovery regeneration failure
3720	0	Warning	DPF ash cleaning request 2
3720	16	Caution	DPF ash cleaning request 1
522573	0	Caution	DPF over accumulation
522574	0	Caution	DPF over accumulation

Replacement:

Replace every 9000 hours.

- Oxidation catalyst

Replacement:

Replace every 9000 hours.






## INSPECTING THE RUBBER TRACKS

Repair or replace the rubber tracks if their condition becomes as described below. Consult your sales or service dealer for repair or replacement.

### Rubber track


Replace the track if the entire track is stretched and cannot be adjusted.

#### (1) Lug



Replace if the height of (A) is 5 mm (0.2 in.) or below.


#### (2) Steel cord



Replace if the steel cord is exposed for two links or more.


Replace if the half or more of the steel cords on one side are cut.

#### (3) Metal core



Replace if even one metal core is off.

#### (4) Rubber



Repair if there are cracks of 60 mm (2.4 in.) or greater in length.

If the steel cord is visible, repair as soon as possible, regardless of the length of the crack.




## REPLACING THE RUBBER TRACKS

### WARNING


- If you must work under the raised machine or its components, always use the dump body prop, wood blocks, jack-stands or other rigid and stable supports to keep the machine or its components raised. Never get under the machine or its components if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.
- Stop the engine and allow each part of the machine to cool before performing maintenance.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
  - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
  - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- When disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- It is extremely dangerous to remove the tracks by not following the procedure below. If the tension of the rubber track cannot be loosened, Contact a Takeuchi service agent for advice.
- Take great care in handling rubber tracks, because they are very heavy.
- If you must work under the raised dump body, be sure to engage the dump body prop to prevent the dump body from dropping. Never position yourself under the dump body without making sure that it is securely supported.

**IMPORTANT:** Prepare two wrenches for removal and installation of hydraulic hoses. Use one of the wrenches for holding the hydraulic hose to prevent it from twisting.

### Removing



1. Start the engine and run it at low speed.
2. Fully raise the dump body.
3. Raise the safety lock lever to the lock position and stop the engine.
4. Engage the dump body prop to the dump body.



5. Change the connecting locations of the hydraulic hoses connected to the auto-tension valve (1).  
Changing the connecting locations of the hydraulic hoses allows the tension cylinder to be retracted and extended.
  - Right rubber track:  
Change the connecting locations between the hydraulic hoses (2) and (3).
  - Left rubber track:  
Change the connecting locations between the hydraulic hoses (4) and (5).



6. Start the engine, fully retract the tension cylinder and then stop the engine.
7. Jack up the machine so that a clearance can be created between the metal core protrusion of the rubber track and the track rollers, and then put wood bases or the like between the track frame on its lower side and ground.
8. Remove the rubber track from the idler side first, and then from the sprocket.

### **Installing**

1. Engage one side the rubber track with the sprocket, and place the side of the rubber track onto the idler.
2. Start the engine and turn the rubber track slowly while using a lever to install the rubber track onto the idler.
3. Stop the engine and confirm that the rubber track is fully engaged with the sprocket, the rollers and idler.
4. Referring to the step (5) on the previous page, change the connecting locations of the hydraulic hoses connected to the auto-tension valve (1), to return those to the original state before the removal of the rubber track.
5. Start the engine and check that the rubber track tension is sufficient.
6. Lower the machine to the ground.
7. Check the hydraulic hoses for oil leakage.



MAINTENANCE

**EVERY 2 YEARS**

---

## **EVERY 2 YEARS**

### **REPLACING THE RECEIVER DRYER**

This operation requires experience. Ask your sales or service dealer for it.



## MAINTENANCE DURING EXTENDED STORAGE PERIOD

### Storage procedures

If the machine is to be stored for 30 days or more, store it indoors. If it must be stored outdoors, park the machine on a surface laid with lumber on a flat ground, and place a waterproof cover over it so that it stays dry.

1. Clean the machine.
2. Inspect for oil leakage, water leakage, cracks and loose nuts and bolts.
3. Add fuel and replace the hydraulic oil and oil.
4. To prevent rusting and freezing, replace the engine coolant with long-life coolant (LLC).  
Refer to “Cleaning the engine cooling system” on page 5-56.
5. Use the grease gun to lubricate the grease fittings.
6. Fully retract the dump cylinders to lower the dump body completely.
7. Apply rust-inhibiting oil to the hydraulic cylinder rods.
8. Disconnect the negative cable from the battery and cover the battery to prevent freezing.

**IMPORTANT: The SCR system operates for up to 10 minutes after the ignition switch is turned to the OFF position. When removing the batteries or electrical connectors for inspection or maintenance, wait for at least 10 minutes after the ignition switch is turned to the OFF position. Otherwise, the system could fail.**

### During storage

#### **WARNING**

- Do not operate the machine in an enclosed area without adequate ventilation.
- If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.

1. To prevent rusting, operate the machine once a month so that the oil can be circulated throughout the system.
2. Inspect the battery and recharge it as necessary.  
Ask your sales or service dealer for recharging.

### Starting the machine after storage

**IMPORTANT: If the above “Storage procedures” have not been followed during the extended storage periods, consult your sales or service dealer before starting the machine again.**

1. Wipe off the rust-inhibiting oil that was applied on the piston rods of the hydraulic oil cylinders.
2. Add oil or grease as necessary.

### Returning the engine to service

1. Perform the daily checks.
2. The engine should be pre-oiled before startup.
  - a. Crank the engine, leaving the fuel system shut off so the engine will not start, for 15 seconds.
  - b. Then pause for 30 seconds.
  - c. Repeat the procedure until you have cranked the engine for a total of one minute. This will circulate the oil in the engine’s lubrication system.
3. Prime the fuel system.
4. Start the engine. Allow the engine to idle for approximately 15 minutes while you check for:
  - Proper oil pressure
  - Fuel, engine oil or coolant leaks
  - Proper operation of the indicators and/or gauges
5. Avoid prolonged operation at minimum or maximum engine speeds and loads for the remainder of the first hour of operation.



# TROUBLESHOOTING



## **SYMPTOMS THAT ARE NOT MALFUNCTIONS**

The symptoms listed below are not malfunctions.

- The swing motor produces noise at the beginning and end of the swing operation.
- The travel motor produces noise when suddenly stopped from its high speed traveling.
- The control valve produces noise if excessive force is applied to the dump body or when it moved to the stroke end.
- In some cases smoke may be emitted from the tail pipe while the DPF regeneration is being performed. This is not a failure; it is due to burning of the particulate matter (PM).
- In some cases the noise associated with the DPF regeneration operation or cancel operation may change; this is not a failure.






## IF THE ENGINE OVERHEATS

### WARNING

- Do not open the engine hood when steam is coming from it. The steam or hot water may spurt out and cause burns.
- Do not try to remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine, wait until the engine and the radiator cool, and then slowly loosen the radiator cap to release the internal pressure.
- Before performing maintenance, stop the engine and allow the machine to cool down.

The symptoms listed below indicate overheating.



- An alarm is sounded and the vehicle and engine emergency lamp and the coolant temperature warning lamp start flashing.
- The water temperature gauge level is in the red zone.
- Steam comes from the engine room.

### Remedy procedure

1. Park the machine in a safe place.
2. Check if steam is coming out of the closed engine hood.
3. If there is steam, stop the engine immediately and contact your sales or service dealer for repair. If steam is not coming out run the engine at low idle and let the water temperature cool down.
4. When the water temperature gauge level drops in the green zone, stop the engine.
5. Perform the inspections and the remedies listed below once the engine cools down.
  - Fan belt slack..... Adjust  
..... Refer to page 5-29.
  - Coolant level ..... Add  
..... Refer to page 5-18.
  - Water leakage..... Repair
  - Radiator fins..... Clean  
..... Refer to page 5-41.
  - Sediment in cooling system  
..... Clean  
..... Refer to page 5-56.

If the problem persists after the above remedies, contact your sales or service dealer for repair.



## IF THE BATTERY GOES DEAD

The symptoms below indicate that the battery is dead.

- The starter motor does not turn or fails to start the engine.
- The horn is too weak.

### Remedy procedure

Start the engine using the booster battery on the other vehicle (booster vehicle) and the jumper cables.

### **WARNING**

- When starting the engine using the jumper cables, be sure to connect the cables by following the proper steps. Improper use of jumper cables can result in battery explosion or unexpected machine motion.
  - Do not allow the booster vehicle and the machine with a dead battery (dead machine) to touch each other.
  - Do not allow the positive (+) and the negative (-) clips of the jumper cables to touch each other.
  - When connecting, attach the jumper cable to the positive (+) terminals first. When disconnecting, remove the cable from the negative (-) terminal (ground) first.
  - Connect the last clip of the jumper cable to a point as far away from the battery as possible.
- Always wear the protective goggle when jump starting the engine by using the jumper cables.


**IMPORTANT:** Use the jumper cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded jumper cables and clips.

**IMPORTANT:** Be sure that the battery of the booster vehicle has the same capacity as the battery of the dead machine.

**IMPORTANT:** Be sure to connect the clips securely.

### Connecting the jumper cables

**IMPORTANT:** Set the ignition keys of the booster vehicle and the dead machine to the OFF position.



1. Connect the clip of jumper cable (R) to the positive (+) battery terminal of the dead machine.
2. Connect the other clip of jumper cable (R) to the positive (+) battery terminal of the booster vehicle.
3. Connect the clip of jumper cable (B) to the negative (-) battery terminal of the booster vehicle.
4. Connect the other clip of jumper cable (B) to the engine block of the dead machine. Connect the clip to a place as far from the battery as possible.

### Starting the engine


1. Check that the clips are securely connected to the terminals.
2. Start the engine of the booster vehicle and run it at high speed.
3. Start the engine of the dead machine.



## TROUBLESHOOTING IF THE BATTERY GOES DEAD

### Disconnecting the jumper cables

Once the dead machine is successfully running, remove the jumper cables by following the same steps as for connection in the reverse order.



1. Disconnect the clip of jumper cable (B) from the engine block of the dead machine.
2. Disconnect the other clip of jumper cable (B) from the negative (-) battery terminal of the booster vehicle.
3. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the booster vehicle.
4. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the dead machine.

### Recharging

Ask your sales or service dealer for recharging the dead battery.



## IF A FUSE BLOWS


If a light does not come on or the electrical system does not work, a fuse may be blown. Inspect the fuses.

### INSPECTING AND REPLACING THE FUSE


#### **WARNING**

If the fuse blows again soon after replacement, then the electric system is likely faulty. It may pose a fire hazard if not properly repaired. Contact your sales or service dealer for advice.

1. Turn the ignition key to the OFF position to stop the engine.



2. Open the battery cover.
3. Open the fuse box cover (1).
4. Check for any blown fuses (2).




5. If a fuse is blown, replace it with a spare fuse of the same capacity.

# MEMO

---














### Fuse layout and circuits protected



AAA0J003



## TROUBLESHOOTING IF A FUSE BLOWS

No.	Capacity	Symbol	Protected circuit	Fuse No.
1	25A		Lights	F1
2	15A		Cab interior power supply	F2
3	15A		Safety lock lever	F3
4	15A		Travel alarm	F4
5	60A	S.B.F.1	Fusible link (1)	-
6	40A	S.B.F.2	Fusible link (2)	-
7	30A	S.B.F.3	Fusible link (3)	-
8	60A	S.B.F.4	Fusible link (4)	-
9	40A	S.B.F.5	Fusible link (5)	-
10	40A	S.B.F.6	Fusible link (6)	-
11	20A	OPT	Option	F5
12	5A		Switch lighting	F6
13	10A		Horn	F7
14	15A		Ignition switch	F8
15	25A		ECU	F9
16	25A		SCR system	F10
17	25A		DEF heater	F11
18	15A		NOx sensor	F12




## RESTARTING AFTER ADDING FUEL


### BLEEDING AIR FROM THE FUEL SYSTEM

**IMPORTANT:** NEVER use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion gear and/or ring gear.

**IMPORTANT:** If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.




1. Add fuel.



(S): Close

2. Open the side cover.
3. Open the valve (2) of the water separator.



4. Turn the ignition key to the ON position and hold it for about 60 seconds. The automatic air bleeder bleeds air from the fuel system.
5. Start the engine and check for fuel leakage.

**Note:** Air in the fuel system causes the engine to fail to start or to have other problems. Always bleed air when the fuel tank is emptied or when there is air in the fuel system.










## **RESTARTING WHEN THE DEF/ ADBLUE® LEVEL IS LOW OR THE TANK IS EMPTY**

1. Turn the ignition switch to the OFF position.
2. Add at least 5 liters (1.3 US gal.) of DEF/ AdBlue®.
3. Turn the ignition switch to the ON position and wait for the warning lamp to go out.
4. Start the engine when the warning lamp goes out.
5. If the warning lamp does not go out, turn the ignition switch to the OFF position.










## IF A WARNING LAMP FLASHES

If an alarm is sounded or a warning lamp starts flashing during operation, park the machine in a safe place and perform the remedy procedures described below.

Warning lamp	Lamp name	Causes and remedies
 AW4J007	<b>Vehicle and engine emergency lamp</b>	<p>There is a problem in the machine. Refer to the respective warning lamp below. Get the vehicle or engine error code number from the multi-information display, and then consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list”. Refer to “Multi-information display” on page 2-16. Refer to “Vehicle error code list” on pages 6-14 and 6-15. Refer to “Engine error code list” on pages 6-16 to 6-27.</p>
 AW4J0041	<b>ECU error warning lamp</b>	<p>There is a problem in the engine. If an error code is displayed on the multi-information display, inform your sales or service dealer of the code and ask for help. Refer to “Multi-information display” on page 2-16. Refer to “Engine error code list” on pages 6-16 to 6-27.</p>
 AN4J005	<b>Engine stop request warning lamp</b>	
 AG7J019	<b>Battery charge warning lamp</b>	<p>There is a problem with the fan belt or charger.  Check the fan belt for slack or breakage and adjust as necessary. If the lamp continues flashing after maintenance, there is likely a problem with the charger. Consult your sales or service dealer for help. Refer to “Inspecting and adjusting the fan belt” on page 5-29.</p>
 AG7J017	<b>Engine oil pressure warning lamp</b>	<p>There is a problem in the engine lubrication system.  Check the engine oil level. If the lamp is flashing when the level is normal or even after replenishment of oil or coolant, consult your sales or service dealer. Refer to “Inspecting and replenishing the engine oil” on page 5-19.</p>



**TROUBLESHOOTING**  
**IF A WARNING LAMP FLASHES**

Warning lamp	Lamp name	Causes and remedies
 <small>AW4J009</small>	<b>Water separator warning lamp</b>	Water is in the water separator. Drain water. Refer to “Draining the water from the water separator” on page 5-60.
 <small>AG7J018</small>	<b>Coolant temperature warning lamp</b>	The coolant temperature is too high and the engine is overheating. Refer to “If the engine overheats” on page 6-3.
 <small>AG7J020</small>	<b>Air cleaner warning lamp</b>	The air cleaner is clogged. Clean it. Refer to “Cleaning the air cleaner” on page 5-39.
 <small>AW4J010</small>	<b>Fuel level warning lamp</b>	The fuel level is too low. Add fuel. Refer to “Inspecting the fuel level” on page 5-20.
 <small>AR0J004</small>	<b>SCR system warning lamp</b>	There is a problem in the SCR system. Contact a Takeuchi service dealer for advice. Refer to “Output limitation performed by inducement due to an abnormality detected in the SCR system” on page 6-39.
	<b>NCD warning lamp NCD: NOx Control Diagnostic system</b>	A problem is detected in the exhaust system. Get the engine error code number from the multi-information display and consult your sales or service dealer referring to the “Engine error code list”. Refer to “Multi-information display” on page 2-16. Refer to “Engine error code list” on page 6-16.
 <small>AU5J003</small>	<b>Pilot line filter warning lamp</b>	The hydraulic oil pilot line filter is clogged. Stop the engine and replace the filter immediately. Continuing to operate the machine while the lamp is flashing could damage the line filter and hydraulic equipment. Refer to “Replacing the pilot line filter” on page 5-28.  Cold climate operation: Hydraulic oil is not warmed up. Refer to “Warming up the machine (hydraulic oil)” on page 3-8.
 <small>AN4J008</small>	<b>DEF/AdBlue® level warning lamp</b>	The DEF/AdBlue® level is low. Make sure that there is no leakage, and then add the DEF/AdBlue® solution. Refer to “Checking the DEF/AdBlue® level and refilling” on page 5-24. Refer to “Output limitation performed by inducement due to decreased DEF/Adblue® tank level” on page 6-42.



## VEHICLE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

<b>Error code</b>	<b>Error details</b>
9	Impossible to sense ACC key
402	CAN 0 communication error
502	CAN communication error (EECU)
512	CAN communication error (DEF tank)
602	CAN communication error (cluster gauge)
612	CAN communication error (sub-controller)
712	CAN communication error (DCU)
822	CAN communication error (immobilizer)
1703	Main power supply voltage error (too high)
1704	Main power supply voltage error (too low)
1713	Sub-controller power supply voltage error (too high)
1714	Sub-controller power supply voltage error (too low)
2503	Sensor voltage error (too high) MMC
3370	Sensor voltage error (too low) MMC
2513	IOX sensor voltage error (too high) MMC
2514	IOX sensor voltage error (too low) MMC



TROUBLESHOOTING  
**VEHICLE ERROR CODE LIST**

---

<b>Error code</b>	<b>Error details</b>
3300	Alternator charge faulty
3370	Engine overspeeding
3401	Engine oil pressure error
3500	Overheat
3600	Air cleaner clogged
3700	Water separator alarm
3810	Line filter clogged
3820	Hydraulic oil temp. sensor error (too high)
3825	Hydraulic oil temp. sensor error (cable break)
5303	Accelerator sensor error (too high)
5304	Accelerator sensor error (too low)
5323	Foot accelerator sensor error (too high pressure)
5324	Foot accelerator sensor error (too low pressure)
5505	Fuel gauge resistance value error (cable break)
5913	RL pressure sensor error (too high)
5914	RL pressure sensor error (too low)
5923	RR pressure sensor error (too high)
5924	RR pressure sensor error (too low)
5933	FL pressure sensor error (too high)
5934	FL pressure sensor error (too low)
5943	FR pressure sensor error (too high)
5944	FR pressure sensor error (too low)
8095	Lever lock PWM output current error (low current)
8096	Lever lock PWM output current error (high current)

PWM = Pulse width modulation



## ENGINE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

Error code		Error details	DTC
SPN	FMI		
29	3	Accelerator sensor 3 error (voltage high)	P0228
	4	Accelerator sensor 3 error (voltage low)	P0227
51	3	Intake throttle position sensor error (voltage high)	P02E9
	4	Intake throttle position sensor error (voltage low)	P02E8
91	3	Accelerator sensor 1 error (voltage high)	P0123
	4	Accelerator sensor 1 error (voltage low)	P0122
100	1	Low oil pressure alarm	P1198
	4	Oil pressure switch disconnection	P1192
102	3	EGR low pressure side pressure sensor error (voltage high)	P0238
	4	EGR low pressure side pressure sensor error (voltage low)	P0237
	10	EGR low pressure side pressure sensor error (detected value error)	P1673
	13	EGR low pressure side pressure sensor error (abnormal learning value)	P0236
105	3	Intake manifold temperature sensor error (voltage high)	P040D
	4	Intake manifold temperature sensor error (voltage low)	P040C
	10	Intake manifold temperature sensor error (detected value error)	P1676
108	3	Atmospheric pressure sensor error (voltage high)	P2229
	4	Atmospheric pressure sensor error (voltage low)	P2228
	10	Atmospheric pressure sensor error (characteristic error)	P1231
110	0	Engine coolant temperature high (Overheat)	P0217
	3	Engine coolant temperature sensor error (voltage high)	P0118
	4	Engine coolant temperature sensor error (voltage low)	P0117
	10	Engine coolant temperature sensor error (detected value error)	P1674



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
157	0	Rail pressure too high	P0088
	3	Rail pressure sensor error (voltage high)	P0193
	4	Rail pressure sensor error (voltage low)	P0192
	18	Rail pressure deviation error (low rail pressure)	P0094
167	1	Charge alarm	P1568
	5	Charge switch disconnection	P1562
172	3	Ambient air temperature sensor error (voltage high)	P0113
	4	Ambient air temperature sensor error (voltage low)	P0112
	10	Ambient air temperature sensor error (detected value error)	P1678
	19	ECU system error (invalid ambient air temperature value is received)	P1555
173	3	Exhaust manifold temperature sensor error (voltage high)	P0546
	4	Exhaust manifold temperature sensor error (voltage low)	P0545
	10	Exhaust manifold temperature sensor error (detected value error)	P1677
174	0	Fuel temperature high	P0168
	3	Fuel temperature sensor error (voltage high)	P0183
	4	Fuel temperature sensor error (voltage low)	P0182
190	0	Overspeed	P0219
237	13	VI reception data error	U3002
	31	VI reception timeout	U0168
412	3	EGR gas temperature sensor error (voltage high)	P041D
	4	EGR gas temperature sensor error (voltage low)	P041C
	10	EGR gas temperature sensor error (detected value error)	P1675
587	2	Data verification error between ECU and DCU (engine model unmatched)	P1672
588	2	Data verification error between ECU and DCU (serial No. unmatched)	P264F
630	2	EEPROM error	P1601



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
633	3	SCV (MPROP) H/L side VB short circuit	P0629
	5	SCV (MPROP) H side GND short circuit/disconnection	P0627
	7	Drive circuit error (SCV sticking)	P2635
651	5	Injector (No. 1 cylinder) disconnection (injector-specific)	P0201
652	5	Injector (No. 2 cylinder) disconnection (injector-specific)	P0202
653	5	Injector (No. 3 cylinder) disconnection (injector-specific)	P0203
654	5	Injector (No. 4 cylinder) disconnection (injector-specific)	P0204
1202	2	Immobilizer error (system)	U0426
1209	3	EGR high pressure side pressure sensor error (voltage high)	P0473
	4	EGR high pressure side pressure sensor error (voltage low)	P0472
	13	EGR high pressure side pressure sensor error (abnormal learning value)	P0471
1347	0	Pump protection failure	P1235
	15	Pump replacement failure	P1236
1485	2	Power is turned off without self-hold	P068A
1761	1	Low aqueous urea tank level (Inducement 2)	P154A
	3	Aqueous urea tank level sensor (AT1T1I) internal circuit disconnection	P203D
	4	Aqueous urea tank level sensor (AT1T1I) internal circuit short circuit	P203C
	13	Aqueous urea tank level sensor (AT1T1I) controller internal failure	P155A
	15	Aqueous urea tank level sensor detected value error	P155B
	18	Low aqueous urea tank level (Inducement 1)	P1549
2791	0	EGR overvoltage error	P0404
	1	EGR low voltage error	P1404
	7	EGR feedback error	P1409
	9	EGR ECM data error	U0401
	12	Disconnection in EGR motor coils	P0403





TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
2797	3	Injector bank 1 +B short circuit	P2148
	5	Injector bank 1 disconnection	P2146
	6	Injector bank 1 GND short circuit	P2147
2798	3	Injector bank 2 +B short circuit	P2151
	5	Injector bank 2 disconnection	P2149
	6	Injector bank 2 GND short circuit	P2150
2950	3	Intake throttle drive circuit VB/GND short circuit	P1658
	5	Intake throttle drive circuit disconnection	P0660
	7	Intake throttle drive circuit deviation error	P1655
	8	Intake throttle drive circuit drive duty error	P1656
3031	0	Aqueous urea tank temperature rise error	P205B
	2	Aqueous urea tank temperature sensor/Aqueous urea tank level sensor (AT1T1I) controller temperature rise error	P1557
	3	Aqueous urea tank temperature sensor (AT1T1I) internal circuit disconnection	P205D
	4	Aqueous urea tank temperature sensor (AT1T1I) internal circuit short circuit	P205C
	13	Aqueous urea tank temperature sensor (AT1T1I) controller internal failure	P1556
	15	Aqueous urea tank temperature sensor detected value error (upper limit error)	P1539
3216	15	SCR upstream NOx sensor detected value error (upper limit error)	P1525
	17	SCR upstream NOx sensor detected value error (lower limit error)	P1526
3242	0	DPF inlet temperature sensor error (high temperature)	P1436
	3	DPF inlet temperature sensor error (voltage high)	P1428
	4	DPF inlet temperature sensor error (voltage low)	P1427



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
3250	0	DPF intermediate temperature sensor temperature rise error (post-injection failure)	P1426
	1	DPF intermediate temperature sensor temperature too low	P0420
	3	DPF intermediate temperature sensor error (voltage high)	P1434
	4	DPF intermediate temperature sensor error (voltage low)	P1435
3251	0	DPF differential pressure sensor differential pressure rise error	P2452
	3	DPF differential pressure sensor error (voltage high)	P2455
	4	DPF differential pressure sensor error (voltage low)	P2454
	13	DPF differential pressure sensor error (abnormal learning value)	P2453
3515	2	Aqueous urea quality sensor/Aqueous urea tank temperature sensor (A1DEFI) controller temperature rise error	P1559
	3	Aqueous urea tank temperature sensor (A1DEFI) internal circuit disconnection	P1551
	4	Aqueous urea tank temperature sensor (A1DEFI) internal circuit short circuit	P1552
	13	Aqueous urea tank temperature sensor (A1DEFI) controller internal failure	P1550
3516	0	Aqueous urea quality sensor concentration error (large deviation)	P154D
	1	Aqueous urea quality sensor concentration error (small deviation)	P154E
	3	Aqueous urea quality sensor (A1DEFI) internal circuit disconnection	P206D
	4	Aqueous urea quality sensor (A1DEFI) internal circuit short circuit	P206C
	13	Aqueous urea quality sensor (A1DEFI) controller internal failure	P154F
3521	13	Aqueous urea quality sensor contamination error in aqueous urea tank	P1558
3609	3	DPF high pressure side pressure sensor error (voltage high)	P1455
	4	DPF high pressure side pressure sensor error (voltage low)	P1454
3719	0	Backup mode	P1424
	7	Recovery regeneration is inhibited	P1446
	9	Regeneration failure (recovery regeneration failure)	P1445
	16	Stationary regeneration standby	P1421



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
3720	0	Ash cleaning request 2	P1420
	16	Ash cleaning request 1	P242F
4334	3	Supply module pump pressure sensor error (voltage high)	P204D
	4	Supply module pump pressure sensor error (voltage low)	P204C
	15	Supply module pump pressure sensor detected value error (upper limit error)	P153C
	17	Supply module pump pressure sensor detected value error (lower limit error)	P153D
4341	0	Aqueous urea hose heater (pressure) power stage temperature rise error	P1508
	3	Aqueous urea hose heater (pressure) L side VB short circuit	P20C0
	5	Aqueous urea hose heater (pressure) disconnection	P20BD
4343	0	Aqueous urea hose heater (back flow) power stage temperature rise error	P1507
	3	Aqueous urea hose heater (back flow) L side VB short circuit	P20BC
	5	Aqueous urea hose heater (back flow) disconnection	P20B9
4345	0	Aqueous urea hose heater (suction) power stage temperature rise error	P150A
	3	Aqueous urea hose heater (suction) L side VB short circuit	P20C4
	5	Aqueous urea hose heater (suction) disconnection	P20C1
4360	0	SCR catalyst upstream temperature sensor temperature rise error	P0426
	3	SCR catalyst upstream temperature sensor error (voltage high)	P0428
	4	SCR catalyst upstream temperature sensor error (voltage low)	P0427
	10	SCR catalyst upstream temperature sensor detected value error (at cold start check)	P1542
	15	SCR catalyst upstream temperature sensor detected value error (upper limit error)	P153B
	17	SCR catalyst upstream temperature sensor detected value error (lower limit error)	P1541



## TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
4375	0	Supply module (pump motor) power stage temperature rise error	P150D
	3	Supply module (pump motor) PWM signal wire VB short circuit	P208D
	4	Supply module (pump motor) PWM signal wire GND short circuit	P208C
	5	Supply module (pump motor) PWM signal wire disconnection	P208A
	7	Supply module (pump motor) pump motor drive error 2	P208B
	10	Supply module (pump motor) pump motor drive error 1	P151F
5137	0	Tank heating valve power stage temperature rise error	P150C
	4	Tank heating valve L side GND short circuit	P202B
	5	Tank heating valve disconnection	P202A
522243	5	Starting aid relay disconnection/VB short circuit	P0543
	6	Starting aid relay GND short circuit	P0541
522323	0	Air cleaner clogged alarm	P1101
522329	0	Water separator alarm	P1151
522400	2	Crankshaft signal error	P0336
	5	No signal from crankshaft	P0337
522401	2	Camshaft signal error	P0341
	5	No signal from camshaft	P0342
522573	0	Excessive PM accumulation (Method C)	P2463
522574	0	Excessive PM accumulation (Method P)	P1463
522575	7	Regeneration failure (stationary regeneration failure)	P2458
522577	11	Regeneration failure (stationary regeneration not performed)	P2459
522579	12	Short circuit in EGR motor coils	P1405
522580	12	EGR position sensor error	P0488
522581	7	EGR valve sticking error	P148A
522582	7	EGR initialization error	P049D



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
522583	1	EGR high temperature thermistor error	P1410
522584	1	EGR low temperature thermistor error	P1411
522596	9	TSC1 reception timeout (SA1)	U0292
522597	9	TSC1 reception timeout (SA2)	U1301
522599	9	Y_ECR1 reception timeout	U1292
522600	9	Y_EC reception timeout	U1293
522610	9	CAN reception timeout from the EGR valve	U010B
522617	12	Out of EGR target range	U1401
522618	9	EBC1 reception timeout	U1302
522619	9	Y_DPFIF reception timeout	U1303
522730	12	Immobilizer error (CAN communication)	U0167
522803	13	Pump learning not performed alarm	P1237
522993	12	CPU monitoring IC error	P0607
522994	12	CPU error	P0606
522995	12	QR data correction input error	P1630
522996	4	Low charge error	P0611
522997	3	Overcharge error	P0200
522998	12	Flash ROM error (checksum error)	P1602
523074	0	Sensor 5V circuit 1 error (voltage high)	P0653
	1	Sensor 5V circuit 1 error (voltage low)	P0652
523075	0	Sensor 5V circuit 2 error (voltage high)	P0699
	1	Sensor 5V circuit 2 error (voltage low)	P0698
523221	12	QR data not written	P1631
	13	QR data error	P1632
523249	5	Crankshaft/camshaft speed sensor non-input (simultaneous)	P0008
523513	9	CAN reception timeout DCU	U1501



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
523554	3	Supply module (reverting valve) H side VB short circuit	P2671
	4	Supply module (reverting valve) H side GND short circuit	P2670
523555	3	Hose heater relay/tank heating valve H side VB short circuit	P2686
	4	Hose heater relay/tank heating valve H side GND short circuit	P2685
523556	3	Supply module (supply module heater) H side VB short circuit	P26E9
	4	Supply module (supply module heater) H side GND short circuit	P26E8
	5	Supply module (supply module heater) disconnection	P20C5
	10	Supply module (supply module heater) detected value error	P20B6
523557	3	Aqueous urea hose heater (back flow, pressure, suction) H side VB short circuit/L side VB short circuit	P1510
	7	SCR system forced termination	P1506
523558	3	DCU supply voltage error (Voltage high 1)	P1512
	4	DCU supply voltage error (Voltage low 2)	P1513
523559	3	DCU supply voltage error (Voltage high 2)	P1514
	4	DCU supply voltage error (Voltage low 1)	P1511
523560	2	Main relay opens early	P20EA
	7	Main relay sticking	P20EB
523562	9	CAN reception timeout from SCR upstream NOx sensor	U029D
523563	9	CAN reception timeout from SCR downstream NOx sensor	U029E
523570	9	CAN reception timeout from ECU	U1607
523574	3	Supply 1 overvoltage error	P21CC
	4	Supply 1 low voltage error	P21CB
523576	12	Sensor supply voltage error	P1516
523577	12	SPI communication error 1	P1500
523578	12	SPI communication error 2	P1501
523579	12	AD converter error 1	P1502
523580	12	AD converter error 2	P1503



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
523581	0	DCU internal temperature rise error	P1504
523582	3	DCU internal temperature sensor error (voltage high)	P1517
	4	DCU internal temperature sensor error (voltage low)	P1519
523584	0	Dosing module power stage temperature rise error	P1505
523585	3	Dosing module L side VB short circuit	P151B
523586	3	Dosing module H side VB short circuit/disconnection	P2049
	4	Dosing module L side GND short circuit	P2048
	5	Dosing module H side GND short circuit	P2047
523588	7	Dosing module valve sticking	P208E
523589	12	EEPROM memory deletion error	P1600
523590	12	EEPROM memory reading error	P160E
523591	12	EEPROM memory writing error	P160F
523592	0	Hose heater relay power stage temperature rise error	P1509
	3	Hose heater relay L side VB short circuit	P21C4
	4	Hose heater relay L side GND short circuit	P21C3
	5	Hose heater relay disconnection	P21C2
523593	3	Supply module (supply module heater) L side VB short circuit	P20C8
523594	3	Tank heating valve L side VB short circuit	P202C
523595	0	SCR upstream NOx value rise error	P1545
	3	SCR upstream NOx sensor internal circuit short circuit	P2203
	5	SCR upstream NOx sensor internal circuit disconnection	P151C
523596	0	SCR downstream NOx value rise error	P1546
	3	SCR downstream NOx sensor internal circuit short circuit	P2216
	5	SCR downstream NOx sensor internal circuit disconnection	P151D
523597	7	SCR upstream NOx sensor incomplete heating error	P2209
523598	7	SCR downstream NOx sensor incomplete heating error	P2222



TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
523599	0	Supply module (reverting valve) power stage temperature rise error	P150E
523600	3	Supply module (reverting valve) L side VB short circuit	P20A3
	4	Supply module (reverting valve) L side GND short circuit	P20A2
	5	Supply module (reverting valve) disconnection	P20A0
523601	1	Inefficient NOx cleaning	P1520
523606	10	SCR downstream NOx sensor detected value error	P1524
523610	0	Supply module (supply module heater) power stage temperature rise error	P150B
	1	Supply module (supply module heater temperature sensor) detected value error	P152A
	10	Supply module (supply module heater temperature sensor) detected value error (at cold start check)	P1543
523611	1	Supply module (supply module temperature sensor) detected value error	P152B
	10	Supply module (supply module temperature sensor) detected value error (at cold start check)	P1544
523612	2	Supply module (supply module heater temperature sensor) fault value for temperature information duty value received	P152C
523613	2	Supply module (supply module heater temperature sensor) invalid value for temperature information duty value received	P152D
523614	8	Supply module temperature information PWM cycle error	P152F
523615	8	Supply module temperature information PWM signal error	P152E
523616	2	Supply module (supply module temperature sensor) fault value for temperature information duty value received	P1530
523617	2	Supply module (supply module temperature sensor) invalid value for temperature information duty value received	P1531
523618	7	Supply module (pump motor) not starting to measure temperature	P20AD
523619	0	Supply module (pump motor) pressure rise error 1	P20E9
523620	7	Supply module (pump motor) pressure reduction failure	P1532





TROUBLESHOOTING  
**ENGINE ERROR CODE LIST**

Error code		Error details	DTC
SPN	FMI		
523621	0	Aqueous urea hose (back flow side) pressure rise error	P1533
523622	7	Aqueous urea hose (pressure side) pressure rise error	P1534
523623	2	Supply module (pump motor) pressure stability error	P150F
523624	7	Supply module (reverting valve) failure	P1535
523625	0	Supply module aqueous urea sucking back failure	P204F
523626	0	Supply module (pump motor) pressure rise error 2	P1536
523627	1	Supply module pressure drop error	P1537
523628	10	Supply module aqueous urea pressure rise failure	P1538
523630	2	Aqueous urea tank temperature rise error	P154B
523634	9	A1DEFI reception timeout	U1610
523635	9	AT1T1I reception timeout	U1611
523636	0	SCR system error (Inducement2)	P1554
	16	SCR system error (Inducement1)	P1553
523637	0	ECU system error (FS action instruction 1 from ECU)	P155C
523640	5	Key switch disconnection	P1561
523643	9	Data verification error between ECU and DCU (verification timeout)	U1502



## OTHER SYMPTOMS

For symptoms not included in the table below or if the problem persists after the proper remedies have been taken, consult your sales or service dealer.

Symptoms	Major causes	Remedies
Left and right control levers do not move smoothly	<ul style="list-style-type: none"><li>• Insufficient grease on the left and right control levers</li></ul>	<ul style="list-style-type: none"><li>• Grease the levers. Refer to page 5-59.</li></ul>
Dumping, swinging or traveling operation not possible	<ul style="list-style-type: none"><li>• Safety lock lever is raised (locked)</li><li>• Fuse is blown</li></ul>	<ul style="list-style-type: none"><li>• Lower the safety lock lever (release). Refer to page 2-39.</li><li>• Replace the fuse. Refer to page 6-6.</li></ul>
Dumping or swinging force is insufficient	<ul style="list-style-type: none"><li>• Hydraulic oil level too low</li><li>• Hydraulic oil is not warm enough</li><li>• Air cleaner is clogged</li><li>• Hydraulic oil is not of suitable type</li></ul>	<ul style="list-style-type: none"><li>• Add to the specified level. Refer to page 5-21.</li><li>• Perform the warm-up. Refer to page 3-8.</li><li>• Clean the air cleaner. Refer to page 5-39.</li><li>• Replace the hydraulic oil. Refer to page 5-52.</li></ul>
Traveling is not possible or not smooth	<ul style="list-style-type: none"><li>• Stones or foreign objects are stuck</li></ul>	<ul style="list-style-type: none"><li>• Remove the foreign object.</li></ul>
Machine veers to the right/left	<ul style="list-style-type: none"><li>• Stones or foreign objects are stuck</li></ul>	<ul style="list-style-type: none"><li>• Remove the foreign object.</li></ul>
Switches are not functioning	<ul style="list-style-type: none"><li>• Fuse is blown</li></ul>	<ul style="list-style-type: none"><li>• Replace the fuse. Refer to page 6-6.</li></ul>
Travel speed cannot be changed	<ul style="list-style-type: none"><li>• Fuse is blown</li></ul>	<ul style="list-style-type: none"><li>• Replace the fuse. Refer to page 6-6.</li></ul>
Swinging is not possible or not smooth	<ul style="list-style-type: none"><li>• Insufficient grease on the swing bearing</li></ul>	<ul style="list-style-type: none"><li>• Grease the swing bearing. Refer to page 5-45.</li></ul>
Hydraulic oil temperature is too high	<ul style="list-style-type: none"><li>• Hydraulic oil level too low</li></ul>	<ul style="list-style-type: none"><li>• Add up to the specified level. Refer to page 5-21.</li></ul>



Symptoms	Major causes	Remedies
Starter motor turns but engine does not start	<ul style="list-style-type: none"><li>• Insufficient fuel</li><li>• Air in fuel system</li><li>• Water in fuel system</li><li>• Fuel is frozen.</li><li>• Engine control system is faulty.</li><li>• Fuel line is faulty.</li><li>• Preheating device is faulty.</li></ul>	<ul style="list-style-type: none"><li>• Add fuel. Refer to page 5-20.</li><li>• Bleed air. Refer to page 6-10.</li><li>• Drain water. Refer to page 5-38.</li><li>• Warm the fuel pipe with hot water or wait until the ambient temperature becomes high.</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li></ul>
Tracks come off	<ul style="list-style-type: none"><li>• Tracks too loose</li></ul>	<ul style="list-style-type: none"><li>• Consult your sales or service dealer. Refer to page 5-33.</li></ul>
Engine exhaust is white or bluish	<ul style="list-style-type: none"><li>• Excessive engine oil</li><li>• Insufficient engine warm-up.</li><li>• Engine control system is faulty.</li><li>• Fuel line is faulty.</li><li>• Prolonged idling (approx. two hours or more)</li><li>• Poor fuel</li></ul>	<ul style="list-style-type: none"><li>• Adjust to the specified level. Refer to page 5-19.</li><li>• Perform the warm-up operation. Refer to page 3-5.</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Increase the engine RPM and check for smoke.</li><li>• Replace the fuel.</li></ul>



**TROUBLESHOOTING**  
**OTHER SYMPTOMS**

<b>Symptoms</b>	<b>Major causes</b>	<b>Remedies</b>
Engine exhaust is occasionally black	<ul style="list-style-type: none"><li>• Air cleaner is clogged</li><li>• Engine control system is faulty.</li><li>• Fuel line is faulty.</li><li>• Clogging in the exhaust line.</li><li>• DPF is faulty.</li></ul>	<ul style="list-style-type: none"><li>• Clean the air cleaner. Refer to page 5-39.</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li><li>• Adjust or repair (ask your sales or service dealer).</li></ul>
Irregular noise is produced from the engine (combustion or mechanical noise)	<ul style="list-style-type: none"><li>• Low quality fuel is being used</li><li>• Engine is overheating</li><li>• Damage inside the muffler</li></ul>	<ul style="list-style-type: none"><li>• Replace the fuel.</li><li>• Refer to “If the engine overheats” on page 6-3.</li><li>• Replace the muffler. For replacement, ask your sales or service dealer.</li></ul>
Headlights do not come on.	<ul style="list-style-type: none"><li>• The switch located on the light is off.</li></ul>	<ul style="list-style-type: none"><li>• Turn on the switch located on the light.</li></ul>



## TOWING

### WARNING

When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.

- It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
- Do not use a wire rope that is kinked, twisted or otherwise damaged.
- Do not apply heavy loads abruptly to the wire rope.
- Wear safety gloves when handling the wire rope.
- Make sure there is an operator on the machine being towed as well as on the machine that is towing.
- Never tow on slopes.
- Do not let anyone come near to the wire rope while towing.


**IMPORTANT:** Do not tow a machine if its engine does not start or if the machine does not run. Doing so could damage the machine being towed.

**IMPORTANT:** Be sure to follow the steps below closely when towing. Failure to heed even one of the steps may cause damage to the hooks (1).

### Towing the machine


Use the procedure described below to tow heavy objects or the machine itself if it should get stuck in the mud and not be able to get out on its own.

<Front>



1. Attach the wire rope to the hooks (1).

<Rear>



- Permissible forces: 75.4 kN (16947 lbf)

1. Attach the wire rope to the shackle.
2. Fasten the shackle to the towing holes (2).
3. Make sure that the wire rope is horizontal and is lined up straight with the travel frame. (Cone angle of 20° or less)
4. Move the machine to tension the wire rope.
5. Move the machine at a low speed of 2 km/h (1.24 mph) or less to a place (convenient location for repair) a short distance from the site.

**Note:** Do not tow using only a towing hook or hole on one side.




## LOWERING THE DUMP BODY

### **WARNING**

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
  - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
  - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped.  
Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Keep away from the working area when the dump body is lowered. You may be hit by the dump body or the material falling out of it.
- Slowly turn the valve nut and lower the dump body at a slow pace.
- Do not loosen or remove the hoses not located in the specified places. Doing so could cause the oil to spurt out.

1. Slightly turn the stop valve (1) clockwise. (The dump body starts moving down.)
2. Slowly lower the dump body.
3. After the dump body is fully lowered, check the safety and stability of the machine.
4. Close the stop valve (1) by turning it counterclockwise.

If the dump body must be fully lowered while the engine is stopped, use the following procedure.



**IMPORTANT:** After lowering the dump body, be sure to close the stop valve (1). If not closed, the dump body cannot be raised.



## **IF THE CAB IS DAMAGED**



### **WARNING**

Immediately replace the damaged cab. Serious injury or death may occur if the machine is operated with damaged cab. Do not operate the machine until the replacement is complete. Do not try to repair the damaged cab by welding. Doing so could endanger the safety of the cab.

---

Cab part number: 07186-00010



# EXHAUST GAS CONTROL SYSTEM ERROR

## ERROR CODE LIST

If the exhaust gas control system detects an error, the ECM error warning lamp turns on or flashes and the following error codes are displayed.

If an error code appears, immediately repair the fault part detected, or consult your sales or service dealer for help.

Error code		Error description		DTC	NCD or PCD Error*	Limited engine
SPN	FMI	Fault location	Cause			Level
102	3	EGR Differential Pressure Sensor	1. Wiring Bypass	P0238	N	2
102	4	EGR Differential Pressure Sensor	1. Wiring Disconnection 2. Sensor Removal	P0237	N	2
102	10	EGR Differential Pressure Sensor	1. Pressure Hose Removal 2. Sensor Leave in Atmosphere 3. Dummy Resistance	P1673	N	6
110	4	Coolant Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P0117	N	4
3251	3	DPF Differential Pressure Sensor	1. Wiring Bypass	P2455	N	2
3251	4	DPF Differential Pressure Sensor	1. Wiring Disconnection 2. Sensor Removal	P2454	N	2
4795	31	DPF Differential Pressure Sensor	1. Pressure Hose Removal 2. SF Removal 3. Sensor Leave in Atmosphere 4. Dummy Resistance	P226D	P	6
3242	3	DPF Inlet Temperature Sensor	1. Wiring Bypass	P1428	P	2
3242	4	DPF Inlet Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P1427	P	2
3250	3	DPF Intermediate Temperature Sensor	1. Wiring Bypass	P1434	P	2
3250	4	DPF Intermediate Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P1435	P	2
412	3	EGR Gas Temperature Sensor	1. Wiring Bypass	P041D	N	3
412	4	EGR Gas Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P041C	N	3
105	3	Intake Manifold Temperature Sensor	1. Wiring Bypass	P040D	N	2
105	4	Intake Manifold Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P040C	N	2
173	3	Exhaust Manifold Temperature Sensor	1. Wiring Bypass	P0546	N	3
173	4	Exhaust Manifold Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P0545	N	3
2791	12	EGR Valve	1. Wiring Disconnection	P0403	N	4

\*:

N: NCD (NOx Control Diagnostic system)

P: PCD (Particulate Control Diagnostic system)



**NOX CONTROL DIAGNOSTIC SYSTEM (NCD)**

The NCD system warns the operator of any error detected by turning on the warning lamp and displaying an engine error code. The engine output is limited depending on the type of fault.

**PARTICULATE CONTROL DIAGNOSTIC SYSTEM (PCD)**

The PCD system warns the operator of any error detected in the particulate after-treatment system such as the DPF, by using the warning lamp and displaying an engine error code. The engine output is limited depending on the type of fault.




## LIMITING THE ENGINE OUTPUT

If the exhaust gas control system detects an error, the engine output is limited depending on the type of fault.

There are three types of engine output limitation, each corresponding to the fault level determined.

**Note:** If the time interval between the fault repairing and error detecting is short, the regular operation may be executed with a shorter pre operation.

### Level 2



AM4J001E

———— : Normal  
- - - - - : Limited output


**Pre operation:** when the error is detected, the engine torque is reduced by 85%, compared to the normal operation.

The engine revolution becomes +200 min<sup>-1</sup>, compared to the maximum torque.

**Regular operation:** after 15-minute pre operation, the regular operation starts. The engine torque is reduced by 50%, compared to the normal operation. The engine revolution becomes +200 min<sup>-1</sup>, compared to the maximum torque. The regular operation continues until the error is resolved.



Level 3 or 4




———— : Normal  
----- : Limited output

**Pre operation:** when the error is detected, the engine torque is reduced by 85%, compared to the normal operation.

**Regular operation:** after 120-minute pre operation, the regular operation starts. The engine torque is reduced by 50%, compared to the normal operation. The regular operation continues until the error is resolved.



Level 6 (only NCD)



———— : Normal  
- - - - - : Limited output

**Pre operation 1:** If an error is detected, the warning lamp turns on or starts flashing; the engine output is not limited.

**Pre operation 2:** Pre operation 2 starts after pre operation 1 continues 36 hours. The engine torque is reduced by 75%, compared to the normal operation.

**Regular operation:** Regular operation starts after the pre operation 2 continues 64 hours. The engine torque is reduced by 50%, compared to the normal operation. The regular operation continues until the error is resolved.

**OUTPUT LIMITATION PERFORMED BY INDUCEMENT DUE TO AN ABNORMALITY DETECTED IN THE SCR SYSTEM**

The term “inducement” used here refers to the action of limiting the engine RPM or fuel injection amount if the DEF/AdBlue® injection fails due to an abnormality.

If an abnormality is detected in the SCR system (including a decrease in the quality of DEF/AdBlue®), the inducement is activated to prevent the engine from running with a failure in the injection of DEF/AdBlue®. If the engine continues to operate in the inducement status, the engine RPM and fuel injection amount are limited so strictly that operation will eventually become impossible. If this happens, immediately correct the abnormality.

According to the engine running time since the abnormality, the following three levels of inducement are provided in the SCR system.

**a. Warning**

The SCR system warning lamp lights up.

The system enters the warning level if an abnormality occurs, and remains at this level until the engine running time reaches 3 hours and 40 minutes (or 10 minutes in the case of \*1) unless the abnormality is corrected. Whether there is a limitation on the engine RPM or the fuel injection amount depends on the error type.

**b. Inducement 1**

The SCR system warning lamp flashes.

The system enters the inducement level 1 if the duration of the warning level exceeds 3 hours and 40 minutes (or 10 minutes in the case of \*1), and remains at this level until the engine running time reaches 4 hours (or 30 minutes in the case of \*1). At this time, the engine RPM is limited to the maximum torque rotation speed + 200 min<sup>-1</sup> (or to low idle, depending on the error type) and the maximum fuel injection amount is limited to 50%.


**c. Inducement 2**

The system enters the inducement level 2 if the duration of inducement level 1 exceeds 4 hours (or 30 minutes in the case of \*1). The engine RPM is limited to low idle and the maximum fuel injection amount is limited to 50%.



The relation between the engine running time and the inducement is shown in the figure below. Once an abnormality occurs, the inducement status cannot be canceled even if the engine is stopped and restarted, and the level at the time of engine stopping will be continued.

### The relation between the engine running time and the inducement if an abnormality occurs



\*1: If another inducement-related abnormality occurs within 40 hours of engine running time after the last abnormality is corrected.



If the inducement status occurs due to the abnormality in the SCR system, errors by each level are detected. Please contact your local sales or service dealer.

**Table 1-1 Relation between inducement level and errors detected**

Location of abnormality	Inducement level	DTC code			Error
		P code	SPN	FMI	
Engine system	Warning	P155C	523637	0	ECU system error FS action request 1 from ECU
	Inducement 1	P1553	523636	16	SCR system error Inducement 1
		P155C	523637	0	ECU system error FS action request 1 from ECU
	Inducement 2	P1554	523636	0	SCR system error Inducement 2
		P155C	523637	0	ECU system error FS action request 1 from ECU
	SCR system	Inducement 1	P1553	523636	16
Inducement2		P1554	523636	0	SCR system error Inducement 2

**OUTPUT LIMITATION PERFORMED BY INDUCEMENT DUE TO DECREASED DEF/ADBLUE® TANK LEVEL**

By detecting a decrease in the level of DEF/AdBlue® left in the tank, the inducement is activated to prevent the engine from running with an empty DEF/AdBlue® tank. If the engine continues to operate in the inducement status, the engine RPM and fuel injection amount are limited so strictly that operation will eventually become impossible. If the inducement is activated, immediately add DEF/AdBlue® to cancel the inducement.

According to the DEF/AdBlue® level detected, the following three levels of inducement are provided due to the decrease in the DEF/AdBlue® tank level.

**a. Warning**

The DEF/AdBlue® level warning lamp lights up.

The system enters the warning level if the level of the DEF/AdBlue® level meter decreases to 10% or less. The engine RPM and fuel injection amount are not limited.

**b. Inducement 1**

The DEF/AdBlue® level warning lamp flashes.

The system enters the inducement level 1 if the level of the DEF/AdBlue® level meter decreases to 0% or less. The maximum fuel injection amount is limited to 75%.

**c. Inducement 2**

The system enters the inducement level 2 if the DEF/AdBlue® level in the fuel tank is zero (unable to draw up DEF/AdBlue®). The engine RPM is limited to low idle and the maximum fuel injection amount is limited to 50%.

If the inducement status occurs due to a decrease in the DEF/AdBlue® level in the tank, errors by each level are detected. If this happens, immediately add DEF/AdBlue®.

**Relation between inducement level and errors detected**

Location of abnormality	Inducement level	DTC code			Error
		P code	SPN	FMI	
DEF/AdBlue® tank level	Inducement 1	P1549	1761	18	DEF/AdBlue® tank level decreased. Inducement 1
	Inducement 2	P154A	1761	1	DEF/AdBlue® tank level decreased. Inducement 2



# SPECIFICATIONS





## BASIC SPECIFICATIONS

Type		Cab	
<b>MASS</b>			
Operating mass	kg (lb)	6550 (14440)	
<b>PERFORMANCE</b>			
Dump body capacity (Standard dump body)	m <sup>3</sup> (cu.ft.)	Heaped	2.055 (72.57)
		Struck	1.15 (40.61)
Maximum loading mass	kg (lb)	3700 (8160)	
Travel speed	km/h (mph)	1st	7.0 (4.35)
		2nd	9.5 (5.90)
Gradeability	degrees	30	
Ground pressure (ISO 16754: 2008)	kPa (psi)	With dump body full	42 (6.09)
		With dump body empty	27 (3.92)
Noise level	dB (A)	Sound power level	LWA 102
		Emission sound pressure level at the operator's position (ISO 6396,2008:)	—
<b>ENGINE</b>			
Manufacturer and model		Yanmar 4TNV94FHT-NTBC	
Rated output	Net (ISO 14396)	kW/min <sup>-1</sup> (hp/rpm)	88.4/2500 (118.5/2500)
	Net (ISO 9249/ SAEJ1349)	kW/min <sup>-1</sup> (hp/rpm)	83.2/2500 (111.6/2500)
Displacement	ml (cu.in.)	3053 (186.3)	
Amount of CO <sub>2</sub> emission*	g/kWh	732	
Starter	V-kW	12-3	
Alternator	V-kW	12-0.96	
Battery (IEC 60095-1)	V-A·h	12-90	
CCA	A	795	


\*: The amount of CO<sub>2</sub> emission refers to the value obtained by testing the parent engine representing the engine type (engine family member) being used; it shall not guarantee the performance of the machine.

**MEMO**

---



# MACHINE DIMENSIONS



AS7K001




SPECIFICATIONS  
**MACHINE DIMENSIONS**

Unit: mm (inch)

	<b>Item</b>	<b>Standard dump body</b>
<b>A</b>	Overall height	2725 (107.3)
<b>B</b>	Height of bumper	1040 (40.9)
<b>C</b>	Overall length	4660 (183.5)
<b>D</b>	Length of track ground	2500 (98.4)
<b>E</b>	Track base	3145 (123.8)
<b>F</b>	Dump body floor height	1330 (52.4)
<b>G</b>	Dump body flap height from the ground	1715 (67.5)
<b>H</b>	Overall width	2200 (86.6)
<b>J</b>	Track shoe width	450 (17.7)
<b>K</b>	Ground clearance of undercarriage	435 (17.1)
<b>L</b>	Cab width	990 (39.0)
<b>M</b>	Dump body length (inside)	2615 (103.0)
<b>N</b>	Dump body width	1795 (70.7)
<b>P</b>	Height of dump body gate	385 (15.2)
<b>Q</b>	Height of dump body front gate	750 (29.5)

# OPERATING RANGES



AS7K002



Unit: mm (inch)

	<b>Standard dump body</b>
<b>A</b>	4680 (184.3)
<b>B</b>	885 (34.8)
<b>C</b>	3610 (142.1)
<b>D</b>	1005 (39.6)
<b>E</b>	1730 (68.1)
<b>F</b>	2735 (107.7)
<b>G</b>	90°
<b>H</b>	90°
<b>J</b>	65°





# OPTIONS



## GENERAL PRECAUTIONS

### SAFETY PRECAUTIONS

#### **WARNING**

When removing or installing an attachment or optional part, take the following precautions.

- Consult with Takeuchi before installing an optional attachment.
- Do not use any attachments not approved by Takeuchi. Doing so may cause safety problems. Or, it may adversely affect the machine's operation or service life.
- We will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.
- Select a firm, level work area. Also, be sure to park in a well ventilated place.
- Clear obstacles and dangerous objects, and clean up spilled fuel immediately.
- When it is necessary to temporarily place a heavy object or an attachment on the ground during removal or installation, be sure to place it in a stable position.
- Use the proper procedure when mounting an attachment; otherwise serious damage could result. Consult your sales or service dealer for help.
- When hoisting, be sure to designate a person to act as a signalman. Follow the instructions of the signalman regarding the procedure and measures.
- Keep everyone out of the area when hoisting. There is a hazard of objects falling or contacting with people in the area.
- Use a crane to move heavy objects (25 kg (55 lb.) or greater).
- Before removing a heavy object, be sure to put a support to it. When lifting with a crane, pay attention to the center of gravity of the load to keep the machine in balance.
- Do not operate the machine while the load is lifted by a crane stand.

### CAUTIONS WHEN INSTALLING ATTACHMENTS


Be sure to perform a test operation after an optional or other special attachment has been replaced. Inspect the hydraulic oil level and recharge it as necessary. Consult your sales or service dealer for detailed procedures on installing/removing attachments.




## PRECAUTIONS WHEN OPERATING ATTACHMENTS

### **WARNING**


Long or large attachments reduce stability of the machine. The machine may tip over if it loses the balance when traveling or slewing on slopes. Never perform the operations listed below as they are extremely dangerous.



- Traveling down the slopes with the dump body raised



- Traveling across slopes



- Turning on slopes
- If there is a heavy attachment is installed, the machine takes larger operating range than usual to swing. Carefully judge the distance so as not to bump into an object around the machine. Keep a safe distance from surrounding obstacles to the attachment.  
Also, be aware that the spontaneous drop (the gradual dropping of the attachment under its own weight when it is stopped in midair) gets larger as the attachment gets heavier.
- The machine can tip over more easily in the lateral direction than in the longitudinal direction.
  - Do not swing sideways when the dump body is heavily loaded. In particular, do not swing sideways on slopes.

**OPTIONAL EQUIPMENT MASS**

Standard machine mass (Not including operator)	<b>Cab</b>
	6475(14275)
<b>OPTION</b>	
Heater	-20(-44)

Units: kg (lb)

\*: Mass of optional equipment is added to the standard machine mass.

\*: This table only contains the optional equipment of 10 kg (20 lb) or more in mass.




## TAKEUCHI SECURITY SYSTEM

The Takeuchi Security System is a system that allows only registered ignition keys to be used for starting the engine.


The engine cannot be started with any unregistered or counterfeit ignition keys. If a registered ignition key is lost or stolen, you can set the system to delete the registered key information, so that the lost or stolen key cannot be used to start the engine. Although machine theft cannot be completely prevented, the system certainly helps reduce the risk of theft.

### IGNITION KEY




There are two types of ignition key, red and black, which can be registered in the Takeuchi Security System. The red key is the master key. The black key is the starting key.

### STARTING THE ENGINE



The engine can be started using the normal method with a registered BLACK key. The engine cannot be started using the RED master key. Refer to Chapter 3, “Starting and stopping the engine”.

**If an attempt is made to start the engine with an unregistered key:**



If an unregistered ignition key is turned from the OFF to the ON (ACC) position, the message “Authentication failure” appears and the alarm starts sounding. If this attempt is repeated five times in a row, the horn sounds for two minutes, and the engine cannot be started. The horn stops when the key is turned to the OFF position.



## REGISTERING AND DELETING THE IGNITION KEY

### **WARNING**

- Sit on the operator's seat.
- Raise the safety lock lever to the locked position.
- Clear all people from the machine and the area.
- Sound the horn to warn people around the machine.


Registration may fail if the ignition key is on a keyring or keychain; remove it before starting registration.

A malfunction could occur if multiple ignition keys are brought near to the key cylinder. Be sure that no ignition keys other than the correct key are near the key cylinder during registration.


### Ignition key registration procedure

For Steps 1 to 6 below, complete each step and proceed to the next one within five minutes. If no operation is performed for five minutes during this procedure, the system returns to the initial state.



From Step 7 onward, the system automatically ends the operation if no operation is performed for five minutes.




1. Insert the master key (1) into the ignition switch and turn the key from the OFF to the ON (ACC) position.



2. On the LCD, select “REGISTER” and press (A).





4. When the message “Certification was completed” appears on the LCD, turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the ignition switch.




3. Select whether to delete all of the existing registration information.

On the LCD, select “YES” and press (A):  
All registration information will be deleted;  
register a new key.

On the LCD, select “NO” and press (A): A  
new ignition key will be added to the  
existing registration information.




5. Insert the ignition key (2) to be registered into the ignition switch and turn the key from the OFF to the ON (ACC) position.




6. If the registration was successfully completed, the message "Registration was completed" appears. This means that the ignition key (2) currently inserted has been registered.  
If the registration fails, the message "Registration failure" appears.






AV/BL012




AV/BL004

8. Insert the master key (1) into the ignition switch and turn the key from the OFF to the ON (ACC) position. Or, wait for five minutes or more.



AV/BL024

7. Turn the ignition key (2) from the ON (ACC) to the OFF position, and then remove it from the ignition switch.  
To continue registration, repeat the steps from Step 5.  
To end registration, proceed to Step 8.




AV/BL025

9. If any ignition key has been registered, the message “All the registration is completed” appears. Turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the ignition switch to complete the registration.  
If no ignition key has been registered, the message “Registration failure” appears, and the registration information is returned to the initial state.




### Deleting a registered ignition key



The information of each registered ignition key can be deleted to cancel its ability to start the engine.




1. Insert the master key (1) into the ignition switch and turn the key from the OFF to the ON (ACC) position.



2. On the LCD, select "DELETE" and press (A).




3. When the display shown as the illustration appears on the LCD, turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the ignition switch.  
**Note:** If the registered key is lost and you want to delete all registration information, please refer to STEP 3 (A) on page 8-7.




4. Insert the ignition key (2) to be deleted into the ignition switch and turn the key from the OFF to the ON (ACC) position.

5. If the deletion is successful, the message "Success" appears. This means that the information registered for the ignition key (2) currently inserted has been deleted. If the deletion fails, the message "Failure" or "Authentication failure" appears on the LCD. Remove the ignition key, and then repeat the steps from Step 1 again.



6. Turn the ignition key (2) from the ON (ACC) to the OFF position, and then remove it from the ignition switch. To continue deletion, repeat the steps from Step 1.



**IF THE MASTER KEY IS LOST**

If you lose your master key, contact your service or sales dealer for assistance.

**COUNTRIES WHERE THE SYSTEM CAN BE USED**

To use the Takeuchi Security System, “radio wave authentication” must be obtained in the country where the system is to be used. The system can be used in the countries listed below, as of January 2017. Do not use the system in other countries. For details on how to disable the system, please contact your service or sales dealer for assistance.

---

**Countries where the system can be used:**

---

Ireland, Italy, UK, Estonia, Austria, Holland, Cyprus, Greece, Croatia, Sweden, Spain, Slovakia, Slovenia, Czech, Denmark, Germany, Hungary, Finland, France, Bulgaria, Belgium, Poland, Portugal, Malta, Latvia, Lithuania, Rumania, Luxemburg, Iceland, Norway, Liechtenstein, Switzerland, Turkey

---



## **TAKEUCHI FLEET MANAGEMENT**



If equipped, please contact your local dealer for activation and use information.

---

First Published November 2019  
Second Published January 2020

AAA0E001

## **OPERATOR'S MANUAL**

TCR50-2 Crawler Dumper

Edited and issued by TAKEUCHI MFG. CO., LTD.

---

Printed in Japan by STATION M Co., Ltd.



ZTR Control Systems, LLC

955 Green Valley Road  
London, Ontario, N6N 1E4  
Tel: 1-519-452-1233  
FAX: 1-519-452-7764

April 5, 2019

www.ztr.com  
info@ztr.com

RE: M7H

To whom it may concern,

This letter is to confirm that ZTR product **M7H** sufficiently demonstrate compliance to CE and the Radio Equipment Directives (RED). The M7H satisfies all the technical regulations applicable to the product within the scope of Council Directives 2014/53/EU, 2015/35/EU and 2014/30/EU. The following tests were completed successfully.

EN 60950-1: 2006+A11: 2009+A1: 2010+A12: 2011+A2: 2013

EN62311:2008

ETSI EN 300 328 V2.1.1 (2016-05)

ETSI EN 303 413 V1.1.1 (2017-06)

Draft ETSI EN 301 489-52 V1.1.0 (2016-11)

Draft ETSI EN 301 489-17 V3.2.0 (2017-03)

Draft ETSI EN 301 489-1 V2.2.0 (2017-03)

Draft ETSI EN 301 489-19 V2.1.0 (2017-03)

EN 55032: 2015

ETSI EN 301 511 V12.5.1 (2017-03)

ETSI EN 301 908-1 V11.1.1 (2016-07)

ETSI EN 301 908-2 V11.1.2 (2017-08)

(Title(s) of regulations, standards, etc.)

All essential radio test suites have been carried out.

The tests were carried out by a notarized 3<sup>rd</sup> party certification lab MICOM Labs Inc.

This Declaration of Conformity is issued under the sole responsibility of ZTR Control Systems (or the manufacturer).

Please direct any test results questions or concern to ZTR's Engineering Group for clarification.

Regards,

Brent Horne  
Director of Product Development  
ZTR Control Systems

## **Declaration of Conformity**

We herewith declare that following named machine, based on its conception and design and in the form brought into service is in accordance with the relevant, basic safety and health requirements of the following EU directives. In case of any alteration of the machine not coordinated with us, this certificate loses its validity.

Designation of the machine    Crawler Dumper  
Manufacturer                    TAKEUCHI MFG. CO., LTD  
    205 Uwadaira, Sakaki-machi, Hanishina-gun, Nagano  
    389-0605, Japan

Model                            TCR50-2  
Engine type                    4TNV94FHT-N (e13\*2016/1628\*2016/1628EV5/D\*0200\*Δ)  
Engine power                 88.4kW @ 2500 rpm

The machine is in accordance with the requirements of EU directives:

- 1) Machine directive: 2006/42/EC and appendix
- 2) Electromagnetic compatibility-regulation: 2014/30/EU and appendix
- 3) Noise directive: 2000/14/EC (Evaluation procedure according to appendix VI), 2005/88/EC and appendices.
- 4) Regulations on engine emissions: Regulation (EU) 2016/1628, as last amended by Regulation 2016/1628.

Harmonized norms: EN474-1:2006+A5:2018, EN474-6:2006+A1:2009.

Compiler of the technical files:

Daniel Bailli  
Parc d'Activités des Béthunes  
3, avenue de la Mare 95310 SAINT OUEN L'AUMONE  
CS 29258 – SOA

Issued in Sakaki, Japan  
Akio Takeuchi, Chairman





**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to [www.P65warnings.ca.gov/diesel](http://www.P65warnings.ca.gov/diesel).



# WARNING:

Cancer and Reproductive Harm –  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)